



**POWER SOLUTIONS
INTERNATIONAL**

PSI HD 4G

DIAGNOSTIC MANUAL

LARGE SPARK IGNITED

<i>Engine Type</i>	<i>Series</i>
8L	GE Series
11L	GE Series
14.6L	GV Series
18.3L	GV Series
22L	GV Series

A Product by Power Solutions International
Wood Dale, IL

This publication may not be reproduced without written permission of Power Solutions International (PSI). At date of publication, all information included in this manual is accurate to the best of our knowledge. PSI cannot be held responsible for information that has changed after publication date.

**Power Solutions International, Inc (PSI)
201 Mittel Drive
Wood Dale, IL 60191
USA
630-350-9400**

REVISION CONTROL INFORMATION

Revision Level	Release Date	Change Description (s)
1	01/10/2020	Initial Release
2	02/23/2021	Included Pre-lube Electrical Diagrams
3	10/30/2023	Added DTC 1603
4	11/21/2023	Updated troubleshooting trees to 5 column tables and added DTC that were missing but on the DTC list.
5	2/24/2024	Merged all HD 4G products into this manual including new 20L, 17L, etc.
6	8/28/2025	Updated all images related to UEGO1 to correct image. Added multiple new DTC's, general updates throughout the manual. Details on ignition coil codes added to manual.

This manual applies to the PSI HD Engines listed below using the 4G Controller. Some information can be applied to other engine platforms since the controls and diagnostics are often shared between engine platforms. In any case, the diagnostic manual provides general information on the systems. Certain engines or products may have unique diagnostic codes, setting conditions, and wiring circuits.

8L HDI Engine

11L HDI Engine

14.6L HDI Engine

18.3L HDI Engine

22L HDI Engine

DIAGNOSTIC TROUBLE CODE (DTC) CHART	9
Diagnostic Trouble Code Setting Conditions and Diagnostics	13
OBD System Check/MIL (Malfunction Indicator Lamp)	14
DTC 6 - Lockoff Open / Ground Short	15
DTC 7 - Lockoff Short to Power	17
DTC 11 - Intake Cam / Distributor Position	19
DTC 16 - Never Crank Synced at Start	21
DTC 51 - EGOH2 Open / Ground Short	25
DTC 52 - EGOH2 Short to Power	27
DTC 107 - MAP Low Voltage	29
DTC 108 - MAP High Pressure	31
DTC 111 - IAT Higher Than Expected Stage 1	33
DTC 112 - IAT Low Voltage	34
DTC 113 - IAT High Voltage	36
DTC 116 - ECT Higher Than Expected 1	38
DTC 117 - ECT/CHT Low Voltage	40
DTC 118 - ECT/CHT High Voltage	42
DTC 121 - TPS 1 Lower Than TPS 2	44
DTC 122 - TPS 1 Low Voltage	46
DTC 123 - TPS 1 High Voltage	48
DTC 127 - IAT Higher Than Expected 2	51
DTC 129 - BP Low Pressure	52
DTC 148 - Fuel Run-out Longer Than Expected	55
DTC 154 - EGO2 Open/Lazy	58
DTC 186 - (3468:1) - FT Gaseous Fuel Extremely Low	61
DTC 187 - Fuel Temperature Gaseous Low	62
DTC 188 - (520240:3) - FT Gaseous Fuel High	64
DTC 217 - ECT Higher Than Expected 2	66
DTC 219 - RPM Higher Than Max Allowed Governed Speed	67
DTC 221 - TPS 1 Higher Than TPS 2	68
DTC 222 - TPS 2 Signal Voltage Low	71
DTC 223 - TPS 2 Signal Voltage High	74
DTC 234 - Boost Control Overboost Failure	77
DTC 236 - TIP/TOP Active	79
DTC 237 - TIP/TOP Low Voltage	80
DTC 238 - TIP/TOP High Voltage	83
DTC 298 - Oil Temperature Too High	85

DTC 299 - Control Underboost	87
DTC 326 - Knock 1 Excessive Signal	89
DTC 327 – Knock I Sensor Open	91
DTC 336 - Crank Sync Noise	93
DTC 337 - Loss of Crankshaft Signal	96
DTC 341 - Cam Input Signal Noise	97
DTC 342 - Loss of Camshaft Input Signal	100
DTC 359 - (1239:7) - Fuel Run-Out Longer Than Expected	101
DTC 520 - Oil Pressure Low Stage 1	102
DTC 521 - Oil Pressure High (Sender)	105
DTC 522 - Oil Pressure Sender low voltage	107
DTC 523 - Oil Pressure Sender high voltage	109
DTC 524 - Oil Pressure Low Stage 2	112
DTC 562 - System Voltage Low	115
DTC 563 - Battery Voltage High	117
DTC 601 - Flash Checksum Invalid	119
DTC 604 - RAM Failure	121
DTC 606 - COP Failure	123
DTC 616 - Start Relay Control Ground Short	125
DTC 642 - External 5 Volt 1 Reference Low	127
DTC 643 - External 5 Volt 1 Reference High	129
DTC 652 - 5VE2 Low Voltage	131
DTC 653 - 5VE2 High Voltage	133
DTC 685 - Relay Coil Open	135
DTC 686 - Relay Control Ground Short	137
DTC 687 - Relay Coil Short to Power	139
DTC 726 - Max Govern Speed Override	141
DTC 1020 - MFG Unable to Reach Higher TPS	143
DTC 1022 - MFG Supply Voltage High	144
DTC 1023 - MFG Supply Voltage Low	146
DTC 1024 - MFG Fluid Temperature Voltage High	148
DTC 1025 - MFG Fluid Temperature Voltage Low	150
DTC 1026 - MFG Upstream Pressure Voltage High	152
DTC 1027 - MFG Upstream Pressure Voltage Low	154
DTC 1028 - MFG Downstream Pressure Voltage High	156
DTC 1029 - MFG Downstream Pressure Voltage Low	158
DTC 1111 - Fuel Rev Limit	160
DTC 1112 - Spark Rev Limit	162

DTC 1113 - RPM Higher Than Expected	164
UEGO Sensor Details.....	165
UEGO Sensor and Fuel Trim Diagnostics	166
DTC 1151 - Closed Loop High LPG.....	167
DTC 1152 - Closed Loop Multiplier Low LPG	168
DTC 1153 - Closed Loop Multiplier High NG.....	169
DTC 1154 - Closed Loop Multiplier Low NG.....	170
DTC 1161 - Adaptive Learn High LPG.....	171
DTC 1162 - Adaptive Learn Low LPG	172
DTC 1163 - Adaptive Learn High NG	173
DTC 1164 - Adaptive Learn Low NG	174
DTC 1171 - EPR Pressure Higher Than Expected	176
DTC 1172 - EPR Pressure Lower Than Expected.....	178
DTC 1173 - EPR/CFV Comm Lost	180
DTC 1174 - EPR/CFV Voltage Supply High.....	183
DTC 1175 - EPR/CFV Voltage Supply Low.....	184
DTC 1176 - EPR/CFV Internal Actuator Fault Detection	185
DTC 1177 - EPR/CFV Internal Circuitry Fault Detection	186
DTC 1178 - EPR/CFV Internal Comm Fault Detection	187
DTC 1271 - EPR Secondary Regulation Pressure Higher Than Expected	188
DTC 1272 - EPR Secondary Regulation Pressure Lower Than Expected	190
DTC 1325 - Knock Retard at Limit.....	192
DTC 1326 - Knock Retard Above Threshold.....	194
DTC 1330 - Intake Backfire Detected	195
DTC 1351 - Spark Plug or Coil Failure.....	200
DTC 1439 - Engine Oil Temperature Sensor High	201
DTC 1511 - AUX Analog PU1 High	202
DTC 1512 - AUX Analog PU1 Low	204
DTC 1514 - AUX Analog PU2 Low	206
DTC 1515 - AUX Analog PD1 High	208
DTC 1516 - AUX Analog PD1 Low	210
DTC 1517 - AUX analog PU3 high / Oil Temp Sensor High Voltage	212
DTC 1552 (111:0) – Aux Dig 1 Low Voltage / Coolant Level Low	214
DTC 1572 - AUX DIG4 high - Coolant Level Stage 1 High Voltage	215
DTC 1574 - AUX DIG5 high - Coolant Level Stage 2 High Voltage	217
DTC 1602 - Relay Off High Voltage	219
DTC 1603 - Relay On Low Voltage	221
DTC 1612 - RTI 1 Loss	223

DTC 1613 - RTI 2 Loss	225
DTC 1614 - RTI 3 Loss	227
DTC 1615 - A/D Loss	229
DTC 1616 - Invalid Interrupt	231
DTC 1625 - J1939 Shutdown Request	233
DTC 1626 - CAN1 Tx Failure	234
DTC 1627 - CAN1 Rx Failure	235
DTC 1628 - CAN Address Conflict	238
DTC 1646 - CAN2 Tx Failure	240
DTC 1647 - CAN3 Tx Failure	241
DTC 1648 - CAN2 Rx Failure	242
DTC 1649 - CAN3 Rx Failure	243
DTC 1650 - CAN2 Address Conflict Failure	244
DTC 1653 - CAN3 Address Conflict Failure	245
DTC 1673 - Calibration Configuration Error	246
DTC 1674 - Hardware ID Failure	247
DTC 2111 - Unable To Reach Lower TPS	249
DTC 2112 - Unable To Reach Higher TPS	252
DTC 2122 - FPP1 High Voltage	255
DTC 2123 - FPP1 Low Voltage	257
DTC 2135 - TPS1/2 Simultaneous Voltages Out of Range	259
DTC 2229 - BP High Pressure	260
Description and Diagnostic Aids for Primary Coil Faults	262
DTC 2301 - 1 Primary Coil Shorted	262
DTC 2300 - 1 Primary Loop Open or Low-Side Short to Ground	262
DTC 2304 - 2 Primary Coil Shorted	262
DTC 2303 - 2 Primary Loop Open or Low-Side Short to Ground	262
DTC 2307 - 3 Primary Coil Shorted	262
DTC 2306 - 3 Primary Loop Open or Low-Side Short to Ground	262
DTC 2310 - 4 Primary Coil Shorted	262
DTC 2309 - 4 Primary Loop Open or Low-Side Short to Ground	262
DTC 2313 - 5 Primary Coil Shorted	262
DTC 2312 - 5 Primary Loop Open or Low-Side Short to Ground	262
DTC 2316 - 6 Primary Coil Shorted	262
DTC 2315 - 6 Primary Loop Open or Low-Side Short to Ground	262
22L Cylinder Block Number Arrangement vs Firing Order	263
DTC 2300 - 1 Primary Loop Open or Low-Side Short to Ground	267
DTC 2301 - 1 Primary Coil Shorted	269

DTC 3011 - UEGO1 Internal Processor Fault	271
DTC 3012 - UEGO1 Heater Supply High Voltage	272
DTC 3014 - UEGO1 Cal Resistor Voltage High	274
DTC 3020 - UEGO1 Sense Cell Voltage High	276
DTC 3024 - UEGO1 Sense Cell Slow To Warm Up	278
DTC 3026 - UEGO1 Sense Cell Impedance High	279
DTC 3029 - Drift Is Out-Of-Tolerance	281
DTC 3030 - Drift Is Out-Of-Tolerance – Level 2	282
DTC 3031 - UEGO1 Heater Open/Ground Short	283
DTC 3032 - UEGO1 Heater Short to Power	285
DTC 8901 - UEGO1 Internal Processor Fault	287
DTC 8902 - UEGO1 Heater Supply High Voltage	288
DTC 8904 - UEGO1 Internal Supply Voltage Low	290
DTC 8910 - UEGO1 Sense Cell Voltage High	291
DTC 8914 - UEGO1 Sense Cell Slow to Warm Up	293
DTC 8915 - UEGO1 pump cell slow to warm up	294
DTC 8916 - UEGO1 Sense Cell Impedance High	295
DTC 8920 - UEGO1 Internal Supply Voltage Low	296
Connecting to Each ECM	302
Mass Fuel Gas (MFG) Diagnostic Trouble Codes	303
DTC 101A - MFG Main Comm Lost	304
DTC 101B - MFG Internal Circuitry Fault Detection	305
DTC 102A - MFG Delta Pressure zVoltage High	306
DTC 102B - MFG Delta Pressure zVoltage High	308
DTC 102C - MFG Delta Pressure Voltage High	310
DTC 102D - MFG Delta Pressure Voltage Low	312
DTC 102E - MFG Delta Pressure Voltage Low	314
DTC 103C - MFG RLV Test Failed	316
Pro-Lube Electrical Diagrams	317

DIAGNOSTIC TROUBLE CODE (DTC) CHART

Fault Code Description	DTC	SPN	FMI
Lockoff open / ground short	6	632	4
Lockoff short to power	7	632	3
Intake cam / distributor position	11	520800	7
Never crank synced at start	16	636	8
EGOH2 open / ground short	51	3232	4
EGOH2 short to power	52	3232	3
MAP low voltage	107	106	4
MAP high pressure	108	106	16
IAT higher than expected 1	111	105	15
IAT low voltage	112	105	4
IAT high voltage	113	105	3
ECT higher than expected 1	116	110	15
ECT / CHT low voltage	117	110	4
ECT / CHT high voltage	118	110	3
TPS1 lower than TPS2	121	51	1
TPS1 low voltage	122	51	4
TPS1 high voltage	123	51	3
IAT higher than expected 2	127	105	0
BP low pressure	129	108	1
Fuel run-out longer than expected	148	1239	7
EGO 2 Open / Lazy	154	520208	10
FT gaseous fuel extremely low	186	3468	1
FT gaseous fuel low	187	520240	4
FT gaseous fuel high	188	520240	3
ECT higher than expected 2	217	110	0
RPM higher than expected	219	515	31
TPS1 higher than TPS2	221	51	0
TPS2 low voltage	222	3673	4
TPS2 high voltage	223	3673	3
Boost Control Overboost Failure	234	102	0
TIP/TOP active	236	1692	2
TIP/TOP low voltage	237	1127	4
TIP/TOP high voltage	238	1127	3
Oil temperature too high	298	195	0
Control overboost	299	102	1
Knock excessive signal	326	731	2
Knock sensor open	327	731	4
Crank sync noise	336	636	2
Crank loss	337	636	4
Cam sync noise	341	723	2
Cam1 loss (intake)	342	723	4
Fuel run-out longer than expected	359	1239	7
Oil pressure low stage 1 (sender)	520	100	18
Oil pressure high (sender)	521	100	0
Oil pressure low voltage (switch or sender)	522	100	4
Oil pressure high voltage (switch or sender)	523	100	3
Oil pressure low stage 2 (sender)	524	100	1
Voltage low	562	168	17
Voltage high	563	168	15

Fault Code Description	DTC	SPN	FMI
Flash checksum invalid	601	628	13
RAM failure	604	630	12
COP failure	606	629	31
Start relay control ground short	616	1321	4
5VE1 low voltage	642	1079	4
5VE1 high voltage	643	1079	3
5VE2 low voltage	652	1080	4
5VE2 high voltage	653	1080	3
Relay coil open	685	1485	5
Relay control ground short	686	1485	4
Relay coil short to power	687	1485	3
Max govern speed override	726	515	15
MFG Unable to Reach Higher TPS	1020	520276	31
MFG Supply Voltage High	1022		
MFG Supply Voltage Low	1023		
MFG Fluid Temperature Voltage High	1024		
MFG Fluid Temperature Voltage Low	1025		
MFG Upstream Pressure Voltage High	1026		
MFG Upstream Pressure Voltage Low	1027		
MFG Downstream Pressure Voltage High	1028		
MFG Downstream Pressure Voltage Low	1029		
Fuel rev limit	1111	515	16
Spark rev limit	1112	515	0
RPM higher than expected	1113	515	31
CL high LPG	1151	520206	0
CL low LPG	1152	520206	1
CL high NG	1153	520207	0
CL low NG	1154	520207	1
AL high LPG	1161	520202	0
AL low LPG	1162	520202	1
AL high NG	1163	520203	0
AL low NG	1164	520203	1
EPR / CFV regulation pressure higher than expected	1171	520260	0
EPR / CFV regulation pressure lower than expected	1172	520260	1
EPR / CFV comm lost	1173	520260	31
EPR / CFV voltage supply high	1174	520260	3
EPR / CFV voltage supply low	1175	520260	4
EPR / CFV internal actuator fault detection	1176	520260	7
EPR / CFV external Vrelay intermittent or internal circuitry fault detection	1177	520260	12
EPR / CFV internal comm fault detection	1178	520260	12
EPR secondary regulation pressure higher than expected	1271	520621	0
EPR secondary regulation pressure lower than expected	1272	520261	1
Knock retard at limit	1325	731	15
Knock retard above threshold	1326	731	15
Intake backfire detected	1330	520390	31
Spark Plug or Coil Failure	1351	1268	11
AUX Temperature 1 high	1439	1385	0
AUX analog PU1 high	1511	520216	3
AUX analog PU1 low	1512	520216	4


Fault Code Description	DTC	SPN	FMI
AUX analog PU2 low	1514	520217	4
AUX analog PD1 high	1515	520215	3
AUX analog PD1 low	1516	520215	4
AUX analog PU3 high / Oil Temp Sensor High Voltage	1517	520218	3
AUX DIG1 low	1552	520222	4
AUX DIG4 high - Coolant Level Stage 1 High Voltage	1572	716	3
AUX DIG5 high - Coolant Level Stage 2 High Voltage	1574	520202	3
Relay off high voltage	1602	1485	0
Relay on low voltage	1603	1485	1
RTI 1 loss	1612	629	31
RTI 2 loss	1613	629	31
RTI 3 loss	1614	629	31
A/D loss	1615	629	31
Invalid interrupt	1616	629	31
Shutdown Request	1625	1384	31
CAN1 Tx failure	1626	639	12
CAN1 Rx failure	1627	639	12
CAN1 address conflict failure	1628	639	13
CAN2 Tx failure	1646	1231	12
CAN3 Tx failure	1647	1235	12
CAN2 Rx failure	1648	1231	12
CAN3 Rx failure	1649	1235	12
CAN2 address conflict failure	1650	1231	13
CAN3 address conflict failure	1653	1235	13
Calibration Configuration Error	1673	1634	13
Hardware ID Failure	1674	1634	2
Unable to reach lower TPS	2111	3673	7
Unable to reach higher TPS	2112	51	7
FPP1 high voltage	2122	91	3
FPP1 low voltage	2123	91	4
TPS1/2 simultaneous voltages	2135	51	31
BP high pressure	2229	108	0
1 Primary Loop Open or Low-Side Short to Ground	2300	1268	5
1 Primary Coil Shorted	2301	1268	6
UEGO1 internal processor fault	3011	3221	31
UEGO1 heater supply high voltage	3012	3222	3
UEGO1 cal resistor voltage high	3014	3221	3
UEGO1 sense cell voltage high	3020	3217	3
UEGO1 sense cell slow to warm up	3024	3222	10
UEGO1 sense cell impedance high	3026	3222	0
UEGO1 drift is out-of-tolerance	3029	0	31
UEGO1 drift is out-of-tolerance - level 2	3030	3221	16
UEGO1 heater open / ground short	3031	3222	4
UEGO1 heater short to power	3032	3222	3
UEGO1 internal processor fault	8901	3221	31
UEGO1 heater supply high voltage	8902	3222	3
UEGO1 cal resistor voltage high	8904	3221	3
UEGO1 sense cell voltage high	8910	3217	3
UEGO1 sense cell slow to warm up	8914	3222	10

Fault Code Description	DTC	SPN	FMI
UEGO1 sense cell impedance high	8916	3222	0
UEGO1 internal supply voltage low	8920	3221	0
MFG Main Comm Lost	101A		
MFG Internal Circuitry Fault Detection	101B		
MFG Delta Pressure zVoltage High	102A		
MFG Delta Pressure zVoltage High	102B		
MFG Delta Pressure Voltage High	102C		
MFG Delta Pressure Voltage Low	102D		
MFG Delta Pressure Voltage Low	102E		
MFG RLV Test Failed	103C		
MFG Delta Pressure zVoltage High	102B		
MFG Delta Pressure Voltage High	102C		
MFG Delta Pressure Voltage Low	102D		
MFG Delta Pressure Voltage Low	102E		
MFG RLV Test Failed	103C		

Diagnostic Trouble Code Setting Conditions and Diagnostics


OBD System Check/MIL (Malfunction Indicator Lamp)

Circuit Description



The fuel system is equipped with OBD (On-Board Diagnostics). The MIL serves as notification of an engine or fuel system related problem. The MIL also has the ability to flash DTC codes in what is referred to as the blink code mode. It will display DTCs that have been stored due to a possible system malfunction. The following DTC charts in this manual will instruct the technician to perform the OBD system check. This simply means to verify the operation of the MIL. The codes can be viewed from the Primary (Master) ECM on grounding pin #4 in the diagnostic connector.

DTC 6 - Lockoff Open / Ground Short



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Cranking or Running
- Fault Condition: PWM low-side feedback < 5% of Vbattery for 2 seconds and PWM duty cycle < 5%

Fault Description

A normally closed electromechanical fuel shut-off is used to isolate the Dual Stage Regulator (DSR) or the Continuous Flow Valve (CFV) and all downstream components from the upstream fuel supply when the engine is shut off.


Lockoff open/ground short monitors for electrical / wiring problems with the lockoff or the harness. The ECM monitors the voltage on the appropriate PWM pin when the lockoff is not energized.

This fault will set if the ECM detects low feedback voltage (% Vbat) on the lockoff while the lockoff circuit is in the off-state as defined in the diagnostic calibration.

DTC 6 - Lockoff Open / Ground Short

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF	Does the engine start and run?	Go to Step (3)	Go to Step (4)
3	Check the harness between the ECM and lockoff for a short to ground. If no short to ground is detected, the problem is intermittent.			-
4	Check the harness for an open between the ECM and the lockoff and/or an open between the lockoff and the lockoff power source Check fuses and relays associated with the power to the lockoff.			

DTC 7 - Lockoff Short to Power



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Cranking or Running
- Fault Condition: PWM low-side feedback < 90% of Vbattery for 2 seconds and PWM duty cycle < 90%

Fault Description

A normally closed electromechanical fuel shut-off is used to isolate the Dual Stage Regulator (DSR) or the Continuous Flow Valve (CFV) and all downstream components from the upstream fuel supply when the engine is shut off.

Lockoff short to power monitors for electrical / wiring problems with the lockoff or the harness.


The ECM monitors the voltage on the appropriate PWM pin when the lockoff is energized

This fault will set if the ECM detects high feedback voltage (% Vbat) on the lockoff while the lockoff circuit is in the on-state as defined in the calibration.

DTC 7 - Lockoff Short to Power

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine OFF	Does the engine start and run?	Go to Step (3)	Go to Step (4)
3	Fault Condition not present.			-
4	Check the harness for an short to power between the ECM and the lockoff and replace			

DTC 11 - Intake Cam / Distributor Position



Conditions for Setting the DTC

- Camshaft Position Sensor
- Check Condition: Key-On, Engine Cranking
- Fault Condition: Difference between the desired CAM position and actual CAM position is greater than 6 CAD
- MIL: ON during active fault

Fault Description

The CAM position sensor is utilized to distinguish the cylinder event (compression or exhaust), thus making the cylinder identification available to the ECM. The camshaft position sensor is a 3-wire hall effect sensor. One wire for current feed (5v), one for ground, and one for the output signal (CAM 1). The sensor must have a good 5v reference and ground to operate properly. The cam sensor is located on the right front area of the engine behind the front timing cover.

The CAM position and CAM Position desired value is displayed on the “TESTS” page in the 4G display software under the “Distributor Alignment” section. This code will set when these two values are more than 6 CAD apart.

DTC 11 - Intake Cam Position Error

1. Preliminary Inspection:

- Visually inspect the camshaft position sensor and wiring for any obvious damage or disconnections.
- Ensure the sensor is properly seated in its position on the right front area of the engine behind the front timing cover.

2. Check the 4G Display Software:

- Engine Running while 4G Display software is connected.
- Navigate to the “TESTS” page and locate the “Distributor Alignment” section.
- Observe the CAM position and CAM Position desired values. Verify they are more than 6 Crank Angle Degrees (CAD) apart, which is a condition for setting DTC 11.

3. Voltage Reference and Ground Check:

- Disconnect the camshaft position sensor.
- Set a multimeter to measure DC voltage.
- Connect the multimeter's positive lead to Pin 1 (5V_ext) and negative lead to a good engine ground.
- Check for a 5V reference. If voltage is not present, trace the circuit back to the ECM Pin 19 for issues.

4. Signal Circuit Check:

- With the sensor still disconnected, set the multimeter to measure DC voltage.
- Connect the positive lead to Pin 2 (CAM +) and negative lead to Pin 3 (CAM -).
- Turn the engine over by hand or with a starter. Observe the voltage reading; it should fluctuate if the sensor is generating a signal. If not, the signal circuit might be faulty.

5. Sensor Ground Check:

- With the sensor disconnected, set the multimeter to the Ohms (resistance) setting.
- Connect one lead to Pin 3 (CAM -) on the sensor connector and the other to a good engine ground.
- Check for continuity. If there's no continuity, there might be an issue with the ground circuit.

6. Sensor Resistance Check:

- With the sensor disconnected, set the multimeter to the Ohms (resistance) setting.
- Measure the resistance across the sensor's output (Pin 2) and ground (Pin 3) terminals.
- Compare the reading to the manufacturer's specifications. A significant deviation indicates a faulty sensor.


7. ECM Check:

- Check the ECM's corresponding pins (Pin 27 for CAM + and Pin 28 for CAM -) for any signs of damage or poor connection.
- Ensure the ECM is properly grounded and functioning.

8. Final Steps:

- If any faults are found in the wiring or connections, repair as needed.
- If the sensor is found to be faulty, replace it.
- Once repairs or replacements are done, clear the DTC from the ECM memory.
- Start the engine and monitor to see if DTC 11 reappears.

DTC 16 - Never Crank Synced at Start



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Cranking or Running
- Fault Condition: Engine speed > 90 RPM, no sync for 4 revs
- MIL: ON during active fault

Fault Description

The crankshaft and camshaft position sensors are magnetic sensors installed in the block adjacent to "coded" trigger wheels that are used to determine crankshaft and camshaft position (with respect to TDC cylinder #1 compression) and the rotational engine speed. The ECM must see a valid crankshaft position and camshaft position signal properly aligned during cranking before it can synchronize the ignition system to initiate starting. If engine speed is greater than 90 RPM and the crank and/or cam cannot synchronize within 4 cranking revs this fault will set. Typically, conditions triggering this fault will result in an engine that will not start or run.

Diagnostic Aids

- Check that the crankshaft and/or camshaft position sensors are securely connected to harness
- Check that the crankshaft and/or camshaft position sensors are securely installed on the engine, and all brackets are tight
- Check crankshaft and/or camshaft position sensor circuits wiring for open circuits


DTC 16 - Never Crank Synced at Start

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Check that the ECM ground terminals C010, C022 and C023 are clean and tight Are the ground terminals clean and tight?		Go to Step (3)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
3	Key On, Engine OFF Disconnect the CKP (Crankshaft position) Sensor connector C015 Using A DVOM check for voltage at the CKP sensor connector pin 1 and engine ground (CHECK THIS BEFORE THE POWER RELAYSHUTS OFF) Do you have voltage?	5.0 volts	Go to Step (4)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
4	Key OFF Disconnect ECM connector C001 Using a DVOM check for continuity between CKP connector pin 2 and ECM connector pin 22 Do you have continuity between them?		Go to Step (5)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
5	Using a DVOM check for continuity between CKP connector pin 3 and ECM connector pin 21 Do you have continuity between them?		Go to Step (6)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
6	Inspect the CKP connector C015 terminals for damage, corrosion or contamination Did you find a problem?		Repair the circuit as necessary. Refer to Wiring Re- pairs in Engine Electrical.	Go to Step (7)

Step	Action	Value(s)	Yes	No
7	Inspect the ECM connector C001 terminals 19, 21 and 22 for damage, corrosion or contamination Did you find a problem?		Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (8)
8	Check that the ECM ground terminals C010, C022 and C023 are clean and tight Are the ground terminals clean and tight?		Go to Step (3)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
9	Replace CKP sensor Is the replacement complete?		Go to Step (10)	-
10	Replace ECM Is the replacement complete?		Go to Step (11)	-
11	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-16 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to Step (9)

Step	Action	Value(s)	Yes	No
12	<p>Remove all test equipment except the DST.</p> <p>Connect any disconnected components, fuses, etc.</p> <p>Using the DST clear DTC information from the ECM.</p> <p>Turn the ignition OFF and wait 30 seconds.</p> <p>Start the engine and operate the vehicle to full operating temperature</p> <p>Observe the MIL</p> <p>Observe engine performance and drivability</p> <p>After operating the engine within the test parameters of DTC-16 check for any stored codes.</p> <p>Does the engine operate normally with no stored codes?</p>		System OK	Go to OBD System Check

DTC 51 - EGOH2 Open / Ground Short



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Cranking or Running
- Fault Condition: Voltage feedback from the HEGO 2 sensor heater should always equal ground voltage.
- Condition: HEGO 2 low-side feedback < 5.0% Vbat
- MIL: ON during active fault

Fault Description


This fault will set when the HEGO heater control feedback signal does not see Vbat when the heater is switched off.

This may be caused by a bad heater element in the HEGO sensor, a break in the wire harness on the heater supply or control circuits, or fault within the ECM.

DTC 51 - EGOH2 Open / Ground Short

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine OFF Disconnect the harness from the HEGO sensor. With a DMM, measure the heater resistance within the sensor (C & D). Normal resistance is approximately 2.5 ohms.	Is the resistance >50 ohms?	Go to Step (3)	Go to Step (4)
3	HEGO heater element is bad Replace HEGO sensor			-
4	Disconnect the harness from the ECM With DMM, check for continuity in the harness on the heater control signal (Test between Pin D on the HEGO sensor connector and Pin 64 on the ECM connector).	Does continuity exist (is resistance <50 ohms?	Go to Step (5)	Go to Step (6)
5	Replace ECM			
6	Repair/Replace circuit in harness			

DTC 52 - EGOH2 Short to Power



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Cranking or Running
- Fault Condition: Voltage feedback from the UEGO sensor heater is always equal to the battery or supply voltage (short to Vbattery.)
- MIL: ON during active fault

Fault Description


A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. The sensor is heated with an internal resistive element that is supplied by the battery voltage and switched on/off by the ECM. The ECM will pull the heater control signal to ground when turning on the heater. The ECM monitors the heater control signal for a short to ground. If the control signal is not equal to Vbattery when the heater is turned off then the circuit is not functioning properly.

This fault will set when the UEGO heater control signal does not achieve zero volts when the heater is switched on. This may be caused by an internal fault within the ECM.

DTC 52 - EGOH2 Short to Power

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine OFF Disconnect the harness from the UEGO sensor. With a DMM, measure the heater resistance. (For the Bosch sensor, measure the resistance between the white and grey lines connected to pins 3 and 4.) Normal resistance is approximately 2.5 ohms.	Is the resistance <0.5 ohms?	Go to Step (3)	Go to Step (4)
3	UEGO heater element is bad Replace UEGO sensor			
4	Disconnect the harness from the ECM Check the heater control signal (Test between Pin 3 of the UEGO sensor and Pin 75 on the ECM) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to the positive battery terminal.	Is the circuit shorted?	Go to Step (5)	Go to Step (6)
5	Repair short to Vbattery in harness			
6	Replace ECM			

DTC 107 - MAP Low Voltage



Conditions for Setting the DTC

- Check Condition: Engine cranking or running
- Fault Condition: MAP voltage less than 0.050 with throttle position greater than 2.0% and engine RPM less than 7000.
- MIL: ON
- Engine Shutdown

Circuit Description

The Manifold Absolute Pressure sensor is a pressure transducer connected to the intake manifold. It is used to measure the pressure of air in the manifold prior to induction. The pressure reading is used in conjunction with other inputs to estimate the airflow rate to the engine, which determines the fuel flow rate. This fault will set if the MAP voltage is less than 0.050 with TPS greater than 2% and engine RPM is less than 7000. The fault will cause an engine shutdown.

If the ground signal is lost on this circuit, it is highly likely that other fault codes will appear due to improper grounding affecting other sensors or circuits tied to the same ground line. Specifically:


DTC 113 IAT high voltage (Intake Air Temperature Sensor):

As the diagram shows, the ground is shared with the IAT sensor. A loss of ground could trigger an IAT fault code, such as "IAT Circuit High" or "IAT Circuit Low," depending on how the circuit fails.

DTC 107 - MAP Low Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step 2	Go to OBD System Check Section
2	Check for the presence of DTC 113.	Is DTC 113 present?	Go to Step 3	Go to Step 4
3	Investigate potential ground loss related to DTC 113:	- Check for a loss of ground between the sensor terminal 1 and ECM ground.	Resolve DTC 113 and retest	Continue troubleshooting
4	Key ON, Engine Running. Does DST display MAP voltage less than the limit defined in calibration with the engine idling?	Less than 0.050v	Go to Step 7	Intermittent Problem.
7	If DTC 642 or 643 are present, troubleshoot those first.	Using a DMM, measure the voltage potential across ref1 and 5V rtn1 at connector.	Does DMM indicate a voltage >4.7 VDC?	Go to Step 8
8	Jumper the MAP circuit to Vref (5 VDC) in the connector on the harness.	Does DST display MAP voltage of 4.7 VDC or greater?	Go to Step 9	Go to Step 10
9	Inspect for a poor connection at the sensor.	Is there a poor connection?	Repair the connection, retest	Go to Step 10
10	Key off. Disconnect wire harness header from ECM.	CAREFULLY remove yellow lock from header at the device output terminal. CAREFULLY check resistance between MAP input at ECM header and signal at the device. DO NOT INSERT probes or objects into terminals as this can damage terminals.	Is the resistance <5 ohms?	Go to Step 11
11	Reconnect header to ECM. Key on, Engine off. Probe MAP signal circuit with a test light connected to battery voltage.	Does DST display MAP voltage of 4.0 VDC or greater?	Go to Step 13	Go to Step 14
13	Inspect for faulty ECM connection.	-	Faulty ECM (analog input circuit).	
14	MAP signal shorted to ground.	-	Faulty ECM connection. Faulty ECM (analog input circuit).	

DTC 108 - MAP High Pressure



Conditions for Setting the DTC

- Check condition: engine running
- Fault Condition: MAP greater than 35 psi with TPS less than 10% and engine rpm greater than 1400.
- MIL: ON
- Engine Shutdown


Circuit Description

The MAP (Manifold Absolute Pressure) is measured by the MAP sensor. The MAP pressure value is used for fuel, airflow and spark calculations. This fault will set in the event the MAP value is greater than 35 psia when the TPS is less than 10% with engine rpm greater than 1400.

DTC 108 - MAP High Pressure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine On System Mode = "Running" If engine idle is rough, unstable, missing or incorrect due to suspected engine mechanical problem or vacuum leak etc. Correct the condition before continuing this diagnostic chart.	Does DST display MAP greater than that defined in in the diagnostic calibration?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect MAP sensor from engine harness Key ON, Engine Off System Mode = "Stopped"	Does DST display MAP voltage <0.100 VDC?	Go to Step (5)	
4	Intermittent Problem			
5	Probe sensor ground circuit with test light connected to battery voltage	Does test light come on?	Go to Step (6)	Go to Step (7)
6	Faulty MAP sensor or pressure connection to intake Faulty MAP sensor Faulty ECM connection			
7	Open sensor ground circuit Faulty ECM			

DTC 111 - IAT Higher Than Expected Stage 1



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Intake Air Temperature greater than 140 degrees F
- Condition must be present for a minimum of 30 seconds
- MIL: ON
- Adaptive: Disabled during active fault

Circuit Description


The TMAP is a combined IAT (Intake Air Temperature) and MAP (Manifold Absolute Pressure) sensor. A temperature sensitive resistor is used in the TMAP located in the air intake manifold of the engine. It is used to monitor incoming air temperature, and the output in conjunction with other sensors is used to determine the airflow to the engine. The ECM provides a voltage divider circuit so that when the air is cool, the signal reads higher voltage, and lower when warm. This fault will set if the Intake Air Temperature is greater than 140 degrees F.

Diagnostic Aid

This fault will set when inlet air is much hotter than normal. The most common cause of high inlet air temperature is a problem with the air inlet system or valve lash, which causes a burn back or backfire.

- Ensure that the air inlet is not obstructed, modified, or damaged.
- Ensure the intake air is being sourced from a cool location. Engine heat recirculating into the intake can cause elevated intake air temperatures.
- Inspect the air inlet system for cracks or breaks that may allow unwanted hot air into the air inlet system.
- If none of the above can be found, follow the diagnostic steps for DTC 112-IAT Low Voltage.
- Refer to the 40L Owner's manual or service manual to adjust the valve lash accordingly.

DTC 112 - IAT Low Voltage



Conditions for Setting the DTC

- Check Condition: Engine Cranking or Running
- Fault Condition: IAT Sensor Voltage less than 0.050
- MIL: ON during active fault
- Engine Shutdown


Circuit Description

The TMAP is a combined IAT (Intake Air Temperature) and MAP (Manifold Absolute Pressure) sensor. A temperature sensitive resistor is used in the TMAP is located in the engine's air intake or intake manifold. It is used to monitor incoming air temperature, and the output in conjunction with other sensors is used to determine the airflow to the engine. The ECM provides a voltage divider circuit so that when the air is cool the signal reads higher voltage, and lower when warm. This fault will set if the signal voltage is less than 0.050 volts for 1 second anytime the engine is cranking or running. The engine will not start if this fault is active, and this fault will cause a shutdown if it becomes active during engine operation.

DTC 112 - IAT Low Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine On System Mode = "Running"	Does DST display IAT a voltage less the limit defined in calibration?	Go to Step (3)	Go to Step (4)
3	Intermittent Problem			
4	Key Off Disconnect IAT sensor from harness Key ON, Engine Off System Mode = "Stopped"	Does DST display IAT voltage of 4.9 VDC or greater?	Go to Step (5)	Go to Step (6)
5	Faulty IAT sensor			
6	Sensor signal circuit shorted to ground, check wire harness for ground short Faulty ECM			

DTC 113 - IAT High Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: IAT Sensor Voltage greater than 4.950 volts
- MIL: ON during active fault
- Engine Shutdown

Circuit Description

The TMAP is a combined IAT (Intake Air Temperature) and MAP (Manifold Absolute Pressure) sensor. A temperature sensitive resistor is used in the TMAP is located in the engine's air intake or intake manifold. It is used to monitor incoming air temperature, and the output in conjunction with other sensors is used to determine the airflow to the engine. The ECM provides a voltage divider circuit so that when the air is cool, the signal reads higher voltage, and lower when warm. This fault will set if the signal voltage is greater than 4.950 volts for 1 second or longer. The ECM will use a default value for the IAT sensor in the event of this fault.

If the ground signal is lost on this circuit, it is highly likely that other fault codes will appear due to improper grounding affecting other sensors or circuits tied to the same ground line. Specifically:


DTC 107 (MAP Low Voltage):

As the diagram shows, the ground is shared with the MAP sensor. A loss of ground could trigger an MAP fault code depending on how the circuit fails.

DTC 113 - IAT High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped"	Does DST display IAT a voltage greater than the limit set in calibration?	Go to Step (3)	Go to Step (4)
3	Disconnect IAT sensor from harness Jumper across terminal at connector	Does DST display IAT voltage of 0.1 or less?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Faulty connection to sensor Faulty IAT sensor			
6	Jumper IAT sensor signal to ground	Does DST display IAT voltage of 0.1 or less?	Go to Step (7)	Go to Step (8)
7	Open IAT ground (5Vrtn1) circuit Faulty connection to sensor Faulty IAT sensor			
8	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between MAP input at ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer contact with ECM pin. Spread pins will void warranty! Probe on the side of terminal.	Is the resistance <5 ohms?	Go to Step (9)	Go to Step (10)
9	Faulty ECM connection Faulty ECM			
10	Faulty Harness			

DTC 116 - ECT Higher Than Expected 1



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Engine Coolant Temperature reading greater than 220 degrees F. for 15 seconds
- MIL: On
- Adaptive: Disabled during active fault


Circuit Description

The ECT (Engine Coolant Temperature) sensor is a temperature sensitive resistor located in the engine coolant sensor that is located in the coolant passage. The ECT is used for engine airflow calculation, fuel enrichment, and ignition timing control and to enable certain other temperature dependent operations. This code set is designed to help prevent engine damage from overheating. The ECM provides a voltage divider circuit so when the sensor reading is cool the sensor reads higher voltage, and lower when warm. This fault will set when the coolant exceeds 220 degrees F for more than 15 seconds.

DTC 116 - ECT Higher Than Expected 1

Step	Action	Value(s)	Yes
1	Did you perform the On-Board (OBD) System Check?	–	Go to Step (2)
2	Key ON DST (Diagnostic Scan Tool) connected in system data mode Warm engine to normal operating temperature, then run the engine above 1200 rpm for at least 60 seconds Does the DST display ECT temperature of 220 degrees F or greater?		Go to Step (3)
3	Verify with a temperature gauge that the engine coolant is over 220 degrees F. Does the temperature gauge indicate 220 degrees F. or greater?		Repair cooling system.
4	Verify ECT Circuit function. Follow diagnostic test procedure for DTC 217 (ECT Higher than expected 2)		-

DTC 117 - ECT/CHT Low Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: ECT sensor voltage less than 0.050
- MIL: ON during active fault
- Adaptive: Disabled during active fault

Circuit Description


The ECT (Engine Coolant Temperature) sensor is a temperature sensitive resistor located in the engine coolant passage. It is used for the engine airflow calculation, cold fuel enrichment and to enable other temperature dependent features. The ECM provides a voltage divider circuit so that when the coolant is cool, the signal reads higher voltage, and lower when warm (see table). This fault will set if the signal voltage is less than 0.050 volts for any period longer than 1 second. The ECM will use a default value for the ECT sensor in the event of this fault.

Temp (deg F)	Ohms +/-10%
242.4	101
231.9	121
211.6	175
201.4	209
181.9	302
163.1	434
144.9	625
127.4	901
102.4	1,556
78.9	2,689
49.9	5,576
23.5	11,562
-5.7	28,770
-21.2	49,715
-30.8	71,589
-40.0	99,301

DTC 117 - ECT/CHT Low Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DST display an ECT voltage less the limit defined in calibration?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect ECT sensor from harness Key ON, Engine Off System Mode = "Stopped"	Does DST display ECT voltage of 4.9 VDC or greater?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Faulty ECT sensor			
6	Sensor signal circuit shorted to ground, check wire harness for ground short Faulty ECM			

DTC 118 - ECT/CHT High Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: ECT sensor voltage exceeds 4.950 volts
- MIL: ON during active fault
- Adaptive: Disabled

Circuit Description


The ECT (Engine Coolant Temperature) sensor is a temperature sensitive resistor located in the engine coolant passage. It is used for the engine airflow calculation, cold fuel enrichment and to enable other temperature dependent features. The ECM provides a voltage divider circuit so that when the coolant is cool, the signal reads higher voltage, and lower when warm (see table). This fault will set if the signal voltage is greater than 4.950 volts anytime the engine is running. The ECM will use a default value for the ECT sensor in the event of this fault.

Temp (deg F)	Ohms +/-10%
242.4	101
231.9	121
211.6	175
201.4	209
181.9	302
163.1	434
144.9	625
127.4	901
102.4	1,556
78.9	2,689
49.9	5,576
23.5	11,562
-5.7	28,770
-21.2	49,715
-30.8	71,589
-40.0	99,301

DTC 118 - ECT/CHT High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped"	Does DST display ECT voltage greater than limit set in calibration?	Go to Step (3)	Go to Step (4)
3	Disconnect ECT sensor from harness Jumper across terminals at connector	Does DST display ECT voltage of 0.1 or less?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Open ECT ground (5Vrtn1) circuit Faulty connection to sensor Faulty ECT sensor			
6	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between MAP input at ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer contact with ECM pin. Spread pins will void warranty! Probe on the side of terminal.	Is the resistance <5 ohms?	Go to Step (7)	Go to Step (8)
7	Faulty ECM connection Faulty ECM			
8	Faulty Harness			

DTC 121 - TPS 1 Lower Than TPS 2



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: TPS 1 20% lower than TPS 2
- MIL: ON for remainder of key on cycle
- Engine shutdown


Circuit description

Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS 1 will read low voltage when closed and TPS 2 will read high voltage when closed. The TPS 1 and TPS 2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. This fault will set if TPS 1 is 20% (or more) lower than TPS 2. At this point the throttle is considered to be out of specification, or there is a problem with the TPS signal circuit. The MIL command is ON, and the engine will shut down.

DTC 121 - TPS 1 Lower Than TPS 2

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped" Enable "DBW Test" mode Slowly depress FPP sensor NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box.	Is TPS1 and TPS2 difference in calibration?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect throttle from harness Key ON, Engine Off System Mode = "Stopped" Enable "DBW Test" mode	Is the voltage for both TPS1 and TPS2 <0.100 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Connect TPS1 signal to the 5V reference at throttle connector while observing TPS1 voltage. Repeat for TPS2	Does DST display both TPS1 and TPS2 voltage over 4.90 VDC when each is connected to 5Vref?	Go to Step (6)	Go to Step (7)
6	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between MAP input at ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer contact with ECM pin. Spread pins will void warranty! Probe on the side of terminal.	Are both resistances <5 ohms?	Go to Step (8)	Go to Step (9)
7	TPS1 or TPS2 signal shorted to ground in harness Faulty ECM connection Faulty ECM			
8	Faulty harness			

DTC 122 - TPS 1 Low Voltage



Conditions for Setting the DTC

- Check Condition: Cranking or Running
- Fault Condition: TPS sensor less than 0.200 volts
- MIL: ON during active fault
- Engine shutdown


Circuit Description

Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS1 will read lower voltage when closed and TPS2 will read higher voltage when closed. The TPS1 and TPS2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. The TPS is not serviceable and in the event of a failure the electronic throttle assembly must be replaced. This fault will set if the TPS 1 voltage is less than 0.200 volts. The MIL command is ON and the engine will shut down.

DTC 122 - TPS 1 Signal Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step 2	Go to OBD System Check Section
2	Key ON, Engine Off. System Mode = "Stopped". Enable "DBW Test" mode.	TPS1 voltage low (< 1.00 VDC) at 0% TPS by design	Go to Step 3	Go to Step 4
3	Key ON, Engine Off. System Mode = "Stopped". With the throttle closed, check if DST displays a TPS1 fault condition.	TPS1 voltage < 0.200 VDC	Go to Step 5	Go to Step 7
4	Slowly sweep throttle position while observing TPS1 voltage. System Mode = "Stopped".	TPS1 voltage < 0.200 VDC	Go to Step 5	Go to Step 6
5	Key Off. Disconnect throttle from harness. Jumper 5Vref1 to TPS1 signal circuit at throttle connector. Key ON, Engine Off. System Mode = "Stopped".	TPS1 voltage > 4.0 VDC	Go to Step 9	Go to Step 10
6	Slowly sweep throttle position while observing TPS1 voltage. System Mode = "Stopped".	TPS1 voltage ever falls below 0.200 VDC	Go to Step 7	Intermittent problem.
7	Slowly sweep throttle position while observing TPS1 voltage. System Mode = "Stopped".	TPS1 voltage ever falls below 0.200 VDC	Go to Step 5	Go to Step 8
8	Investigate intermittent problem.	-		
9	Inspect for a poor throttle connection.	Poor connection found	Repair the connection, retest	Go to Step 10
10	Key Off. Disconnect wire harness header from ECM. CAREFULLY remove yellow lock from header at the device output terminal. CAREFULLY check resistance between TPS1 input at ECM header and signal at the device. DO NOT INSERT probes or objects into terminals , as this can damage terminals. Probe from the side.	Both resistances < 5 ohms	Go to Step 11	Faulty harness.
11	Inspect for potential TPS1 signal shorted to ground in the harness.	-	Faulty ECM connection or TPS.	
12	Inspect for faulty ECM or TPS (Throttle Position Sensor).	-	Faulty throttle or harness.	

DTC 123 - TPS 1 High Voltage



Conditions for Setting the DTC

- Check Condition: Cranking or Running
- Fault Condition: TPS sensor voltage exceeds 4.800 volts
- MIL: ON during active fault
- Engine shutdown

Circuit Description


Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS1 will read lower voltage when closed and TPS2 will read higher voltage when closed. The TPS1 and TPS2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. The TPS is not serviceable and in the event of a failure the electronic throttle assembly must be replaced. This fault will set if the TPS 1 voltage exceeds 4.800 volts. The MIL command is ON and the engine will shut down.

DTC 123 - TPS 1 High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped" Enable "DBW Test" mode	Is TPS1 voltage low (< 1.00 VDC) at 0% TPS by design?	Go to Step (3)	Go to Step (4)
3	-	With the <u>throttle</u> closed, does DST display TPS1 voltage > fault condition defined in the calibration?	Go to Step (5)	Go to Step (7)
4	Slowly depress FP while observing TPS1 voltage NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	With the <u>throttle</u> closed, does DST display TPS1 voltage > fault condition defined in the calibration?	Go to Step (5)	Go to Step (6)
5	Key Off Disconnect throttle from harness. Key On, Engine Off System Mode=" Stopped"	Does DST display TPS1 voltage < 0.20 VDC?	Go to Step (9)	Go to Step (10)
6	Slowly depress FPP sensor while observing TPS1 voltage NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	Does TPS1 voltage ever exceed the fault condition defined in the calibration?		Go to Step (7)
7	Slowly depress FP while observing TPS1 voltage NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	Does TPS1 voltage ever exceed the fault condition defined in the calibration?	Go to Step (5)	

Step	Action	Value(s)	Yes	No
8	Intermittent problem			
9	TPS1 signal shorted to power Faulty ECM			
10	Probe TPS1 sensor ground circuit at connector with test light connected to battery voltage	Does test light illuminate?	Go to Step (11)	Go to Step (12)
11	Faulty Throttle connection Faulty Throttle			
12	Open sensor ground Faulty ECM			

DTC 127 - IAT Higher Than Expected 2



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Intake Air Temperature greater than 155 degrees F. with engine speed greater than 600 rpm
- Fault condition must be active for longer than 5 seconds
- MIL: ON for active fault
- Engine Shut Down


Circuit Description

The TMAP is a combined IAT (Intake Air Temperature) and MAP (Manifold Absolute Pressure) sensor. A temperature sensitive resistor is used in the TMAP located in the intake manifold of the engine. It is used to monitor incoming air temperature, and the output in conjunction with other sensors is used to determine the airflow to the engine. The ECM provides a voltage divider circuit so that when the air is cool, the signal reads a higher voltage, and lower when warm. This fault will set if the intake air temperature is greater than 155 degrees F. with engine speed greater than 600 rpm. The MIL light command is on during this active fault and the engine will shut down.

Diagnostic Aid

- This fault will set when inlet air is much hotter than normal. The most common cause of high inlet air temperature is a problem with the air inlet system. Ensure that the air inlet is not obstructed, modified or damaged, and that hot air from the engine, exhaust, or radiator is not recirculating into the air inlets.
- Another common cause is valve lash. Refer to the 40L Owner's manual or service manual to adjust the valve lash accordingly.
- Inspect the air inlet system for cracks or breaks that may allow heated air into the air inlet system.
- If none of the above can be found, follow the diagnostic steps for DTC 112-IAT Low Voltage.

DTC 129 - BP Low Pressure



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: BP less than 8.30 psia
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description


The BP (Barometric Pressure) is estimated from the TMAP sensor. The barometric pressure value is used for fuel and airflow calculations. This fault sets in the event the BP value is out of the normal range.

DTC 129 - BP Low Pressure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped"	Does DST display BP less than defined in the diagnostic calibration?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect MAP sensor from harness Jumper the MAP circuit to 5Vref1 (5 VDC) in connector on harness Key On, Engine Off System Mode="Stopped"	Does DST display BP> 14 0 psia?	Go to Step (5)	Go to Step (6)
4	Intermittent problem			
5	Poor connection at sensor Faulty MAP sensor			
6	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between MAP input at ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer contact with ECM pin. Spread pins will void warranty! Probe on the side of terminal.	Is the resistance <5 ohms?	Go to Step (7)	Go to Step (8)
7	Reconnect header to ECM Key On, Engine Off System Mode="Stopped" Probe MAP signal circuit with a test light connected to battery voltage	Does DST display BP> 14 0 psia?	Go to Step (9)	Go to Step (10)
8	Faulty Harness			

Step	Action	Value(s)	Yes	No
9	5 Volt reference is open or shorted to ground Faulty ECM connection Faulty ECM			
10	BP/MAP signal circuit shorted to ground Faulty ECM connection Faulty ECM			

DTC 148 - Fuel Run-out Longer Than Expected



Conditions for Setting the DTC

- Check Condition: Key OFF
- Fault Condition: Engine run down time greater than 10 seconds
- MIL-ON

Circuit Description

The fuel shut off valves are supplied system battery power from the VSW fused source. The ECM then provides a path to ground to turn the valve on. This fault will set in the event the engine continues to run for more than 10 seconds after the key is turned off. This fault indicates a possible problem with the electric fuel shut-off valve, or a wiring issue.


DTC 148 - Fuel Run-out Longer Than Expected

Note: Ensure to check voltage and ground separately.

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) Sys- Check?	-	Go to Step (2)	
2	Disconnect the natural gas lockoff solenoid connector. Using a DVOM check for power across terminals A and B while cranking the engine, then turn the key to the OFF position Did the voltage immediately turn OFF with the	System Voltage	Go to Step (3)	Go to Step (5)
3	Turn off the natural gas manual valve. Start the engine and let it idle until the engine stops. (THIS MAY TAKE SEVERAL MINUTES) Did the engine ever stop?		Intermittent problem. See intermittent problems in the electrical section of this manual.	Go to Step (4)
4	Replace the natural gas lockoff solenoid. Is the replacement complete?		Go to Step (8)	-
5	Key OFF Disconnect the ECM wire harness header connector Using a DVOM check for continuity between header connector pin 33 and engine ground Do you have continuity?		Repair the natural gas solenoid control short to ground	Go to Step (6)
6	Inspect the ECM wire harness and connector for damage corrosion or contamination. Did you find a problem?		Correct the problem as required. See wire harness repair.	Go to Step (7)
7	Replace the ECM Is the replacement complete?		Go to Step (8)	

Step	Action	Value(s)	Yes	No
8	<p>Remove all test equipment except the DST.</p> <p>Connect any disconnected components, fuses, etc.</p> <p>Using the DST clear DTC information from the ECM.</p> <p>Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature</p> <p>Observe the MIL</p> <p>Observe engine performance and drivability After operating the engine within the test parameters of DTC-359 check for any stored codes.</p> <p>Does the engine operate normally with no stored codes?</p>		System OK	Go to OBD System Check

DTC 154 - EGO2 Open/Lazy



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Running
- Fault Condition: EGO cold persistently for greater than 120 seconds
- MIL: ON during active fault

Fault Description

In a post-catalyst configuration, the HEGO/H2OS sensor is a switching-type sensor around stoichiometry that measures the oxygen content downstream of the catalyst for two main functions: 1) to compare it to the oxygen content upstream of the catalyst to determine how efficiently the catalyst is using oxygen to determine its effectiveness and 2) trim the commanded equivalence ratio target to maximize the catalyst conversion efficiency.


This fault will set if the sensor element is cold, non-responsive, or inactive for 120 seconds. Cold, nonresponsive, or inactive are determined based on two criteria: 1) a measurement of the feedback sense element (zirconia) to determine its temperature or 2) a lack of change in sensor feedback.

DTC 154 - EGO2 Open/Lazy

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) Sys- Check?	-	Go to Step (2)	
2	Key ON, Engine Running Run Mode = "Running" Fuel Control Module="CL Active" or "CL+Adapt" Warm engine to normal operating temperature (ECM must have been powered for > 5 minutes) Ensure that Closed-Loop is active (CL Active or CL+Adapt)	Is HO2S voltage fixed between 0.4 and 0.6 volts?	Go to Step (3)	Go to Step (4)
3	Using a DMM, check continuity from ECM header to HO2S signal at sensor connector Check continuity from HO2S signal return at sensor connector to Analog Return at the ECM header	Is the resistance < 5 ohms?	Go to Step (6)	Go to Step (5)
4	Using a DMM, check continuity from ECM header to H)2S heater low side circuit Check continuity from HO2S heater high side to power relay	Is the resistance < 5 ohms?	Go to Step (6)	Go to Step (7)
5	Repair wiring harness and retest			
6	Using a DST check the HEGO impedance feedback versus target	Is impedance within +/- 50 ohms of target?	Go to Step (8)	Go to Step (9)
7	Repair wiring harness and retest			
8	Replace HO2S Sensor and retest	Is HO2S properly functioning?	Go to Step (12)	Go to Step (11)

Step	Action	Value(s)	Yes	No
9	With the HO2S sensor connected to the wire harness measure the heater control duty-cycle across heater + and – at sensor Alternately, with the HO2S sensor connected to the wire harness measure the heater control voltage across heater + and – at sensor	Does measured DC or voltage = commanded DC or voltage displayed in DST?	Go to Step (10)	Go to Step (11)
10	HO2S Heater is not functional or sensor element is cracked Replace HO2S Sensor			
11	Replace ECM		Go to Step (10)	
12	HO2S sensor was faulty			

DTC 186 - (3468:1) - FT Gaseous Fuel Extremely Low



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Running
- Fuel temp < -40 Deg F
- MIL: ON during active fault


Fault Description

The Fuel Temperature sensor is a thermistor (temperature sensitive resistor) integrated into the EPR fuel outlet OR MFG. It is used to monitor the gaseous fuel temperature exiting the EPR/MFG to be used as an input in a fuel temperature estimation of the temperature entering the gaseous mixer.

This information is used to calculate a real-time fuel pressure correction in order to reduce fueling errors. The DPR or MFG sends the fuel temperature information to the ECM via the CAN J1939 communication circuit between the EPR/MFG and ECM.

This fault is not user modifiable. It is always enabled and is intended to protect the CFV from extremely low fuel temperatures by load limiting the system when the FT falls below the target temperature given in the fault conditions.

DTC 187 - Fuel Temperature Gaseous Low



Conditions for Setting the DTC

- Key on, Engine on
- Fault Conditions: FT voltage less than normal operating voltage or fuel temperature less than normal operating temperature.


Fault Description

The Fuel Temperature sensor is a thermistor (temperature sensitive resistor) integrated into the EPR fuel outlet. It is used to monitor the gaseous fuel temperature exiting the EPR to be used as an input in a fuel temperature estimation of the temperature entering the gaseous mixer. This information is used to calculate a real time fuel pressure correction in order to reduce fueling errors. The ECM provides a voltage divider circuit so that when the fuel is cool, the signal reads higher voltage, and lower when warm.

DTC 187 - Fuel Temperature Gaseous Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DST display FT a voltage less than the limit defined in calibration?	Go to Step (3)	Go to Step (4)
3	Key OFF Key On, Engine Off System Mode = "Stopped" Wait for fuel pump to stop running Disconnect FT sensor from harness	Does DST display FT voltage of 0.1 or less?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem Condition is operating condition dependent			
5	Faulty FT sensor			
6	Sensor signal circuit shorted to ground, check wire harness for ground short Faulty ECM			

DTC 188 - (520240:3) - FT Gaseous Fuel High



Conditions for Setting the DTC

- Check Condition: Key-On, Engine Running
- Fault Conditions: FT voltage greater than 4.95v or fuel temp is greater than 250F.
- MIL: ON during active fault

Fault Description

The Fuel Temperature sensor is a thermistor (temperature sensitive resistor) integrated into the EPR fuel outlet OR MFG. It is used to monitor the gaseous fuel temperature exiting the EPR/MFG to be used as an input in a fuel temperature estimation of the temperature entering the gaseous mixer.


This information is used to calculate a real-time fuel pressure correction in order to reduce fueling errors. The DPR or MFG sends the fuel temperature information to the ECM via the CAN J1939 communication circuit between the EPR/MFG and ECM

This fault code is set when the ECM receives data indicating that the voltage associated with the gaseous fuel temperature sensor is greater than 4.95 volts or when the fuel temperature itself exceeds 250 degrees Fahrenheit. The ECM is programmed to interpret these conditions as potential issues with the gaseous fuel system, and it generates a fault code accordingly.

DTC 188 - (520240:3) - FT Gaseous Fuel High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF System Mode = "Stopped" In 4G Display FAULTS Page, monitor Fuel Temperature. Is the temperature greater than the diagnostic threshold?	>250F	Go to Step (3)	Go to Step (4)
3	Measure your fuel temp with an infrared gun or temperature probe, Is the fuel temp greater than 250F?	>250F	Determine cause of high fuel temp and resolve	Replace MFG or EPR
4	Start engine and monitor fuel temp as engine is running. Is the fuel temp greater than 250F?	>250F	Determine cause of high fuel temp and resolve	

DTC 217 - ECT Higher Than Expected 2



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Engine Coolant Temperature reading or estimate greater than 230 degrees F. for greater than 10 seconds
- MIL: On
- Engine shutdown will occur


Circuit Description

The ECT (Engine Coolant Temperature) sensor is a temperature sensitive resistor located in the engine coolant sensor that is located in the coolant passage. The ECT is used for engine airflow calculation, fuel enrichment, and ignition timing control and to enable certain other temperature dependent operations. This code set is designed to help prevent engine damage from overheating. The ECM provides a voltage divider circuit so when the sensor reading is cool the sensor reads higher voltage, and lower when warm. This fault will set when the coolant exceeds 230 degrees F. for more than 10 seconds. Engine shutdown will occur if this code occurs.

This is not an electronic fault; the engine is running too hot. The cooling system should be thoroughly inspected to find the root cause of the overheating.

- Is the cooling system full?
- Is the coolant in the cooling system the proper type, and is it the proper 50/50 mix of coolant and water?
- Are the fan belts intact and tight?
- Is the radiator clean? Debris on the radiator core and impede airflow through the radiator and cause the engine to overheat. Bear in mind that most engines are equipped with pusher fans, so the side of the radiator core closest to the engine will be the one to get coated with debris. Fan guards may need to be removed in order to inspect and properly clean the radiator core.
- Is hot air recirculating around the radiator, or is hot exhaust being drawn into the airflow through the radiator?

DTC 219 - RPM Higher Than Max Allowed Governed Speed



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: RPM > 2350rpm
- MIL: On
- Adaptive learn disabled
- Power Derate 1: ON

Circuit Description

The Max Allowed Governed Speed overrides any higher max governor speeds programmed by the user. This fault is designed to help prevent engine or equipment damage.

This fault will set anytime the engine RPM exceeds the limit set in the diagnostic calibration for the latch time or more.

Diagnostic Aid:

If any other DTCs are present, diagnose those first.


- Record a plot file in 4G display using the PSI HD Plot Template.

If you do not have access to the template tag the variables below and record them in 4G Display (MAIN Page).

- **Engine Speed, Max Governor Setpoint, Current Governor Target, Active Governor Type**
- Check mechanical operation of the throttle
- Check the engine intake for large air leaks downstream of the throttle body

System Variables		
Engine Speed	0	rpm
Min Governor Setpoint	0	rpm
Max Governor Setpoint	0	rpm
Current governor target	0	rpm
Pulse width	0.00	ms
Bank 1/2 Pre-cat EGO	0.000	0.000 volts
Bank 1/2 Post-cat EGO	0.000	0.000 volts
System State		
Run Mode	Stopped	
Power Mode	Sleep	
Fuel Type	Gasoline	
Fuel Supply	Off	
Fuel/Spark inhibit input	Inactive / Normal	
Fuel Control Mode	Open Loop	
Governor switch state	None	
Oil pressure state	OK	
Active governor type	None	
Active governor mode	Disabled	

DTC 221 - TPS 1 Higher Than TPS 2



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: TPS 1 20% higher than TPS2
- MIL: ON for remainder of key on cycle
- Engine shutdown

Circuit Description


Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS 1 will read lower voltage when closed and TPS 2 will read higher voltage when closed. The TPS 1 and TPS 2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. The TPS is not serviceable and in the event of a failure the electronic throttle assembly must be replaced. This fault will set if TPS 1 is 20% (or more) higher than TPS 2. At this point the throttle is considered to be out of specification, or there is a problem with the TPS signal circuit. The MIL command is ON and the engine will shut down.

DTC 221 - TPS 1 Higher Than TPS 2

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF System Mode = "Stopped" Enable "DBW Test" mode Slowly Depress FPP sensor NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	Is TPS1 and TPS2 difference more than the fault condition defined in the calibration?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect throttle from harness Key On, Engine Off System Mode – "Stopped" Enable "DBW Test" mode	Is the voltage for both TPS1 and TPS2 < 0.100 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent problem.			
5	Connect TPS1 signal to the 5V reference at throttle connector while observing TPS1 voltage Repeat for TPS2	Does DST display both TPS1 and TPS2 voltage over 4.90 VDC when each is connected to 5Vref?	Go to Step (7)	Go to Step (8)
6	TPS (the one over 0.1 volts) is shorted to voltage in the harness Faulty ECM			
7	Faulty connection at throttle Faulty throttle			

Step	Action	Value(s)	Yes	No
8	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between TPS1 and TPS2 input ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer make contact with ECM pins. Spread pins will void warranty! Probe on the side of terminal.	Are both resistances <5 ohms?	Go to Step (9)	Go to Step (10)
9	TPS1 and TPS2 signal shorted to ground in harness Faulty ECM connection Faulty ECM			
10	Faulty Harness			

DTC 222 - TPS 2 Signal Voltage Low



Conditions for Setting the DTC

- Check Condition: Cranking or Running
- Fault Condition: TPS 2 sensor voltage less than 0.200 volts
- MIL: ON during active fault

Circuit Description


Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS1 will read lower voltage when closed and TPS2 will read higher voltage when closed. The TPS1 and TPS2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. The TPS is not serviceable and in the event of a failure the electronic throttle assembly must be replaced. This fault will set if the TPS 2 voltage is less than 0.200 volts. The MIL command is ON.

DTC 222 - TPS 2 Signal Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF System Mode = "Stopped" Enable "DBW Test" mode	Is TPS2 voltage low (< 1.00 VDC) at 0% TPS by design?	Go to Step (3)	Go to Step (4)
3	-	Does DST display TPS2 voltage <0.2 VDC with the throttle closed?	Go to Step (5)	Go to Step (6)
4	Slowly Depress FP while observing TPS2 voltage NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	Does DST display TPS2 voltage <0.2 VDC with the throttle open?	Go to Step (5)	Go to Step (7)
5	Key OFF Disconnect throttle from harness		Go to Step (8)	
6	Slowly release FPP sensor while observing TPS2 voltage. NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box.	Does TPS2 voltage ever fall below 0.2 volts?	Go to Step (5)	Go to Step (7)
7	Intermittent Problem			
8	Jumper 5Vref1 to TPS2 signal circuit at throttle connector Key On, Engine Off System Mode="Stopped"	Does DST display TPS2 voltage >4.0 VDC?	Go to Step (9)	Go to Step (10)
9	Poor Throttle Connection Faulty Throttle			

Step	Action	Value(s)	Yes	No
10	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between TPS2 input at ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer make contact with ECM pins. Spread pins will void warranty! Probe on the side of terminal.	Are both resistances < 5 ohms?	Go to Step (11)	Go to Step (12)
11	TPS2 signal shorted to ground in harness Faulty ECM connection Faulty ECM Faulty Throttle (TPS)			
12	Faulty Harness			

DTC 223 - TPS 2 Signal Voltage High



Conditions for Setting the DTC

- Check Condition: Cranking or Running
- Fault Condition: TPS 2 sensor exceeds 4.800 volts
- MIL: ON during active fault

Circuit Description

Dual throttle position sensors are used within the throttle that uses variable resistors to determine signal voltage based on throttle plate position. TPS1 will read lower voltage when closed and TPS2 will read higher voltage when closed. The TPS1 and TPS2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. The TPS is not serviceable and in the event of a failure the electronic throttle assembly must be replaced. This fault will set if the TPS 2 voltage is greater than 4.800 volts. The MIL command is ON.

DTC 223 - TPS 2 Signal Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF System Mode = "Stopped" Enable "DBW Test" mode	Is TPS2 voltage low (< 1.00 VDC) at 0% TPS by design?	Go to Step (3)	Go to Step (4)
3	-	Does DST display TPS2 voltage >4.80 VDC with the throttle closed?	Go to Step (5)	Go to Step (13)
4	Slowly Depress FP while observing TPS2 voltage NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	Does DST display TPS2 voltage >4.80 VDC with the throttle open?	Go to Step (5)	Go to Step (7)
5	Key OFF Disconnect throttle from harness Key On, Engine Off System Mode = "Stopped"	Does DST display TPS2 voltage <0.20 VDC?	Go to Step (9)	Go to Step (10)
6	Slowly release FPP sensor while observing TPS2 voltage. NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box.	Does TPS2 voltage ever fall below 0.2 volts?		
7	Slowly release FPP sensor while observing TPS2 voltage. NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box.	Does DST voltage ever exceed 4.80 VDC	Go to Step (5)	Go to Step (8)
8	Intermittent Problem			

Step	Action	Value(s)	Yes	No
9	TPS2 signal shorted to power Faulty ECM			
10	Probe TPS2 sensor ground circuit at connector with test light connected to battery voltage.	Does test light illuminate?	Go to Step (11)	Go to Step (12)
11	Faulty throttle connection Faulty Throttle			
12	Open sensor ground Faulty ECM			
13	Slowly Depress FP while observing TPS2 voltage NOTE: To sweep throttle on stationary applications, go to DBW page and type desired throttle opening % in the TPS Command box	Does DST voltage ever exceed 4.80 VDC	Go to Step (8)	Go to Step (5)

DTC 234 – Boost Control Overboost Failure

Conditions for Setting DTC

- Check Condition: Key-On, Engine Running
- Fault Condition: MAP is greater than 8 psia, secondary MAP is 1.5 psi higher than primary MAP for 45 seconds
- MIL: ON during active fault
- Fault Action: Engine Shutdown

Fault Description

A V-series engine have separate fuel systems and throttle bodies for the primary side and secondary side of the engine. The ECM monitors MAP pressure to verify both engine banks are equally contributing power.

This fault will set if the ECU measures MAP on the secondary side is at least 1.5 psi higher than the primary MAP for 45 seconds.

Diagnostic Aid


This fault indicates that the boost on the primary side is lower than the boost on the secondary side; it does not necessarily mean the secondary side boost is too high. The most likely and alternate possible causes are listed below. Review the most likely possible causes and diagnose the issue to determine root cause.

Another common issue is a leak in the CAC piping on the primary side, causing the primary side boost to be lower than the secondary. Check all hose clamps on the CAC piping to make sure they're properly clamped and tight, and make sure there are no tears in any of the silicone boots. Pay particular attention to the boots and clamps located underneath the bridge over the valley of the engine by the ECUs, as they are prone to coming loose due to vibration and are difficult to inspect.

Most Likely Causes	Alternate Possible Causes
Misfire condition	Faulty turbo not making boost
Partial misfire from valve lash	Lack of compression
Leak in the CAC system (boots, clamps, CAC)	Turbo wastegate not adjusted properly
Turbo Wastegate sticking ¹	Suspect or sticking throttle body

Step	Action	Yes	No
1	Check all hose clamps on the CAC piping to make sure they are in the proper locations and tight. Clamps are located at the turbocharger compressor outlet, underneath the bridge over the valley of the engine, at the CAC core inlet, at the CAC core outlet, and at the throttle body inlet. Are clamps tight?	Proceed to Step 2	Tighten clamps, making sure the clamp is not located on the edge of either the silicone boot or the pipe. Clear fault and test engine
2	Inspect all silicone boots on CAC piping to make sure there are no tears or holes in the boots. Are boots OK?	Proceed to Step 3	Replace damaged boot(s), clear fault, and retest engine
3	Check the wastegate actuator pressure lines on both turbos to make sure they are connected, the clamps are tight, and the hose is not damaged and leaking. Are the hoses OK?	Proceed to Step 4	Repair loose/damaged hose, clear fault, and retest engine
4	Perform a spark kill test while running the engine under approximately 20% load. Monitor MAP for changes as each cylinder is disabled. Are all cylinders contributing equally?	Proceed to Step 5	Diagnose the issue with the weak cylinder
5A	Remove the TIP and MAP sensors and inspect for damage/dirt. Clean the sensors. Reinstall the MAP sensor from the secondary side on the primary side, and the MAP sensor from the primary side in the secondary side. Clear all faults, run the engine, and try to recreate the fault. Did the DTC 234 fault come back?	Proceed to Step 6	Proceed to Step 5B
5B	Is DTC 299 now active?	Replace MAP sensor currently installed on secondary side	Intermittent fault
6	Inspect the turbocharger: Remove the exhaust pipe from the turbine outlet of the secondary turbo, and remove the fuel system and intake boot from the compressor inlet. Inspect the compressor and turbine wheels for damage. Make sure the wheels spin freely. Do turbine/compressor wheels pass inspection?	Proceed to Step 7	Replace the turbocharger
7	<p>Remove the wastegate cover from the turbochargers and inspect the wastegate. Make sure the wastegate is undamaged and sealing properly.</p> <p>Remove the retaining ring from the actuator linkage and remove the wastegate actuator from the arm.</p> <p>Make sure the wastegate arm moves freely and the valve opens and closes.</p> <p>Make sure the wastegate actuator moves – there will be substantial spring pressure but you should be able to pull the rod out of the actuator slightly.</p> <p>Does the wastegate pass inspection?</p>	Intermittent problem	Replace the turbocharger

DTC 236 - TIP/TOP Active



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: TIP < 16 psia and MAP > 18 psia
- MIL on
- Adaptive disabled

Fault Description


The engine uses a throttle inlet pressure (TIP) sensor upstream of the throttle valve to monitor incoming throttle pressure. The TIP should always be higher than the MAP. If MAP is ever at 18 psia or higher and TIP is reading at less than 16 psia, a TIP/TOP active fault is logged.

Diagnosing the Fault

Check to make sure the wiring for the TIP and MAP sensors is not reversed. The two sensors are identical and they are close enough to each other that it is possible to swap the connectors. The TIP sensor, located on the charge air piping, should have three wires at the connector while the MAP sensor, located on the throttle body adapter on the intake manifold, should have four wires at the connector. If the wiring for the sensors is correct, check to ensure the sensor is properly installed in the CAC piping. It should be held in place with a retaining bolt. Ensure it is fully installed into the pipe and the bolt is tight.

If the installation is correct, remove the sensor and inspect for damage. Replace the sensor with a known good part and test again.

DTC 237 - TIP/TOP Low Voltage



Conditions for Setting the DTC

- Throttle Inlet Pressure
- Check Condition: Key On, Engine Off
- Fault Condition: TIP voltage less than 0.2V
- MIL on
- Adaptive disabled

Fault Description

The engine uses a throttle inlet pressure (TIP) sensor upstream of the throttle valve to monitor incoming throttle pressure. This fault will set when the TIP sensor voltage feedback is sensed as lower than the sensor should normally produce as set in the diagnostic calibration.

Diagnosing the Fault


In many cases, this condition is caused by the TIP sensor being disconnected from the engine harness, an open-circuit or short-to-ground of the TIP sensor circuit in the wire harness, a loss of sensor reference voltage, or a failure of the sensor.

DTC 237 - TIP/TOP Low Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DST display TIP voltage less than the limit defined in calibration with the engine running??	Go to Step (3)	Go to Step (4)
3	Key On, Engine Off System Mode = "Stopped"		Go to Step (5)	
4	Intermittent Problem			
5	If DTC 642 or 643 are present, troubleshoot those first. Using a DMM, measure the voltage potential across 5Vref1 and 5Vrtn1 at connector.	Does DMM indicate a voltage >4.7 VDC?	Go to Step (6)	Go to Step (7)
6	Jumper the TIP circuit to Vref (5 VDC) in connector on harness.	Does DST display TIP voltage of 4.7 VDC or greater?	Go to Step (8)	Go to Step (9)
7	Faulty harness (check 5Vref1 and 5Vrtn1 connections) Faulty ECM (5Vref power supply).			
8	Poor connection at sensor Faulty TIP sensor			

Step	Action	Value(s)	Yes	No
9	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between TPS2 input at ECM header and signal at device. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer make contact with ECM pins. Spread pins will void warranty! Probe on the side of terminal.	Is the resistance <5 ohms?	Go to Step (10)	Go to Step (11)
10	Reconnect header to ECM Key On, Engine Off System Mode="Stopped" Probe TIP signal circuit with a test light connected to battery voltage	Does DST display TIP voltage of 4.0 VDC or greater?	Go to Step (12)	Go to Step (13)
11	Faulty Harness			
12	Faulty ECM connection Faulty ECM (analog input circuit)			
13	TIP signal shorted to ground Faulty ECM connection Faulty ECM (analog input circuit)			

DTC 238 - TIP/TOP High Voltage



Conditions for Setting the DTC

- Throttle Inlet Pressure
- Check Condition: Key On, Engine Off
- Fault Condition: TIP voltage greater than 4.8V
- MIL on
- Adaptive disabled

Fault Description

The engine uses a throttle inlet pressure (TIP) sensor upstream of the throttle valve to monitor incoming throttle pressure. This fault will set when the TIP sensor voltage feedback is sensed as higher than the sensor should normally produce as set in the diagnostic calibration.



Diagnosing Fault

In many cases, this condition is caused by the TIP circuit being shorted to a voltage source or a failure of the sensor.

DTC 238 - TIP/TOP High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running"	Does DST display TIP pressure greater than that defined in the diagnostic calibration with the engine idling?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect TIP sensor from harness Key On, Engine off System Mode = "Stopped"	Does DST display TIP voltage <0.100 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Probe sensor ground circuit with test light connected to battery voltage	Does test light come on?	Go to Step (7)	Go to Step (8)
6	TIP signal circuit shorted to voltage Faulty sensor Faulty ECM			
7	Faulty TIP sensor Faulty ECM connector			
8	Open sensor ground circuit Faulty ECM			

DTC 298 - Oil Temperature Too High



Conditions for Setting the DTC

- Conditions for setting the DTC
- Check Condition: Key On, Engine Stopped
- Fault Condition: Oil Temperature >235 °F
- MIL: ON during active fault
- Engine Shutdown

Fault Description

The Oil Temperature and Pressure sensor is used to monitor oil pressure and oil temperature.

This fault sets if the measured oil temperature is outside the upper limit as defined in the calibration. Required entry conditions for evaluation of this fault are the absence of any of the four faults below:

Diagnostic Aid

High oil temperatures are typically a result of environmental or application related issues. If this is a new installation or new application, please evaluate your oil cooling method to ensure the application is designed and installed correctly to ensure oil temperature is maintained within the allowable guidelines.

Check for other codes such as DTC 1517 which is a circuit fault for the same sensor. If you have an active DTC 298 and active DTC 1517, you likely have a sensor or circuit issue that should be diagnosed.

DTC 298 - Oil Temperature Too High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped"	Does DST display fault code?	Go to Step (3)	Go to Step (4)
3	Measure oil temperature	Is oil temperature >235 °F	Go to Step (5)	Go to Step (6)
4	Intermittent Problem OR run the engine until the fault becomes active.	Fault Active?	Go to Step (3)	Intermittent – monitor for future issues.
5	Troubleshoot and correct the source of oil overheating Re-test			
6	See guidance below.			

1. Visual Inspection:

- Inspect the oil temperature sensor and its wiring for any visible damage, corrosion, or loose connections.
- Ensure the sensor is properly installed and secured.

2. Sensor Signal Check:

- Locate the oil temperature sensor on the engine. It's typically near or in the oil pan or near the oil filter housing.
- Disconnect the sensor.
- Set your multimeter to measure DC voltage.
- Connect the multimeter's positive lead to Pin 1 (Temp Signal) of the sensor connector and the negative lead to a good engine ground.
- Turn the ignition to the ON position (do not start the engine).
- Check for voltage. The exact voltage can vary, but generally, a reading between 0.5 to 4.5 volts is expected at ambient temperature. Consult the manufacturer's specifications for precise values.

3. Reference Voltage Check (5V_EXT):

- With the sensor still disconnected, move the multimeter's positive lead to Pin 3 (5V_EXT).
- Check for a 5V reference. If 5V is not present, trace the issue back to the ECM or check for a wiring fault.

DTC 299 - Control Underboost

Conditions for Setting DTC

- Check Condition: Key-On, Engine Running
- Fault Condition: MAP is greater than 8 psia, secondary MAP is 1.5 psi lower than primary side MAP for 45 seconds
- MIL: ON during active fault
- Fault Action: Engine Shutdown

Fault Description

A V-series engine has separate fuel systems and throttle bodies for the primary side and secondary side of the engine. The ECM monitors MAP pressure to verify both engine banks are equally contributing power.

This fault will set if the ECU measures MAP on the secondary side is at least 1.5 psi lower than the primary MAP for 45 seconds.

Diagnostic Aid


This fault indicates that the boost on the secondary side is lower than the boost on the primary side; it does not necessarily mean the secondary side boost is too high. The most likely and alternate possible causes are listed below. Review the most likely possible causes and diagnose the issue to determine root cause.

Another common issue is a leak in the CAC piping on the secondary side, causing the primary side boost to be higher than the secondary. Check all hose clamps on the CAC piping to make sure they're properly clamped and tight, and make sure there are no tears in any of the silicone boots. Pay particular attention to the boots and clamps located underneath the bridge over the valley of the engine by the ECUs, as they are prone to coming loose due to vibration and are difficult to inspect.

Most Likely Causes	Alternate Possible Causes
Misfire condition	Faulty turbo not making boost
Partial misfire from valve lash	Lack of compression
Leak in the CAC system (boots, clamps, CAC)	Turbo wastegate not adjusted properly
Turbo Wastegate sticking ¹	Suspect or sticking throttle body

Step	Action	Yes	No
1	Check all hose clamps on the CAC piping to make sure they are in the proper locations and tight. Clamps are located at the turbocharger compressor outlet, underneath the bridge over the valley of the engine, at the CAC core inlet, at the CAC core outlet, and at the throttle body inlet. Are clamps tight?	Proceed to Step 2	Tighten clamps, making sure the clamp is not located on the edge of either the silicone boot or the pipe. Clear fault and test engine
2	Inspect all silicone boots on CAC piping to make sure there are no tears or holes in the boots. Are boots OK?	Proceed to Step 3	Replace damaged boot(s), clear fault and retest engine
3	Check the wastegate actuator pressure lines on both turbos to make sure they are connected, the clamps are tight, and the hose is not damaged and leaking. Are the hoses OK?	Proceed to Step 4	Repair loose/damaged hose, clear fault and retest engine
4	Perform a spark kill test while running the engine under approximately 20% load. Monitor MAP for changes as each cylinder is disabled. See “Performing a spark kill test” section of this manual for more information. Are all cylinders contributing equally?	Proceed to Step 5	Diagnose the issue with the weak cylinder
5A	Remove the TIP and MAP sensors and inspect for damage/dirt. Clean the sensors. Reinstall the MAP sensor from the secondary side on the primary side, and the MAP sensor from the primary side in the secondary side. Clear all faults, run the engine, and try to recreate the fault. Did the DTC 299 fault come back?	Proceed to Step 6	Proceed to Step 5B
5B	Is DTC 234 now active?	Replace MAP sensor currently installed on primary side	Intermittent fault
6	Inspect the turbocharger: Remove the exhaust pipe from the turbine outlet of the secondary turbo and remove the fuel system and intake boot from the compressor inlet. Inspect the compressor and turbine wheels for damage. Make sure the wheels spin freely.	Proceed to Step 7	Replace the turbocharger
7	Remove the wastegate cover from the turbochargers and inspect the wastegate. Make sure the wastegate is undamaged and sealing properly. Remove the retaining ring from the actuator linkage and remove the wastegate actuator from the arm. Make sure the wastegate arm moves freely and the valve opens and closes. Make sure the wastegate actuator moves – there will be substantial spring pressure, but you should be able to pull the rod out of the actuator slightly. Does the wastegate pass inspection?	Intermittent problem	Replace the turbocharger

DTC 326 - Knock 1 Excessive Signal



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: With MAP below 10 psia, knock sensor input voltage is greater than 4V for 3 seconds
- MIL: ON during active fault
- Engine Shutdown

Fault Description

The knock sensor is used to detect detonation through mechanical vibration in the engine block and/or cylinder heads and provide feedback for the ignition system to retard spark timing to reduce knock intensity. In most applications the knock sensor is used to protect the engine from damage that can be caused from detonation or knock based on fixed spark advance. This fault sets if the signal from knock sensor 1 is higher than expected for low load operation. If the fault sets, the MIL light is active, and the engine will shut down.


DTC 326 - Knock 1 Excessive Signal

Note:

" Verify all knock sensors are torqued properly before proceeding with the below steps and recheck.

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"			
3	Operate engine at the condition that generated the fault as indicated in fault snapshot. Verify the DTC 326 is active/.			
4	Disconnect ect knock sensor 1 from wire harness			
5	Operate engine at the condition that generated the fault as indicated in fault snapshot.		Go to Step (6)	Go to Step (7)
6	Key ON, Engine Off System Mode = "Running"	Using a DVOM, is the voltage potential between knock 1+ and Vbat >80% of Vbat?	Go to Step (8)	Go to Step (9)
7	Faulty Sensor, replace			
8	Disconnect wire harness header from ECM	Using a DVOM, is the voltage potential between knock 1+ and Vbat >80% of Vbat?	Go to Step (10)	Go to Step (11)
9	Possible faulty sensor Intermittent fault			
10	Possible faulty ECM			
11	Faulty wire harness			

DTC 327 – Knock 1 Sensor Open



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: With MAP below 10 psia, knock sensor input voltage is less than 0.001V for 3 seconds
- MIL: ON during active fault
- Engine Shutdown

Fault Description

The knock sensor is used to detect detonation through mechanical vibration in the engine block and/or cylinder heads and provide feedback for the ignition system to retard spark timing to reduce knock intensity. In most applications the knock sensor is used to protect the engine from damage that can be caused from detonation or knock based on fixed spark advance. This fault sets if the signal from knock sensor 1 is lower than expected for low load operation. If the fault sets, the MIL light is active and the engine will shut down.

Ensure Knock Sensors are Installed securely and torqued to 20 ft/lbs

Visual Inspection:

- Check the knock sensor wiring for visible damage, cuts, or corrosion.
- Inspect connectors for bent pins, corrosion, or loose connections.


Inspect the Knock Sensor:

- Verify the knock sensor is properly torqued to the engine block. If it's loose, retorque it to specification.

DTC 327 – Knock I Sensor Open

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = “Running”			
3	Operate engine at the minimum RPM and MAP defined in diagnostic calibration for the knock sensor open fault	Does DTC 327 reset?	Go to Step (4)	Go to Step (5)
4	Key Off Disconnect knock sensor from wire harness			Go to Step (6)
5	Intermittent Problem			
6	Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between Knock 1 (+) output at ECM header and knock sensor connector. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer make contact with ECM pins. Spread pins will void warranty! Probe on the side of terminal.	Does DMM indicate a resistance <5.0 ohms?	Go to Step (7)	Go to Step (8)
7	Check resistance between Knock 1 (+) and ground and 5Vrtn1 (Analog Return)	Does DMM indicate a resistance <5.0 ohms?	Go to Step (9)	Go to Step (10)
8	Faulty harness (open circuit)			
9	Faulty harness (ground short)			
10	Inspect knock wiring in harness	Is wiring properly twisted?	Go to Step (11)	Go to Step (12)
11	Faulty sensor (replace and retest) Faulty ECM			
12	Faulty Harness			

DTC 336 - Crank Sync Noise



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: 1 invalid resync within a time window of 800 milliseconds
- MIL: ON during active fault
- Adaptive learn disabled

Fault Description

The crankshaft position sensor is a magnetic sensor installed on the engine adjacent to a "coded" trigger wheel located on the vibration dampener. The sensor-trigger wheel combination is used to determine crankshaft position (with respect to TDC cylinder #1 compression) and the rotational engine speed. Determination of the crankshaft position and speed is necessary to properly activate the ignition, fuel injection, and throttle governing systems for precise engine control.


The ECM must see a valid crankshaft position while running. If no signal is present, the signal amplitude is too high (due to improper air gap with respect to trigger wheel), or an irregular crank pattern is detected causing the ECU to resynchronize more than once in 800 milliseconds, the fault will set. Irregular crank patterns can be detected by the ECM due to electrical noise, poor machining of the trigger wheel, or trigger wheel runout and/or gear lash.

DTC 336 - Crank Sync Noise

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"		Go to Step (3)	
3	Operate engine at condition that set the fault based on fault snapshot.	Does DTC 336 reset?	Go to Step (4)	Go to Step (5)
4	-	Is crank sensor a VR/ magnetic pick-up?	Go to Step (6)	Go to Step (7)
5	Intermittent fault			
6	-	Is wiring between sensor and ECM properly twisted?	Go to Step (10)	Go to Step (11)
7	Check wiring and electrical connections between crankshaft position sensor and ECM	Is the wiring, OK?	Go to Step (8)	Go to Step (9)
8	Poor system ground Bad crankshaft position sensor Bad ECM			
9	Repair wire harness			
10	-	Does fault only occur at high operating speeds?	Go to Step (12)	Go to Step (13)
11	Faulty wire harness (twist circuit)			
12	Increase the air gap between sensor and trigger wheel			

Step	Action	Value(s)	Yes	No
13	Check wiring and electrical connections between crankshaft position sensor and ECM	Is wiring OK?	Go to Step (14)	Go to Step (15)
14	Repair wire harness			
15	Poor system ground Bad crankshaft position sensor Bad ECM			

DTC 337 - Loss of Crankshaft Signal



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: ECM sees six cam pulses without crank activity
- MIL: ON during active fault
- Engine shutdown

Fault Description


The crankshaft position sensor is a magnetic sensor installed on the engine adjacent to a "coded" trigger wheel located on the vibration dampener. The sensor-trigger wheel combination is used to determine crankshaft position (with respect to TDC cylinder #1 compression) and the rotational engine speed. Determination of the crankshaft position and speed is necessary to properly activate the ignition, fuel injection, and throttle governing systems for precise engine control.

The ECM must see a valid crankshaft position while running. If no signal is present while six cam pulses continue the fault will set. The MIL will come on and the engine will shut down.

Diagnostic Aids

- Check that the crankshaft position sensor is securely connected to harness
- Check that the crankshaft position sensor is securely installed in bracket, and bracket is tight and properly aligned with the crankshaft position wheel
- Check crankshaft position sensor circuit wiring for open circuit

DTC 341 - Cam Input Signal Noise



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: 1 invalid resyncs in 700 milliseconds
- MIL: ON during active fault
- Adaptive learn disabled

Fault Description

The camshaft position sensor is a magnetic sensor installed in the engine block adjacent to a "coded" trigger wheel. The sensor-trigger wheel combination is used to determine cam position with respect to TDC #1 compression. Determination of the camshaft position is necessary to identify the stroke (or cycle) of the engine to properly activate the ignition for precise engine control.


For a cam synchronized engine, the ECM must see a valid camshaft position signal while running. If no signal is present, the signal amplitude is too high (due to improper air gap with respect to the trigger wheel), or an irregular cam pattern is detected causing the ECM to resynchronize once in 700 milliseconds, this fault will set. Irregular cam patterns can be detected by the ECM due to electrical noise, poor machining of the trigger wheel, or trigger wheel runout and/or gear lash. When the fault is set the MIL will light and the engine will not enter adaptive learn mode. In some instances, this fault can cause rough engine operation and can cause the engine to stall and die if equipped with a coil-on-plug ignition system.

DTC 341 - Cam Input Signal Noise

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"		Go to Step (3)	
3	Operate engine at condition that set the fault based on fault snapshot.	Does DTC 341 reset?	Go to Step (4)	Go to Step (5)
4	-	Is cam sensor a VR/magnetic pick-up?	Go to Step (6)	Go to Step (7)
5	Intermittent fault			
6	-	Is wiring between sensor and ECM properly twisted?	Go to Step (10)	Go to Step (11)
7	Check wiring and electrical connections between camshaft position sensor and ECM	Is the wiring, OK?	Go to Step (8)	Go to Step (9)
8	Poor system ground Bad camshaft position sensor Bad ECM			
9	Repair wire harness			
10	-	Does fault only occur at high operating speeds?	Go to Step (12)	Go to Step (13)
11	Faulty wire harness (twist circuit)			
12	Increase the air gap between sensor and trigger wheel			

Step	Action	Value(s)	Yes	No
13	Check wiring and electrical connections between camshaft position sensor and ECM	Is wiring OK?	Go to Step (14)	Go to Step (15)
14	Repair wire harness			
15	Poor system ground Bad camshaft position sensor Bad ECM			

DTC 342 - Loss of Camshaft Input Signal



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: No cam pulses in 2.5 engine cycles with engine RPM > 1000
- MIL: ON during active fault
- Engine shutdown

Fault Description

The camshaft position sensor is a magnetic sensor installed in the engine block adjacent to a "coded" trigger wheel. The sensor-trigger wheel combination is used to determine cam position with respect to TDC #1 compression. Determination of the camshaft position is necessary to identify the stroke (or cycle) of the engine to properly activate the ignition for precise engine control.

For a cam synchronized engine, the ECM must see a valid camshaft position signal while running. This fault will set if valid crankshaft position data is received for 2.5 engine cycles with an engine speed greater than 1000 RPM and no camshaft signal is received. The MIL will light and the engine will shut down.

Diagnostic Aids

- Check that the camshaft position sensor is securely connected to harness
- Check that the camshaft position sensor is securely installed, and bracket (if used) is tight and properly aligned with the crankshaft position wheel.
- Check camshaft position sensor circuit wiring for open circuit

DTC 359 - (1239:7) - Fuel Run-Out Longer Than Expected

Conditions for Setting the DTC

- Fuel run-out engine run time > 12 Seconds
- Fault Condition: No cam pulses in 2.5 engine cycles with engine RPM > 1000.
- ECT > -40.0 deg F°.
- MIL: ON during active fault
- Engine shutdown

Fault Description

A normally closed electromechanical fuel shut-off is used to isolate the EPR or Dual Stage Regulator (DSR) and all downstream components from the upstream fuel supply when the engine is shut off.

The Fuel Runout Longer Than Expected test is conducted on engine shut down.

The ignition system continues to operate when the key is turned off, but the lockoff is closed, starving the engine of fuel resulting in a shut down.

This fault will occur when the time it takes to shutdown the engine is longer than expected, which generally indicates the fuel lock off is not closing as expected.

Diagnostic Aids

With the engine running disconnect the electrical connector on the fuel shut-off solenoid from the engine harness. If the engine continues to run after 60 seconds you must diagnose the issue further.


Likely causes

- 1) Defective lock off (staying open)
- 2) Incorrect or defective wiring circuit on fuel lock off power and ground
 - a. See PSI knowledge article PSIKO210105 or the PSI application guide to review proper wiring and connections to the fuel lock off valve.

Never connect lock-off power directly to the battery. Instead, source the power supply from either the lock-off connector or the customer interface connector, both of which are accessible on all PSI harnesses.

The relay power circuit serves as the power source for the lock-off, while the ground is provided by the ECM through the NG (Negative Ground) or LP (Lock Off Power) lock-off ground circuit.

DTC 520 - Oil Pressure Low Stage 1




Conditions for Setting the DTC

- Engine Oil Pressure low.
- Check Condition: Engine running for 5 seconds or more with engine speed greater than 600 rpm.
- Fault Condition: Oil pressure less than 15 PSI if engine speed is less than 1,400rpm
- Fault Condition: Oil pressure less than 30 PSI if engine speed is greater than 1,450rpm
- MIL is illuminated

Circuit Description

The Oil Pressure Sender is used to communicate the oil pressure condition to the ECM. Engine damage can occur if the engine is operated with low oil pressure. The ECM sends a 5v signal to the oil pressure sender. The sender will report a signal back to the ECM on the signal wire depending on the pressure that is applied on its diaphragm. The voltage is linear in comparison to the pressure applied (see chart below). The MIL command is ON and the engine will shut down in the event of this fault to help prevent possible engine damage.



Code #	Code Name	RPM	Pressure
520	Oil Pres Low Stage 1	<= 1,400	15 psi
520	Oil Pres Low Stage 1	>= 1,450	30 psi
524	Oil Pres Low Stage 2	<= 1,400	8 psi
524	Oil Pres Low Stage 2	>= 1,450	25 psi

DTC 520 - Oil Pressure Low Stage 1

Note:

If both oil pressure sensors (Master and slave side) are reading zero and are not showing pressure, **DO NOT** continue to crank the engine repeatedly.

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Verify that the engine has oil pressure using a mechanical oil pressure gauge before proceeding with this chart. Does the engine have oil pressure above 8 psi?	8 psi	Go to Step (3)	Repair faulty Oiling System
3	Key ON, Engine Running DST connected in System Data Mode Clear DTC 520 Warm the engine by idling until the ECT temperature is above 160 degrees F. and has been running for at least 5 seconds or more. Does DTC 520 become active?		Go to Step (4)	Intermittent problem Go to Intermittent section
4	With a voltmeter, check terminal B on the sensor for a 5-volt reference from the ECM. Do you have 5 volts on terminal 3?	5v	Go to Step (6)	Go to Step (5)
5	With a voltmeter, check terminal 19 on the ECM for a 5-volt reference. Do you have a 5v reference coming out of the ECM?	5v	Repair faulty wiring between ECM and Oil pressure sensor	Go to Step (8)
6	With the oil pressure sender connected check for a signal coming out of terminal 4. Do you have a voltage signal coming out of terminal 4?		Go to Step (7)	Replace faulty oil pressure sender
7	With the oil pressure sender connected check for a signal at terminal 44 of the ECM. Do you have a signal voltage at pin 44 of the ECM that matches the voltage at terminal 4 of the oil pressure sensor?		Go to Step (8)	Repair faulty wiring between terminal C and Terminal 25.
8	Replace ECM Is the replacement complete?		Go to Step (9)	-

Step	Action	Value(s)	Yes	No
9	<p>Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-520 check for any stored codes. Does the engine operate normally with no stored codes?</p>		System OK	Go to OBD System Check

DTC 521 - Oil Pressure High (Sender)

OIL PRES&TEMP CONN (C16)			
BLACK/LT GREEN	18	1	5V_rtn
LT GREEN/WHITE	18	2	AUX_ana_PU3
LT GREEN/RED	18	3	5V_ext
LT GREEN/BLACK	18	4	OILP

Conditions for setting the DTC

- Key on, Engine on
- Fault Conditions: Oil pressure less than normal operating pressure.
- MIL:ON
- Engine Shutdown


Fault Description

The oil pressure sensor measure oil pressure through a transducer or through a switch. Oil pressure monitoring is important to prevent engine damage due to low oil pressure resulting in higher friction and lack of lubrication. High oil pressure can be undesirable because it can cause oil to leak past seals and rings, can also be a result of a restriction in the oil flow path or it can be a sign of a malfunctioning oiling system.

DTC 521 - Oil Pressure High (Sender)

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"		Go to Step (3)	
3	Warm engine at idle to normal operating temperature Increase RPM above limit set in diagnostic calibration	Does DTC 521 reset?	Go to Step (4)	Go to Step (5)
4	Key Off Disconnect harness from Oil Pressure Switch Clear DTC 521 Key On, Engine On System Mode="Running" Operate engine at idle for at least one minute Increase RPM above limit set by diagnostic calibration	Does DTC 521 reset?	Go to Step (6)	Go to Step (7)
5	Intermittent problem			
6	Oil Pressure circuit shorted-to-ground in harness Faulty ECM			
7	Faulty Oil Pressure Switch (short circuit) Faulty engine oiling system (verify with mechanical gauge)			

DTC 522 - Oil Pressure Sender low voltage




Conditions for Setting the DTC

- Check Condition: Engine running for 20 seconds or more with engine speed greater than 600 rpm.
- Fault Condition: Voltage on terminal 44 is less than 0.2v for more than 1 second
- MIL: ON during active fault and for 2 seconds after active fault.

Circuit Description


The Oil Pressure Sender is used to communicate the oil pressure condition to the ECM. Engine damage can occur if the engine is operated with low oil pressure. The ECM sends a 5v signal to the oil pressure sender. The sender will report a signal back to the ECM on the signal wire depending on the pressure that is applied on its diaphragm. The voltage is linear in comparison to the pressure applied (see chart below). The MIL command is ON and the engine will shut down in the event of this fault to help prevent possible engine damage.



DTC 522 - Oil Pressure Sender low voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DST display Oil Pressure voltage less than the limit defined in calibration?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect Oil Pressure from harness Key On, Engine Off System Mode="Stopped"	Does DTC display Oil Pressure voltage of 4.90 VDC or greater?	Go to Step (5)	Go to Step (6)
4	Intermittent problem			
5	Faulty Oil Pressure sensor			
6	Sensor signal circuit shorted to ground, check wire harness for ground short Faulty ECM			

DTC 523 - Oil Pressure Sender high voltage




Conditions for Setting the DTC

- Check Condition: Engine running for 20 seconds or more with engine speed greater than 600 rpm.
- Fault Condition: Voltage on terminal 44 is greater than 4.8v for more than 1 second
- MIL: ON during active fault and for 2 seconds after active fault.
- Engine Shutdown

Circuit Description

The Oil Pressure Sender is used to communicate the oil pressure condition to the ECM. Engine damage can occur if the engine is operated with low oil pressure. The ECM sends a 5v signal to the oil pressure sender. The sender will report a signal back to the ECM on the signal wire depending on the pressure that is applied on its diaphragm. The voltage is linear in comparison to the pressure applied (see chart below). The MIL command is ON and the engine will shut down in the event of this fault to help prevent possible engine damage.




OTC 523 - Oil Pressure Sender High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine On System Mode = "Running"	Does the DST display Oil Pressure voltage greater than that defined in the recorded in the diagnostic calibration with engine idling?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect Oil Pressure sensor from harness Key On, Engine Off System Mode="Stopped"	Does DTC display Oil Pressure voltage of 4.90 VDC or greater?	Go to Step (6)	Go to Step (7)
4	Operate at an engine speed equal to or greater than that recorded when the fault previously set based on the fault snapshot	Does DST display Oil Pressure voltage greater than that defined in the diagnostic calibration?	Go to Step (3)	Go to Step (5)
5	Intermittent Problem			
6	Jumper Oil Pressure signal circuit to 5Vrtn 1 (Analog Return)	Does DST display Oil Pressure voltage <0.1 VDC?	Go to Step (8)	Go to Step (9)
7	Oil Pressure signal circuit short to ground Faulty ECM			

Step	Action	Value(s)	Yes	No
8	Jumper Oil Pressure signal circuit to ground	Does DST display Oil Pressure voltage <0.1 VDC?	Go to Step (10)	Go to Step (11)
9	Faulty connection to sensor Faulty Oil Pressure sensor			
10	Open Oil Pressure ground (5Vtrn1) circuit Faulty connection to sensor Faulty Oil Pressure sensor			
11	Key Off Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between Knock 1 (+) output at ECM header and knock sensor connector. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer make contact with ECM pins. Spread pins will void warranty! Probe on the side of terminal.	Is the resistance <5 ohms?	Go to Step (12)	Go to Step (13)
12	Faulty ECM connection Faulty ECM			
13	Faulty Harness			

DTC 524 - Oil Pressure Low Stage 2




Conditions for Setting the DTC

- Engine Oil Pressure low.
- Check Condition: Engine running for 20 seconds or more with engine speed greater than 600 rpm.
- Fault Condition: Oil pressure less than 8 PSI with engine RPM less than 1,400rpm
- Fault Condition: Oil pressure less than 25psi with engine RPM greater than 1,450rpm
- Engine Shut Down.

Circuit Description

The Oil Pressure Sender is used to communicate the oil pressure condition to the ECM. Engine damage can occur if the engine is operated with low oil pressure. The ECM sends a 5v signal to the oil pressure sender. The sender will report a signal back to the ECM on the signal wire depending on the pressure that is applied on its diaphragm. The voltage is linear in comparison to the pressure applied (see chart below). The MIL command is ON and the engine will shut down in the event of this fault to help prevent possible engine damage.




Code #	Code Name	RPM	Pressure
520	Oil Pres Low Stage 1	<= 1,400	15 psi
520	Oil Pres Low Stage 1	>= 1,450	30 psi
524	Oil Pres Low Stage 2	<= 1,400	8 psi
524	Oil Pres Low Stage 2	>= 1,450	25 psi

OTC 524 - Oil Pressure Low Stage 2

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Verify that the engine has oil pressure using a mechanical oil pressure gauge before proceeding with this chart. Does the engine have oil pressure above 8 PSI?	8 PSI	Go to Step (3)	Repair faulty Oiling System
3	Key ON, Engine Running DST connected in System Data Mode Clear DTC 524 Warm the engine by idling until the ECT temperature is above 160 degrees F. and has been running for at least 20 seconds or more Does DTC 524 reset and cause the engine to shut down?		Go to Step (4)	Intermittent problem Go to Intermittent section
4	With a volt meter, check terminal 3 on the sensor for a 5 volt reference from the ECM. Do you have 5 volts on terminal 3?	5v	Go to Step (6)	Go to Step (5)
5	With a volt meter, check terminal 19 on the ECM for a 5 volt reference. Do you have a 5v reference coming out of the ECM?	5v	Repair faulty wiring between ECM and Oil pressure sensor	Go to Step (<)
6	With the oil pressure sender connected check for a signal coming out of terminal 3. Do you have a voltage signal coming out of terminal 3?		Go to Step (7)	Replace faulty oil pressure sender
7	With the oil pressure sender connected check for a signal at terminal 44 of the ECM. Do you have a signal voltage at pin 44 of the ECM?		Go to Step (8)	Repair faulty wiring between terminal 3 and Terminal 25.
8	Replace DEPR / ECM Is the replacement complete?		Go to Step (9)	-

Step	Action	Value(s)	Yes	No
9	<p>Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-524 check for any stored codes. Does the engine operate normally with no stored codes?</p>		System OK	Go to OBD System Check

DTC 562 - System Voltage Low



Conditions for Setting the DTC

- Check Condition: Key on with engine speed greater than 1000 RPM
- Fault Condition: Battery voltage at ECM less than 18.0
- Fault Condition is present for longer than 5 seconds.
- MIL: ON for active fault
- Adaptive: Disabled


Circuit Description

The battery voltage powers the ECM and must be measured correctly to properly operate injector drivers, solenoid valves and ignition coils. This fault will set if the ECM detects system voltage less than 18.00 volts while the alternator should be charging. The adaptive learn is disabled during this fault.

DTC 562 - System Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at Idle			
3	Check battery voltage in DST	Is battery voltage > low voltage limit is diagnostic limit in diagnostic condition?	Go to Step (4)	Go to Step (5)
4	Fault is Intermittent			
5	Using a DVM measure the voltage potential across battery (+) and (-)	Is battery voltage > low voltage limit is diagnostic limit in diagnostic condition?	Go to Step (6)	Go to Step (7)
6	Faulty Vbat power or ground circuit to ECM			
7	Faulty battery Faulty charging system Faulty ECM			

DTC 563 - Battery Voltage High



Conditions for Setting the DTC

- Check Condition: Key On, Engine cranking or running
- Fault Condition: Battery voltage exceeds 33V for 3 seconds
- MIL: ON during active fault
- Adaptive learn disabled

Fault Description


The battery voltage powers the ECM and must be within limits to correctly operate ignition coils, throttle, power supplies, and other powered devices that the ECM controls.

This fault will set if the ECM detects system voltage greater than 33V while the engine is running or cranking. The MIL will light and adaptive learn is disabled to avoid improper adaptive learning.

DTC 563 - Battery Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at Idle			
3	Check battery voltage in DST	Is battery voltage < high voltage limit in diagnostic condition?	Go to Step (4)	Go to Step (5)
4	Fault is Intermittent			
5	Using a DVM measure the voltage potential across battery (+) and (-)	Is battery voltage < high voltage limit in diagnostic condition?	Go to Step (6)	Go to Step (7)
6	Faulty ECM			
7	Key Off Disconnect wire harness header from ECM Using a DMM measure the voltage potential across battery (+) and (-)	Is battery voltage < high voltage limit in diagnostic condition?	Go to Step (8)	Go to Step (9)
8	Faulty charging system			
9	Faulty battery			

DTC 601 - Flash Checksum Invalid



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Engine Shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down when this fault occurs.

DTC 601 - Flash Checksum Invalid

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at Idle			
3	Clear system fault	Does DTC 601 reset with engine running?	Go to Step (4)	Go to Step (5)
4	Check all power and ground circuits to ECM	Are all circuits, OK?	Go to Step (6)	Go to Step (7)
5	Fault is Intermittent			
6	Replace ECM with known good part and retest			
7	Repair wiring to ECM and retest			

DTC 604 - RAM Failure



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Engine Shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this fault occurs.

DTC 604 - RAM Failure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at Idle			
3	Clear system fault	Does DTC 604 reset with engine idling?	Go to Step (4)	Go to Step (5)
4	Check all power and ground circuits to ECM	Are all circuits OK?	Go to Step (6)	Go to Step (7)
5	Fault is Intermittent			
6	Replace ECM with known good part and retest			
7	Repair wiring to ECM and retest			

DTC 606 - COP Failure



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Engine Shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this fault occurs.

DTC 606 - COP Failure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at Idle			
3	Clear system fault	Does DTC 606 reset with engine idling?	Go to Step (4)	Go to Step (5)
4	Check all power and ground circuits to ECM	Are all circuits OK?	Go to Step (6)	Go to Step (7)
5	Fault is Intermittent			
6	Replace ECM with known good part and retest			
7	Repair wiring to ECM and retest			

DTC 616 - Start Relay Control Ground Short



Conditions for Setting the DTC

- Check Condition: Key on, Engine Cranking
- Fault Condition: Low side diagnostics non-adjustable or high side-feedback < 10% Vbat
- MIL: ON

Circuit Description


The ECM has auxiliary low-side drivers that can turn on warning devices or ground electromagnetic relay coils to control power to devices connected to the engine.

This fault sets if the output for the starter relay is detected as an open circuit. If this fault is active the starter motor will not receive power and will not engage.

DTC 616 - Start Relay Control Ground Short

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Cranking System Mode = "Cranking" Verify that DTC 616 is active			
3	Remove Starter Relay from fuse block/relay module Crank engine	Is DTC 616 active?	Go to Step (4)	Go to Step (5)
4	Key On, Engine Off System Mode – "Stopped" Using a DMM, measure the resistance from the starter relay output to ground	Is the resistance < 10 ohm?	Go to Step (6)	Go to Step (7)
5	Using a DMM, measure the voltage potential from the starter relay output to ground while the engine is trying to crank	Is voltage >80% of Vbat?	Go to Step (4)	Go to Step (8)
6	Key On, Engine Off Disconnect harness from ECM Using a DMM, measure the resistance from the starter relay output to ground	Is the resistance < 10 ohm?	Go to Step (9)	Go to Step (10)
7	Faulty Starter relay			
8	Faulty Starter relay			
9	Faulty wire harness (ground short)			
10	Faulty ECM			

DTC 642 - External 5 Volt 1 Reference Low



Conditions for Setting the DTC

- Check Condition: Engine cranking or running
- Fault Condition: 5 volt reference voltage lower than 4.60 volts
- MIL: ON during active fault
- Adaptive: Disabled during active fault


Circuit Description

The External 5 volt supply powers many of the sensors and other components of the fuel system. The accuracy of the 5 volt supply is very important to the accuracy of the powered sensors and fuel control by the ECM. The ECM is able to determine if they are overloaded, shorted, or otherwise out of specification by monitoring the 5 volt supply. This fault will set if the 5 volt reference is below 4.60 volts. Adaptive Learn will be disabled during this fault.

DTC 642 - External 5 Volt 1 Reference Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DTC display DTC 642?	Go to Step (3)	Go to Step (4)
3	-	Using DST, is 5Vext1 FB (VE5a_FB_raw) * 11/10 < 0.10 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent problem			
5	Wire connected to terminal # 19 at the ECM is partially or completely shorted to ground 5Vext is overloaded with too many sensors or faulty sensor			
6	5Vext is overloaded with too many sensors or faulty sensor Faulty ECM			

DTC 643 - External 5 Volt 1 Reference High



Conditions for Setting the DTC

- Check Condition: Engine cranking or running
- Fault Condition: 5 volt reference higher than 5.40 volts
- MIL: ON during active fault
- Adaptive: Disabled during active fault


Circuit Description

The External 5 volt supply powers many of the sensors and other components in the fuel system. The accuracy of the 5 volt supply is very important to the accuracy of the powered sensors and fuel control by the ECM. The ECM is able to determine if they are overloaded, shorted, or otherwise out of specification by monitoring the 5volt supply. This fault will set if the 5 volt reference is greater than 5.40 volts anytime the engine is cranking or running. Adaptive Learn will be disabled during this fault.

DTC 643 - External 5 Volt 1 Reference High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DTC display DTC 643?	Go to Step (3)	Go to Step (4)
3	-	Using DST, is 5Vext1 FB (VE5a_FB_raw) * 11/10 < 0.10 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent problem			
5	Wire connected to terminal # 19 at the ECM is partially or completely shorted to power (Vbat, Vsw, Vrelay, etc>)			
6	Poor ECM ground Faulty ECM			

DTC 652 - 5VE2 Low Voltage



Conditions for Setting the DTC

- Check Condition: Key On, Engine Off and Running
- Fault Condition: 5 volt reference higher than 5.42 volts
- MIL: ON during active fault
- Adaptive: Disabled during active fault

Circuit Description


The external 5-volt supply powers sensors and other components in the engine control system. The accuracy of this supply is critical to the accuracy of the sensors' feedback; therefore, it is supplied from a precision regulator whose output is internally monitored by the ECM. The ECM monitors the 5-volt supply to ratio metrically correct sensor feedback and determine if the circuit is overloaded, shorted, or otherwise out of specification.

This fault will set if the internally measured voltage feedback of the regulator output is lower than the low voltage limit as defined in the diagnostic calibration anytime the engine is running or stopped at key-on (if applicable).

DTC 652 - 5VE2 Low Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DST display DTC 652?	Go to Step (3)	Go to Step (4)
3	Using DST, is 5Vext2 FB ("VE5a_FB_raw") *11/10 < 0.10 VDC?		Go to Step (5)	Go to Step (6)
4	Intermittent problem			
5	Wire connected to terminal #TBD at the ECM is partially or completely shorted to ground 5Vext2 is overloaded with too many sensors or faulty sensor			
6	5Vet2 is overloaded with too many sensors or faulty sensor Faulty ECM			

DTC 653 - 5VE2 High Voltage



Conditions for Setting the DTC

- Check Condition: Key On, Engine Off and Running
- Fault Condition: 5 volt reference higher than 5.42 volts
- MIL: ON during active fault
- Adaptive: Disabled during active fault

Circuit Description


The external 5-volt supply powers sensors and other components in the engine control system. The accuracy of this supply is critical to the accuracy of the sensors' feedback; therefore, it is supplied from a precision regulator whose output is internally monitored by the ECM. The ECM monitors the 5-volt supply to ratio metrically correct sensor feedback and determine if the circuit is overloaded, shorted, or otherwise out of specification.

This fault will set if the internally measured voltage feedback of the regulator output is higher than the high voltage limit as defined in the diagnostic calibration anytime the engine is running or stopped at key-on (if applicable).

DTC 653 - 5VE2 High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running"	Does DST display DTC 653?	Go to Step (3)	Go to Step (4)
3	Using DST, is 5Vext2 FB ("VE5a_FB_raw") *11/10 > 5.20 VDC?		Go to Step (5)	Go to Step (6)
4	Intermittent problem			
5	Wire connected to terminal #TBD at the ECM is partially or completely shorted to power (Vbat, Vsw, Vrelay, etc).			
6	Poor ECM ground Faulty ECM			

DTC 685 - Relay Coil Open



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: Relay coil open

Circuit Description

The power relay switches power out to various sensors, actuators, and solenoids in the fuel system. This fault will set if the ECM detects an open circuit on the relay control output.


Diagnostic Aid

Relay coil resistance changes with temperature. The following diagnostic charts have steps to measure relay coil resistance values. When checking the resistance values be sure the relay is at a reasonable temperature, between +20- and +100-degrees F.

DTC 685 - Relay Coil Open

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Cranking System Mode = "Cranking" Verify that DTC 685 is active			
3	Remove Relay from fuse block/relay module Using a DMM, measure the voltage potential from the relay output to ground while the engine is trying to crank	Is voltage >80% of Vbat?	Go to Step (4)	Go to Step (5)
4	Key Off Connect test lamp to Vbat and Relay output Key On, Engine Off System Mode="Stopped" External power Test Mode="All On"	Does test lamp stay lit?	Go to Step (6)	Go to Step (7)
5	Faulty Relay			
6	Faulty Relay Faulty Relay connection/wiring			
7	Disconnect wire harness header from ECM Carefully remove yellow lock from header at device output terminal CAREFULLY check resistance between Relay output at ECM header and at relay. NOTE: DO NOT INSERT probe or object into terminals as this will cause the terminal to spread and may no longer make contact with ECM pins. Spread pins will void warranty! Probe on the side of terminal.	Does DMM indicate a resistance <5.0 ohms?	Go to Step (8)	Go to Step (9)
8	Faulty ECM			
9	Faulty harness (open-circuit)			

DTC 686 - Relay Control Ground Short



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: Relay control shorted to ground

Circuit Description

The power relay switches power out to various sensors, actuators and solenoids in the fuel system. This fault will set if the ECM detects a short to ground on the relay control output.


Diagnostic Aid

Relay coil resistance changes with temperature. The following diagnostic charts have steps to measure relay coil resistance values. When checking the resistance values be sure the relay is at a reasonable temperature, between +20- and +100-degrees F.

DTC 686 - Relay Control Ground Short

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped" If "Stopped Check" is enabled, verify the DTYC 686 is active			
3	Remove Relay from fuse block/relay module	Is DTC 686 active?	Go to Step (4)	Go to Step (5)
4	Key On, Engine Off System Mode="Stopped" Using a DMM, measure the voltage potential from the relay output to ground	Is the resistance <10 ohms?	Go to Step (8)	Go to Step (7)
5	External Power Test Mode="All On" Using a DMM, measure the voltage potential from the relay output to ground	Is voltage >80% of Vbat?	Go to Step (4)	Go to Step (6)
6	Faulty Relay			
7	Faulty Relay			
8	Key Off Disconnect harness from ECM Using a DMM, measure the resistance from the relay output to ground	Is the resistance <10 ohms?	Go to Step (9)	Go to Step (10)
9	Faulty harness (open-circuit)			
10	Faulty ECM			

DTC 687 - Relay Coil Short to Power



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: Relay coil shorted to power

Circuit Description

The power relay switches power out to various sensors, actuators, and solenoids in the fuel system. This fault will set if the ECM detects a short circuit to power on the relay control output.


Diagnostic Aid

Relay coil resistance changes with temperature. The following diagnostic charts have steps to measure relay coil resistance values. When checking the resistance values be sure the relay is at a reasonable temperature, between +20- and +100-degrees F.

DTC 687 - Relay Coil Short to Power

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off System Mode = "Stopped" If "Stopped Check" is enabled, verify the DTYC 687 is active			
3	Remove Relay from fuse block/relay module	Is DTC 687 active?	Go to Step (4)	Go to Step (5)
4	Key On, Engine Off System Mode="Stopped" Using a DMM, measure the voltage potential from the relay output to ground	Is the resistance <10 ohms?	Go to Step (8)	Go to Step (7)
5	External Power Test Mode="All On" Using a DMM, measure the voltage potential from the relay output to ground	Is voltage >80% of Vbat?	Go to Step (4)	Go to Step (6)
6	Faulty Relay			
7	Faulty Relay			
8	Key Off Disconnect harness from ECM Using a DMM, measure the resistance from the relay output to Vbat	Is the resistance <10 ohms?	Go to Step (9)	Go to Step (10)
9	Faulty harness (ground short)			
10	Faulty ECM			

DTC 726 - Max Govern Speed Override



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Engine rpm greater than 2,250 rpm
- Fault condition active for 2 or more seconds
- MIL: ON during active fault

Circuit description

This fault will set anytime the engine rpm exceeds 2,250 rpm for longer than 2 seconds. The MIL command is ON during this active fault.


Diagnostic Aid

Check for other stored DTC codes before using the following DTC chart for this code set. Always diagnose and repair any existing codes starting with the lowest numerical code first.

DTC 726 - Max Govern Speed Override

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF DST connected. Are any other DTC codes present with DTC 219?		Go to Step (3).	Go to Step (4)
3	Diagnose and repair any other DTC codes stored before proceeding with this chart. Have any other DTC codes been diagnosed and repaired?		Go to Step (4)	-
4	Check the service part number on the ECM to ensure the correct calibration is in use Is the Service Part Number Correct?		Go to Step (6)	Go to Step 5
5	Replace ECM with correct service part number Is the replacement complete?		Go to Step (9)	-
6	Check the mechanical operation of the throttle Is the mechanical operation of the throttle, OK?		Go to Step (8)	Go to Step (7)
7	Correct mechanical operation of the throttle. Refer to Engine & Component section. Has the mechanical operation of the throttle been corrected?		Go to Step (9)	-
8	Check engine for large manifold vacuum leaks. Refer to Symptom Diagnostic section. Did you find and correct the vacuum leak?		Go to Step (9)	Go to OBD System Check Section
9	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature. Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-219 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1020 - MFG Unable to Reach Higher TPS



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication.
- MIL: ON during active fault
- Engine shutdown



Fault Description

This fault will set after a latch period if the MFG throttle command is lower than the actual MFG throttle position as defined internally for longer than the defined threshold time.

Diagnostic Aid

- This fault is most often caused by a mechanical problem with the throttle. Testing the engine with a known good throttle or swapping the throttles side to side on a G-Drive engine and seeing if the problem moves are good ways to diagnose a stuck throttle.
- Replace MFG with known good unit and retest.

DTC 1022 - MFG Supply Voltage High



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Key on, Engine running
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set after a latch period if the internally measured voltage feedback of the MFG throttle is higher than the internally-defined high voltage limit anytime the engine is running or stopped at key-on (if applicable).


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1022 - MFG Supply Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine Running System Mode = "Running	Does DTC Display DTC?	Go to Step (3)	Go to Step (4)
3	Wire connected to terminal at the MFG is partially or completely shorted to power (Vbat, Vsw, Vrelay, etc.)			
4	Intermittent problem			

DTC 1023 - MFG Supply Voltage Low



Conditions for Setting the DTC

- Check Condition: Key on, Engine running
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set after a latch period if the internally measured voltage feedback of the MFG throttle is lower than the internally-defined low voltage limit anytime the engine is running or stopped at key-on (if applicable).



Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1023 - MFG Supply Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running	Does DTC Display DTC?	Go to Step (3)	Go to Step (4)
3	Wire connected to terminal at the MFG is partially or completely shorted to power (Vbat, Vsw, Vrelay, etc.) Faulty battery or battery connection Faulty MFG			
4	Intermittent problem			

DTC 1024 - MFG Fluid Temperature Voltage High



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid temperature sensor output voltage is higher than the internally defined high voltage limit.



Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1024 - MFG Fluid Temperature Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running Clear fault with DST and see if the fault resets.	Fault resets?	Go to Step (3)	Go to Step (4)
3	Intermittent Problem – unable to diagnose at this time			
4	Replace MFG and re-test			

DTC 1025 - MFG Fluid Temperature Voltage Low



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid temperature sensor output voltage is lower than the internally-defined low voltage limit.


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1025 - MFG Fluid Temperature Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running Clear fault with DST and see if the fault resets	Fault Resets	Go to Step (3)	Go to Step (4)
3	Replace MFG and retest			
4	Intermittent Problem-unable to diagnose at this time			

DTC 1026 - MFG Upstream Pressure Voltage High



Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid upstream pressure sensor output voltage is higher than the internally-defined high voltage limit.



Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1026 - MFG Upstream Pressure Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running Clear fault with DST and see if the fault resets	Fault Resets	Go to Step (3)	Go to Step (4)
3	Replace MFG and retest			
4	Intermittent Problem-unable to diagnose at this time			

DTC 1027 - MFG Upstream Pressure Voltage Low



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid upstream pressure sensor output voltage is lower than the internally-defined low voltage limit.



Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1027 - MFG Upstream Pressure Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running Clear fault with DST and see if the fault resets	Fault Resets	Go to Step (3)	Go to Step (4)
3	Replace MFG and retest			
4	Intermittent Problem-unable to diagnose at this time			

DTC 1028 - MFG Downstream Pressure Voltage High



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid downstream pressure sensor output voltage is higher than the internally-defined high voltage limit.


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1028 - MFG Downstream Pressure Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running Clear fault with DST and see if the fault resets	Fault Resets	Go to Step (3)	Go to Step (4)
3	Replace MFG and retest			
4	Intermittent Problem-unable to diagnose at this time			

DTC 1029 - MFG Downstream Pressure Voltage Low



Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid downstream pressure sensor output voltage is lower than the internally-defined lower voltage limit.


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 1029 - MFG Downstream Pressure Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running Clear fault with DST and see if the fault resets	Fault Resets	Go to Step (3)	Go to Step (4)
3	Replace MFG and retest			
4	Intermittent Problem-unable to diagnose at this time			

DTC 1111 - Fuel Rev Limit



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Engine rpm greater than 2300rpm set limit
- MIL: ON during active fault

Circuit Description

This fault will set anytime the engine rpm exceeds the specified speed settings in the calibration. This is generally set at 2300 rpm. The MIL command is ON during this active fault.


Diagnostic Aid

Always check for other stored DTC codes before using the following DTC chart for this code set. Repair any existing codes starting with the lowest numerical code first.

DTC 1111 - Fuel Rev Limit

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF DST in Active Fault Mode Are any other DTC codes present with DTC 1111?		Go to Step (3)	Go to Step (4)
3	Diagnose and repair any other DTC codes before proceeding with this chart. Have any other DTC codes been diagnosed and repaired?		Go to Step (4)	-
4	Check the service part number on the ECM to ensure correct calibration is in use Is the service part number correct?		Go to Step (6)	Go to Step 5
5	Replace ECM with the correct service part number Is the replacement complete?		Go to Step (9)	-
6	Check the mechanical operation of the throttle Is the mechanical operation of the throttle OK?		Go to Step (8)	Go to Step (7)
7	Correct mechanical operation of the throttle. Refer to Engine & Component section Has the mechanical operation of the throttle been corrected?		Go to Step (9)	-
8	Check engine for large manifold vacuum leaks. Refer to Fuel Systems symptom diagnostics Did you find and correct the vacuum leaks?		Go to Step (9)	Go to OBD System Check Section
9	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature. Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-1111 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1112 - Spark Rev Limit



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: Engine rpm greater than 2325 rpm set limit
- MIL: ON during active fault
- Engine Shut Down

Circuit description

This fault will set anytime the engine rpm exceeds the specified speed settings installed in the calibration. This is set at 2325 rpm. The MIL command is ON during this active fault and the engine will shut down.


Diagnostic Aid

Always check for other stored DTC codes before using the following DTC chart for this code set. Repair any existing codes starting with the lowest numerical code first.

DTC 1112 - Spark Rev Limit

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF DST connected Are any other DTC codes present with DTC 1112?		Go to Step (3)	Go to Step (4)
3	Diagnose any other DTC codes before proceeding with this chart. Have any other DTC codes been diagnosed and repaired?		Go to Step (4)	-
4	Check the service part number on the ECM to ensure correct calibration is in use Is the service part number correct?		Go to Step (6)	Go to Step (5)
5	Replace ECM with correct service part number Is the replacement complete?		Go to Step (9)	-
6	Check the mechanical operation of the throttle Is the mechanical operation of the throttle OK?		Go to Step (8)	Go to Step (7)
7	Correct mechanical operation of the throttle. Refer to Engine & Component section Has the mechanical operation of the throttle been corrected?		Go to Step (9)	-
8	Check engine for large manifold vacuum leaks. Refer to Fuel Systems section Symptom Diagnostics Did you find and correct the vacuum leak?		Go to Step (9)	Go to OBD System Check Section
9	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-1112 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1113 - RPM Higher Than Expected



Conditions for Setting the DTC

- Check Condition: Engine running/Stopped Checked
- Fault Condition: Engine rpm >2550
- MIL: ON during active fault
- Engine Shut Down

Circuit description

The crankshaft position sensor is a magnetic sensor (variable reluctant/magnetic pick-up or hall-effect) installed in the engine block adjacent to a “coded” trigger wheel located on the crankshaft. The sensor-trigger wheel combination is used to determine crankshaft position (with respect to TDC cylinder #1 compression) and the rotational engine speed. Determination of the crankshaft position and speed is necessary to properly activate the ignition, fuel injection, and throttle governing systems for precise engine control.

This fault will set anytime the engine RPM exceeds the entry condition rpm limit set in the diagnostic calibration for the latch time or more. This fault is designed to help prevent engine or equipment damage. The throttle will be closed in order to govern the engine to the speed set in the diagnostic calibration for **Max Gov Override**.

Diagnostic Aid

NOTE: If any other DTCs are present, diagnose those first.


- Ensure that no programmed governor speeds exceed the entry condition rpm value set in the diagnostic calibration.
- Verify the crank position sensor is reading properly.
- Perform Drive by Wire test to verify proper throttle performance
- Check mechanical operation of the throttle
- Check the engine intake for large air leaks downstream of the throttle body

UEGO Sensor Details

PSI HD Engines use a wide band (UEGO) Sensor in the pre-catalyst location ("EGO 1"). This is a 6 pin sensor which is installed ahead of the catalyst. In V-Series engines there is one UEGO for each bank (Primary Bank and Secondary Bank have their own UEGO sensor before the catalyst).



Sensor Operation

- **Current Pump Technology:**
 - Unlike traditional oxygen sensors (1, 2, or 4-wire types) that output a voltage signal, the UEGO sensor uses a "current pump" to determine oxygen concentration or demand.
 - The sensor internally measures the oxygen concentration in the exhaust gas or calculates the amount of oxygen required to achieve stoichiometric combustion.
- **Signal Output:**
 - The sensor outputs a small current proportional to the air-fuel ratio:
 - **$\Phi < 1$** : Lean condition (excess oxygen in the exhaust).
 - **$\Phi = 1$** : Stoichiometric operation.
 - **$\Phi > 1$** : Rich condition (excess fuel in the exhaust).
 - This design enables the measurement of exact air-fuel ratios across the entire operating range, which traditional sensors cannot achieve.




UEGO Sensor and Fuel Trim Diagnostics

UEGO Data is viewed on HD Service Page “UEGO 1 Phi”



When viewing UEGO 1 Phi on a plot file set your plot to **“Average”** to show the average Phi over time

DTC 1151 - Closed Loop High LPG



Conditions for Setting the DTC

- Check Condition-Engine running
- Fault Condition-Closed Loop multiplier out of range (greater than 35%) while running on propane
- MIL-ON

Circuit description

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and the adaptive multiplier. This fault sets if the Closed Loop multiplier exceeds the limits of normal operation and cannot correctly modify the fuel flow within its limits.

Diagnostic Aid

Vacuum Leaks - Large vacuum leaks and crankcase leaks can cause a lean exhaust condition at especially at light load.

Fuel Mixer - System can be lean due to faulty EPR (Electronic Pressure Regulator) or faulty fuel mixer. **Fuel**

Pressure - System will be lean if fuel pressure is too low. Ensure fuel pressure is not too low and that gaseous fuel control actuator/regulator has proper fuel pressure under all operating conditions. Ensure proper coolant flow to LP vaporizer.

Exhaust Leaks - If there is an exhaust leak, outside air can be pulled into the exhaust and past the O2 sensor causing a false lean condition.

Misfire - A misfiring cylinder will pass oxygen through rather than burning it. The sensor will interpret this oxygen as a lean condition and enrichen the fuel mixture.


Fuel Quality - A drastic variation in fuel quality may cause the system to be lean.

Ground Problem - ECM and engine must be grounded to the battery with very little resistance allowing for proper current flow. Faulty grounds can cause current supply issues resulting in many undesired problems.

Oxygen Sensor Wire - Sensor may be mispositioned contacting the exhaust. Check for short to ground between harness and sensor sense signal.

If all tests are OK, replace the O2 sensors with known good parts and retest.

DTC 1152 - Closed Loop Multiplier Low LPG



Conditions for Setting the DTC

- Functional Fault: Closed Loop multiplier out of range (at limit of -35%) while running on propane
- MIL Disabled

Circuit Description

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and the adaptive multiplier. This fault sets if the Closed Loop multiplier exceeds the limits of normal operation. When the multiplier cannot correctly modify the fuel flow within its limits, it is limited at -35%.

Diagnostic Aid

Fuel System High secondary fuel pressure will cause the system to run rich. A worn fuel mixer or faulty EPR (Electronic Pressure Regulator) may also cause the system to run rich.


Fuel Quality A drastic variation in fuel quality (very high butane content) may cause the fuel system to run rich. Be sure that the specified HD-5 or HD-10 motor fuel grade LPG is used.

Air Filter A plugged, damaged or modified air filter may cause the system to run rich.

Note:

- If one bank shows high adaptive and the other is low, the O₂ sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

DTC 1153 - Closed Loop Multiplier High NG



Conditions for Setting the DTC

- Functional Fault: Closed Loop multiplier out of range (greater than 35%) while running on natural gas
- MIL: Disabled

Circuit Description

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and the adaptive multiplier. This fault sets if the Closed Loop multiplier exceeds the limits of normal operation and cannot correctly modify the fuel flow within its limits.

Diagnostic Aid

Vacuum Leaks Large vacuum leaks and crankcase leaks can cause a lean exhaust condition, especially at light load.

Fuel Mixer System can be lean due to a faulty EPR (Electronic Pressure Regulator) or faulty fuel mixer. **Fuel Pressure** System will be lean if fuel pressure is too low. Ensure fuel pressure is not too low and that gaseous fuel control actuator/regulator has proper fuel pressure under all operating conditions.

Exhaust Leaks If there is an exhaust leak, outside air can be pulled into the exhaust and past the O2 sensor causing a false lean condition.

Misfire A misfiring cylinder will pass oxygen through rather than burning it. The sensor will interpret this oxygen as a lean condition and enrichen the fuel mixture.

Fuel Quality A drastic variation in fuel quality may cause the system to be lean.

Ground Problem ECM and engine must be grounded to the battery with very little resistance allowing for proper current flow. Faulty grounds can cause current supply issues resulting in many undesired problems.


Oxygen Sensor Wire Sensor may be mispositioned contacting the exhaust. Check for short to ground between harness and sensor sense signal.

If all tests are OK, replace the O2 sensors with known good parts and retest.

Note:

- If one bank shows high adaptive and the other is low, the O2 sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

DTC 1154 - Closed Loop Multiplier Low NG



Conditions for Setting the DTC

- Functional Fault: Closed Loop multiplier out of range (at limit of -35%) while running on natural gas
- MIL: Disabled

Circuit Description

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and the adaptive multiplier. This fault sets if the Closed Loop multiplier exceeds the limits of normal operation. When the multiplier cannot correctly modify the fuel flow within its limits, it is limited at -35%.

Diagnostic Aid


Fuel System High secondary fuel pressure will cause the system to run rich. A worn fuel mixer, faulty EPR (Electronic Pressure Regulator) may also cause the system to run rich.

Fuel Quality A drastic variation in fuel quality (high content of ethane and heavier hydrocarbons) may cause the fuel system to run rich. If running on wellhead gas, obtain a current gas analysis report for your fuel source. Wells can change over time and the gas supply may be different than when a sample was originally taken. Air Filter A plugged, damaged or modified air filter may cause the system to run rich.

Note:

- If one bank shows high adaptive and the other is low, the O₂ sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

DTC 1161 - Adaptive Learn High LPG



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Adaptive multiplier out of range greater than 30% while running on propane
- MIL: ON

Circuit Description

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and Adaptive multiplier. This fault will set if the adaptive multiplier exceeds the limits of normal operation. Always run the fuel system diagnostic checks before using the following diagnostic chat.

Diagnostic Aid

Oxygen Sensor Wire - Oxygen sensor wires may be mis-routed and contacting the exhaust manifold, pipes, or other hot parts causing damage.

Vacuum Leaks - Large vacuum leaks and crankcase leaks can cause a lean exhaust condition at especially at light load.

Fuel Mixer - System can be lean due to faulty EPR (Electronic Pressure Regulator) or faulty fuel mixer.

Fuel Pressure - Low fuel pressure, faulty fuel regulator or contaminated fuel filter can cause fuel the system to run lean

Exhaust Leaks - If there is an exhaust leak, outside air can be pulled into the exhaust and past the O2 sensor causing a false lean condition.


Fuel Quality - Contaminated or spoiled fuel can cause the fuel system to be lean.

Ground Problem - ECM grounds must be clean, tight and in the proper location.

Note:

- If one bank shows high adaptive and the other is low, the O2 sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

DTC 1162 - Adaptive Learn Low LPG



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: Adaptive multiplier out of range greater than -30% while running on propane
- MIL: ON

Circuit Description

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and Adaptive multiplier. This fault will set if the adaptive multiplier exceeds the limits of normal operation. Always run the fuel system diagnostics before using the following diagnostic chart.

Diagnostic Aid

Fuel System - High secondary fuel pressure will cause the system to run rich. A worn fuel mixer, faulty EPR (Electronic Pressure Regulator) may also cause the system to run rich.

Fuel Quality - A drastic variation in fuel quality (very high butane content) may cause the fuel system to run rich. Be sure that the specified HD-5 or HD-10 motor fuel grade propane is used.

Air Filter - A plugged, damaged or modified air filter may cause the system to run rich.

Note:

- If one bank shows high adaptive and the other is low, the O2 sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

The diagram illustrates the wiring between a UEGO sensor and an ECM. The UEGO sensor has six pins: 6 (SENSE CELL), 2 (PUMP/SENSE RETURN), 1 (PUMP CONTROL), 5 (TRIM RESISTOR), 3 (HEATER CONTROL), and 4 (HEATER). The ECM has five pins: 46 (UEGOS), 51 (UEGOC), 50 (UEGOP), 52 (UEGOR), and 63 (HEATER CONTROL). The UEGO controller is connected to UEGOS, UEGOC, and UEGOP. The MICRO CONTROLLER is connected to UEGOR, UEGOH (Heater Feedback), and the HEATER. A common ground is shown at the bottom, connected to the ECM and the heater circuit. A line labeled 'TO SYSTEM POWER RELAY' is connected to pin 4 of the heater.


- Check Condition: Engine Running
- Fault Condition: Adaptive multiplier out of range greater than 30% while running on natural gas
- MIL: ON

The UEGO sensor is used to determine if the fuel flow to the engine is correct by measuring the oxygen content in the exhaust gas. The ECM uses this information to correct the fuel flow with the Closed Loop multiplier and Adaptive multiplier. This fault will set if the adaptive multiplier exceeds the limits of normal operation. Always run the fuel system diagnostic checks before using the following diagnostic chat.

Ground Problem - ECM grounds must be clean, tight and in the proper location.

- If one bank shows high adaptive and the other is low, the O2 sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

DTC 1164 - Adaptive Learn Low NG



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: Adaptive multiplier out of range greater than -30% while running on natural gas
- MIL: ON

Circuit Description

DTC 1164 triggers when the Adaptive Multiplier falls below the low limit of normal operation, indicating that the engine is operating **rich** (excess fuel). This occurs when less fuel than expected is required for correction, often due to high fuel supply pressure or sensor-related issues. The fault disables the Adaptive Learn function for the key cycle to prevent improper learning of fuel control adjustments.

Diagnostic Aid

Fuel System - High secondary fuel pressure will cause the system to run rich. A worn fuel mixer, faulty EPR (Electronic Pressure Regulator) may also cause the system to run rich.

Fuel Quality - A drastic variation in fuel quality (very high butane content) may cause the fuel system to run rich. Be sure that the specified HD-5 or HD-10 fuel grade propane is used.

Air Filter - A plugged, damaged or modified air filter may cause the system to run rich.

Note: If one bank shows high adaptive and the other is low, the O2 sensor leads are crossed. Trace those wires back to their ECM's are correct accordingly.

Oxygen Sensor (HEGO/UEGO) Issues:

- Faulty or mispositioned sensor providing incorrect air-fuel ratio data.
- Sensor wire shorted to ground or damaged in the harness.

Fuel Delivery Issues:

- High Fuel Pressure: Excessive fuel pressure caused by a failing gaseous control actuator, valve, or regulator.

- Faulty pressure control system unable to regulate fuel delivery under varying engine loads.


Fuel Quality (Wellhead Gas Concerns):

- Engines operating on wellhead gas or other non-standard fuels with high inert gas content or inconsistent energy density can experience over-rich conditions.
- Wellhead gas impurities, including heavy hydrocarbons, moisture, or sulfur, may alter combustion dynamics, requiring corrective action such as a fuel derate or switching to a cleaner fuel source.

Worn or Malfunctioning Fuel Mixer Hardware:

- A degraded or worn gaseous fuel mixer may deliver excess fuel due to poor metering or improper functionality.

DTC 1171 - EPR Pressure Higher Than Expected



Conditions for Setting the DTC

- Check condition: Engine running or cranking
- MIL: ON during active fault
- Fault condition: EPR actual pressure greater than 1.5 inches above commanded pressure
- Adaptive disabled
- Engine shutdown will occur

Circuit Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This code will set in the event the actual pressure is 1.5 inches water pressure higher than the actual commanded pressure. Adaptive learn is disabled and the MIL command is ON during this fault. The engine will shut down if this fault occurs.


Diagnostic Aid

Always run the fuel system diagnostic pressure check before proceeding with the following diagnostic chart.
High fuel pressure into the EPR is the most common cause of this fault.

DTC 1171 - EPR Pressure Higher Than Expected

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Did you run the fuel pressure diagnostic test in the fuel system diagnostic section with no problems found?		Go to Step (4)	Go to Step (3)
3	Run the EPR pressure test in the fuel system diagnostic section Did the EPR pass the fuel pressure test specifications?		Go to Step (4)	Follow the EPR service recommendations from the fuel pressure test chart.
4	Inspect the EPR electrical connector pins C018 for damage, corrosion, or contamination. Did you find a problem?		Repair the circuit as necessary. Refer to wire harness repair section.	Go to Step (5)
5	Replace or repair the EPR Is the replacement complete?		Go to Step (6)	-
6	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature. Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC1171 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1172 - EPR Pressure Lower Than Expected



Conditions for Setting the DTC

- Check condition: Engine running or cranking
- MIL: ON during active fault
- Fault condition: EPR actual pressure less than 1.5 inches below commanded pressure
- Adaptive disabled
- Engine shutdown will occur

Circuit Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This code will set in the event the actual pressure is 1.0 inches water pressure lower than the actual commanded pressure. Adaptive is disabled and the MIL command is ON during this fault. Engine will shut down if this fault occurs.

Diagnostic Aid


Low fuel pressure into the EPR is the most common cause of this fault. Improper operation of the fuel lock off is also a common cause, which can restrict or limit flow.

The required fuel pressure at the EPR is 7 to 11 Inches of Water Column under all load conditions.

DTC 1172 - EPR Pressure Lower Than Expected

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Did you run the fuel pressure diagnostic test in the fuel system diagnostic section with no problems found?	-	Go to Step (4)	Go to Step (3)
3	Measure fuel pressure upstream of the lock-off valve . Does the fuel supply meet specifications?	Greater than 7 in. H ₂ O	Go to Step (4)	Inspect upstream fuel components (e.g., fuel delivery line, regulator) for restrictions. Repair as needed or adjust regulator to increase pressure.
4	Measure fuel pressure downstream of the lock-off valve (before the EPR) . Does the fuel pressure meet specifications?	7-11 in. H ₂ O	Go to Step (5)	Inspect the lock-off valve for restriction or malfunction. Repair or replace as necessary.
5	Inspect the EPR electrical connector pins (C018) for damage, corrosion, or contamination. Did you find a problem?	-	Repair the circuit as necessary. Refer to wire harness repair section.	Go to Step (6)
6	Replace or repair the EPR as required. Is the replacement or repair complete?		Go to Step (7)	Replace the EPR and retest the system.
7	Remove all test equipment and reconnect components. Clear DTC information using the diagnostic tool. Start the engine and operate it to full operating temperature. Observe the MIL and drivability. Are there any stored codes?	No codes	System OK	Repeat the diagnostic process or escalate for further analysis.

DTC 1173 - EPR/CFV Comm Lost



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: ECU received no communication from EPR for .500 ms
- MIL: ON during active fault
- Engine power derate 1
- Adaptive Disabled

Fault Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This fault sets if the ECM loses CAN communication with the EPR. The fault indicates that the ECM is no longer receiving CAN packets from the EPR which also results in the EPR not receiving communication from the ECM. This is often the result of a power loss at the EPR or improper CAN termination or wiring. The MIL will light, and the engine will shut down.


DTC 1173 - EPR/CFV Comm Lost

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Mode = "Running" Attempt to connect to ECM with CAN-based DST Clear fault with DST and see if the fault resets	DST connects to ECM?	Go to Step (3)	Go to Step (4)
3	Clear DTC 1173 Fault	Fault resets?	Go to Step (5)	Go to Step (6)
4	Key OFF, Engine Stopped System Mode = "Stopped" Disconnect ECM header connection Carefully remove yellow lock from ECM harness side header Using a multimeter, check continuity between diagnostic connector pin 7 and ECM pin 14 and between connector pin 8 and ECM pin 15 on the harness	Harness connector is good?	Go to Step (7)	Go to Step (8)
5	Key OFF, Engine Stopped System Mode = "Stopped" Disconnect EPR/CFV harness connection Carefully remove locks on the harness side of the EPR/CFV connection Using a multimeter Check harness continuity of CAN+ wire between EPR Pin 2/CFV Pin 2 and ECM pin 14 (CAN1) or Pin17 (CAN2) Check harness continuity of CAN- wire between EPR Pin 5/CFV Pin 3 and ECM pin 15 (CAN1) or Pin 16 (CAN2)	Harness continuity is good?	Go to Step (9)	Go to Step (10)
6	Intermittent problem			
7	Using a multimeter, check resistance between ECM pin 14 and ECM pin 15 on the harness	Resistance is between 115 and 135 ohms?	Go to Step (11)	Go to Step (12)
8	Faulty harness			

Step	Action	Value(s)	Yes	No
9	Key OFF, Engine Stopped System Mode = "Stopped" Enable "External Power" test to "All On" Using a multimeter, measure voltage (Vrelay) and (Vbat) relative to (GND)	Vbat and Vrelay both >18V?	Go to Step (13)	Go to Step (14)
10	Faulty Harness			
11	Faulty ECM			
12	Faulty harness or faulty CAN termination			
13	Faulty EPR/CFV			
14	Faulty harness or relay Troubleshoot Vbat and Vrelay circuits			

NOTE Do not insert probe or object into terminals as this will cause the terminal to spread and it may no longer make electrical contact with its mate. Spread pins will void warranty. Probe instead on side of terminal.

DTC 1174 - EPR/CFV Voltage Supply High




Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Voltage supply to EPR/CFV is >VDC exceeds 33.0 VDC for greater than 3 seconds.
- MIL: ON during active fault
- Engine power derate 1
- Adaptive Disabled

Fault Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This fault sets if the ECM loses CAN communication with the EPR. The fault indicates that the ECM is no longer receiving CAN packets from the EPR which also results in the EPR not receiving communication from the ECM. This is often the result of a power loss at the EPR or improper CAN termination or wiring. The MIL will light, and the engine will shut down.

DTC 1175 - EPR/CFV Voltage Supply Low




Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Voltage supply to EPR/CFV is <VDC below 18.0 VDC for > 5 seconds while engine RPM > 1000.
- MIL: ON during active fault
- Adaptive Disabled

Fault Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This fault sets if the ECM loses CAN communication with the EPR. The fault indicates that the ECM is no longer receiving CAN packets from the EPR which also results in the EPR not receiving communication from the ECM. This is often the result of a power loss at the EPR or improper CAN termination or wiring. The MIL will light, and the engine will shut down.

DTC 1176 - EPR/CFV Internal Actuator Fault Detection




Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: EPR detects an internal actuator fault
- MIL: ON during active fault
- Adaptive Disabled

Fault Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This fault sets if the EPR detects an internal actuator fault. The fault is transmitted from the EPR to the ECM via CAN. If the fault is active, adaptive learn is disabled to prevent improper learning and updating of the table. The MIL is illuminated for the duration of the key-on cycle. If the EPR does not trigger either 1171 or 1172 there is no issue with the EPR. If one or more of these faults are triggered, refer to the appropriate section for diagnostic information.

DTC 1177 - EPR/CFV Internal Circuitry Fault Detection



Conditions for Setting the DTC


- Check Condition: Key On
- Fault Condition: EPR detects an internal circuitry fault
- MIL: ON during active fault
- Adaptive Disabled

Fault Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This fault sets if the EPR detects an internal circuitry fault. The fault is transmitted from the EPR to the ECM via CAN. If the fault is active, adaptive learn is disabled to prevent improper learning and updating of the table. The MIL is illuminated for the duration of the key-on cycle.

If the EPR does not trigger either 1171 or 1172 there is no issue with the EPR. If one or more of these faults are triggered, refer to the appropriate section for diagnostic information.

DTC 1178 - EPR/CFV Internal Comm Fault Detection




Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: Internal comm fault detected
- MIL: ON during active fault
- Adaptive Disabled

Fault Description

This fault sets if the EPR/CFV detects a loss of CAN communication with the ECM. The ECM is configured to illuminate the MIL, disable closed loop fueling correction and adaptive fueling correction, and initiate a Power Derate 1 condition to prevent possible damage to the engine.

DTC 1271 - EPR Secondary Regulation Pressure Higher Than Expected



Conditions for Setting the DTC

- Check condition: Engine running or cranking
- MIL: ON during active fault
- Fault condition: EPR or CFV (actual-command) pressure greater than 10.00 PSI
- Engine shutdown will occur

Circuit Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This code will set in the event the actual pressure is 10.00 psi inches water pressure higher than the actual commanded pressure. MIL command is ON during this fault. The engine will shut down if this fault occurs.


Diagnostic Aid

Always run the fuel system diagnostic pressure check before proceeding with the following diagnostic chart. **High fuel pressure into the EPR is the most common cause of this fault.**

DTC 1271 - EPR Secondary Regulation Pressure Higher Than Expected

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Did you run the fuel pressure diagnostic test in the fuel system diagnostic section with no problems found?		Go to Step (4)	Go to Step (3)
3	Run the EPR pressure test in the fuel system diagnostic section Did the EPR pass the fuel pressure test specifications?		Go to Step (4)	Follow the EPR service recommendations from the fuel pressure test chart.
4	Inspect the EPR electrical connector pins C018 for damage, corrosion, or contamination. Did you find a problem?		Repair the circuit as necessary. Refer to wire harness repair section.	Go to Step (5)
5	Replace or repair the EPR Is the replacement complete?		Go to Step (6)	-
6	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature. Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC1171 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1272 - EPR Secondary Regulation Pressure Lower Than Expected



Conditions for Setting the DTC

- Check condition: Engine running or cranking
- MIL: ON during active fault
- Fault condition: EPR or CFV (actual-command) pressure greater than 10.00 PSI
- Engine shutdown will occur

Circuit Description

The EPR (Electronic Pressure Regulator) unit measures and controls the amount of fuel that is able to pass to the fuel mixer. This code will set in the event the actual pressure is -10.00 inches water pressure lower than the actual commanded pressure. MIL command is ON during this fault. Engine will shut down if this fault occurs.


Diagnostic Aid

Always run the fuel system diagnostic pressure check before proceeding with the following diagnostic chart. **High fuel pressure into the EPR is the most common cause of this fault.**

DTC 1172 - EPR Secondary Regulation Pressure Lower Than Expected

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Did you run the fuel pressure diagnostic test in the fuel system diagnostic section with no problems found?		Go to Step (4)	Go to Step (3)
3	Run the EPR pressure test in the fuel system diagnostic section. Did the EPR pass the fuel pressure test specifications?		Go to Step (4)	Follow the EPR service recommendations from the fuel pressure test chart.
4	Inspect the EPR electrical connector C018 for damage, corrosion, or contamination. Did you find a problem?		Repair the circuit as necessary. Refer to wire harness repair section.	Go to Step (5)
5	Replace or repair the EPR Is the replacement complete?		Go to Step (6)	-
6	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature. Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC1172 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1325 - Knock Retard at Limit



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: With RPM greater than 1200 and MAP load greater than 11 psia, knock retard is at 100% for 125 combustion cycles (1 cycle = 2 revs, 8.3 seconds at 1800 RPM, 10 seconds at 1500 RPM)
- MIL: ON during active fault
- Engine Shutdown

Fault Description

The knock sensor is used to detect detonation through mechanical vibration in the engine block and/or cylinder heads and provide feedback for the ignition system to retard spark timing to reduce knock intensity. In most applications the knock sensor is used to protect the engine from damage that can be caused from detonation or knock based on fixed spark advance. This fault sets if the signals from the knock sensors indicate severe engine knocking, triggering maximum knock retard for 125 combustion cycles (one cycle = two crank rotations). The MIL will light and the engine will shut down.

Diagnostic Aids

This fault occurs when the engine is actively knocking, and the shutdown is triggered to protect the engine from potentially catastrophic damage. Knock can be caused by a number of factors, including:

- Poor quality fuel
- Elevated intake air temperature
- Elevated coolant temperature
- Loads exceeding engine load limit
- Excessive exhaust backpressure

If running on wellhead gas, a gas analysis sample should be taken to check the makeup of the wellhead gas. Wellhead gas can vary greatly in quality, even from the same well over time. It is important to reduce the load when running on "hot" gas (gas containing a higher than usual concentration of ethane and larger hydrocarbons) in order to keep cylinder pressures down below the threshold where knock can occur. Contact your OEM for more information on running an engine on wellhead gas.

DTC 1325 - Knock Retard at Limit

Verify that the engine is running at the proper load for your application at all times. Make sure that any required derates* for elevation, ambient temperature, and gas quality are applied to the maximum load. Verify all loads to be certain there isn't a situation that can cause load to suddenly spike above the limit, e.g. motors starting simultaneously. Consider using VFDs (Variable Frequency Drivers) if there are cumulative inrush currents that could be overloading your engine.

Higher intake and coolant temperatures and excessive exhaust back pressure can lead to higher in-cylinder temperatures, which will contribute to the likelihood of knock.


- Make sure the engine is receiving intake air that is as cool as possible. Elevated intake air temperatures can be caused by exhaust leaks near the intake, blocked or closed intake louvers on an enclosure, or air circulating over hot engine components.
- The cooling system should also be checked. Clogged radiator/CAC cores, low coolant level, loose, slipping, or broken fan and/or water pump belts can all lead to elevated engine coolant temperatures.
- Check the exhaust system for proper flow. Make sure there are no obstructions in the piping, catalysts, or muffler (if equipped).

If the engine is thoroughly inspected and found to not be experiencing any knock, there are other factors that can sometimes cause the knock sensors to detect vibrations that the ECM will interpret as knock:

- Check the engine and all attached components for any loose nuts, bolts, or brackets that could be vibrating.
- Check to make sure there is nothing coming in contact with any of the knock sensors.
- Verify that the knock sensors are properly secured to the engine and the nut/bolt is correctly torqued:
 Nut: 18 lb/ft
 Bolt: 20 lb/ft
- Check the spark plugs, ignition coils, and coil boots on all cylinders to make sure the ignition system is performing properly and there is no misfire. Make sure spark plugs are the correct type as recommended by the manufacturer.
- Check and adjust engine valve lash as necessary. Loose valve lash can cause vibrations in the engine that is picked up by the knock sensors and could be interpreted by the ECM as knock.

*For information on derates consult PSI Heavy-Duty Technical Standard 56300003 - PSI HD Derate Specification.

DTC 1326 - Knock Retard Above Threshold



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running / Stopped Checked
- Fault Condition: With RPM greater than 1000 and MAP load greater than 8 psia, and ECT >- 40.0 deg F, and engine run time > 120.0 sec, and knock spark retard at percent of maximum 50%, and octane rating <=100%
- MIL: ON during active fault

Fault Description

The knock sensor is used to detect detonation through mechanical vibration in the engine block and/or cylinder heads and provide feedback for the ignition system to retard spark to reduce knock intensity. In most applications the knock sensor is used to protect the engine from damage that can be caused from detonation or knock based on fixed spark advance. In other applications, the knock sensor is used to optimize spark advance and “learn” between spark tables based on fuel quality.

This fault sets when the engine is retarding the ignition timing due to knock. If the amount of retard is above the percentage of the maximum retard (without consideration of ‘active knock’– see Knock Retard at Limit fault description) the fault will be set.

See Diagnostic Information for DTC 1325

Diagnostic Aids:

- If other DTCs exist diagnose these first.
- Refer to the engine manufacturer’s service manual for additional information.

DTC 1330 - Intake Backfire Detected

Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: Intake backfires ≥ 4 events
- MIL: ON
- Adaptive: Disabled during active fault

Fault description

The ECM detects IAT readings which may indicate an intake backfire. This may be caused by improper fuel-air mixtures, worn ignition components, improper valve lash settings, engine timing and possibly bad sensors.

The DTC is set to trigger an event based off of any change in IAT¹ greater than 25 deg F/sec greater than 20ms. Once an event is counted, it will be stored in a histogram visible on the “Service” page in 4G Display. The diagnostic is set around these event counts within a timeframe.

¹*This is a calculated IATdt which is a filtered signal. You cannot directly relate this to IAT or rIAT in a bplt for 1:1 visual if it will trigger.*

Diagnostic Aids

- Capture **ALL fault code history** in MASTER and SLAVE ECM's
- Download **ALL fault code flight data recorders** from MASTER and SLAVE ECM's
- Download **ALL fault snapshot** from MASTER and SLAVE ECM's
- Download **Backfire Histogram** from MASTER and SLAVE ECM's (located on Service page)
- **Inspect spark plugs for water ingress/corrosion** from the top side (coil side)
- **Ignition coil wire harness inspection** (closely looking at pin conditions)

Below is a list of issues that may indicate a backfire event has occurred.

- Damaged or melted MAP sensor
- DTC 111 (IAT Higher than Expected 1)
- DTC 127 (IAT Higher than Expected 2)
- DTC 112 (IAT Voltage Low)

DTC 1330 - Intake Backfire Detected

EDIS ECI Target Communications

File Page Flash Comm Port Plot/Log Settings Help

EControls

Service
Not Connected

MIL

← → ↺

REC

Error opening ECom module in HandleConnect, (error code 251)

No No No No

Hour Last Commit 0.000 Hour Hst 1 0.000 Hour Hst 2 0.000

Intake Backfire Monitoring

Intake backfire detection mode: Disabled ▼

Intake backfire IATdt limit: 0.0 deg F/sec

Intake backfire MAP limit: 0.0 psia

Intake backfire latch time: 0 ms

Intake backfire unlatch time: 0 ms

IATdt: 0.0 deg F/sec

IATdt max (key cycle): 0.0 deg F/sec

Intake Backfire Histogram (Lifetime)

MAP load (psia)

Speed (rpm)	0.0	0.0	0.0	0.0	0.0	0.0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0

Intake Backfire Occurrences

Total intake backfires (lifetime): 0 occurrences

Intake Backfire Histogram (Recent)

MAP load (psia)

Speed (rpm)	0.0	0.0	0.0	0.0	0.0	0.0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0
0	0	0	0	0	0	0

Intake Backfire Occurrences

Total intake backfires (recent): 0 occurrences

Cumulative time since reset: 0.000 hours

Intake backfire action request: Press to select action... ▼

Intake Backfire Events (Recent)

Time (hours)	Occurrences
0	0
0	0
0	0
0	0


DTC 1330 - Intake Backfire Detected

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	<p>When did the backfire occur (date, time, engine hours)?</p> <p>What conditions did the backfire occur in (engine starting, load step, etc)</p> <p>Was the backfire through the intake or exhaust?</p> <p>Did the backfire occur on the master or slave side of the engine (right or left)?</p> <p>Are any fault codes active or historic in the master AND slave ECM?</p> <p>Download all fault snapshots and flight data recorder ("FDR") and save for later.</p>		Go to Step (3)	
3	<p>Inspect for any obvious issues that may have caused the event.</p> <ul style="list-style-type: none"> a. Fuel system b. Ignition system c. Electrical d. Base Engine e. Application 		System OK	Go to Step (4)
4	<p>Ignition Coil Wire Harness Inspection</p> <ul style="list-style-type: none"> a. Inspect the coil harness to engine harness connector as well as the ignition coil to harness connector for incorrectly pinned circuits. b. Inspect for connections that are not fully seated. c. Inspect for pushed back, loose, damaged, bent, or spread terminals. d. Inspect for damage to the wiring. e. Inspect for water ingress into the connectors. f. Inspect for debris in the terminals or circuit. g. Pay close attention to turbo boots for any signs of oil leak, weep, or seep onto ignition harness connectors. 		System OK	Go to Step (5)
5	<p>Remove each ignition coil from the engine one at a time.</p> <ul style="list-style-type: none"> a. Inspect and document coils that are not fully seated or loose. b. Inspect and document ignition coil boots that may have torn or fragmented off before or during removal. c. Inspect for water or coolant around the body of the ignition coil. d. Inspect for presence of dielectric grease. 		System OK	Go to Step (6)

Step	Action	Value(s)	Yes	No
6	Remove each spark plug from engine one at a time. a. Inspect for contamination (oil, fuel, coolant, other) b. Inspect spark plug condition using the guide below as a visual.	Replace spark plugs at 750 hours if not already replaced.	System OK	Go to Step (7)
7	Measure resistance of spark plug. a. Replace if the resistance is outside the acceptable value. b. Measurement requires very firm contact with the probes and may require scratching the surface to get a valid measurement.	3.5-7 kOhm = Acceptable resistance value	System OK	Go to Step (8)
8	*M-Series Engine Only Locate the crank sensor on bottom left-hand side of flywheel housing and perform a crank sensor gap verification.	Crank sensor specification is 0.110" +/- 0.015	System OK	Go to Step (9)
9	In cases where the engine is within 100 hours of a valve lash PM, remove valve covers from engine and perform a valve clearance inspection. Adjust as required and reassemble per instructions in the service manual.	Valve lash MUST BE performed on cold engine	System OK	Go to Step (10)
10	Important - Reassemble the spark plugs, ignition coils, and ignition coil boots on the exact opposite cylinder which they were removed. Meaning install cylinder 1 ignition system parts onto cylinder 7 during the reassembly procedure. Install spark plugs. a. Apply dielectric grease* to spark plug tip. b. Replace spark plugs if any visual issues were noted during the inspection. Apply dielectric grease* to spark plug boots. Install and torque ignition coils and boots. Connect electrical connections to ignition coils. a. Ensure the connections are tight and secured properly. Replace any damaged components found during the evaluation. *Use Permatex Dielectric grease #81150 or equivalent	Replace spark plugs if the spark plugs have 750 hours or more of operation		Go to Step (11)

Step	Action	Value(s)	Yes	No
11	<p>When you are ready to start the engine connect the 4G Display software to the engine wire harness diagnostic link connector.</p> <p>Turn VSW (B+) on to the engine so the 4G display connects to the engine ECM's.</p> <p>Load the DWELL plot file template into the 4G display software.</p> <p>Start a plot file recording.</p> <p>Start Engine.</p> <p>Monitor engine for any abnormal conditions, fault codes, fuel pressure expected vs actual.</p> <ol style="list-style-type: none"> Specifically, monitor fuel trims on both the primary and secondary side ECM's to ensure they are within acceptable limits. A DTC will not likely set until +/- 35%, ideally the fuel trims will be +/- 15% <p>Run the engine for 10 minutes while recording the plot file data.</p> <p>Save plot file data.</p>			

DTC 1351 - Spark Plug or Coil Failure



Conditions for Setting the DTC

- Key on, Engine on
- Fault conditions: Ignition/spark drive circuitry (internal to the ECM) is overheating.
- MIL: ON
- Engine Shutdown

Fault Description

Coil driver #1 (correlates to DTC 1351) fires either the 1st cylinder in the firing order or the 1st cylinder in the block order depending on the configuration of the 'Injector/Spark.

Diagnostic Numbering' scheme as set in calibration. Drivers 2-10 (correlating to DTCs 13521360) follow in-kind.

Diagnostic Aids:

- Check plug gap on the cylinder associated with the fault.
- Check for loose connections at the coil and spark plugs. Look for evidence of charring or arcing around the spark plugs.
- Check coil resistance and verify that it is within specifications. Look for a short internal to the coil.
- Ensure the use of high-quality coils without a history of internal arcing or other failures.
- Verify that ambient conditions are not exceeding 85C on a continuous basis or 125C for short intervals. If so, verify that this fault stops occurring when ambient temperatures are lower.
- Verify the dwell time set in the diagnostic calibration is not set too long and that adaptive dwell is enabled.

DTC 1439 - Engine Oil Temperature Sensor High

OIL PRES&TEMP CONN (C16)			
BLACK/LT GREEN 18	1	5V_rtn	
LT GREEN/WHITE 18	2	AUX_ana_PU3	
LT GREEN/RED 18	3	5V_ext	
LT GREEN/BLACK 18	4	OILP	

Conditions for Setting the DTC

- Check Condition: Key On
- Fault condition: Temperature exceeds 235°F for over 3 seconds
- MIL: ON
- Engine Shutdown


Fault Description

The engine oil temperature sensor determines if the engine oil temperature is operating at normal operating temperatures given known air temperature and engine loads. Sensor allows for continuous monitoring after startup conditions are achieved.

Diagnostic Aid

- Check the engine oil level and refill if necessary.
- If the oil level is full, check the function of the switch. Disconnect the switch, clear the fault and try running the engine again. If the fault does not come back, check the oil temperature sensor switch.
- If the fault is still active with the switch disconnected, check the wiring for the switch to make sure it is not shorted to ground. The wiring originates at the Vehicle Interface Connector on the engine at terminal K. Disconnect the VIC and use an ohmmeter to check for a short to ground from pin K on the engine side of the VIC and on the OEM side of the VIC. Once you have determined whether the short is on the engine or in the OEM wiring you can begin searching for the short and repair it.
- Check for containment buildup or other non-leak-based failures that reduce the efficiency of the oil cooler.
- Check for damages in the rotating assembly that is causing excessive heat buildup, extra friction is going to be transferred into the oil in either loaded prime or continues applications, this will not be enough additional load and will come up as an increase in power output.

DTC 1511 - AUX Analog PU1 High



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault condition: Oil voltage > 4.8 Volts
- MIL: ON

Fault Description

This fault sets if the measured oil temperature is outside the upper limit as defined in the calibration. Required entry conditions for evaluation of this fault are the absence of any of the four faults below:


- **Oil Level and Temperature Sensor Loss**
- **Oil Level and Temperature Sensor Voltage Out of Range**
- **Oil Level Out of Range**
- **Oil Temperature Out of Range**

NOTE: The **Oil voltage Too High** fault is not reported in the EDIS **Oil T/L** diagnostics state field and does not illuminate the LED

DTC 1511 - AUX Analog PU1 High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Off System Mode="Stopped"	Does DST display fault code?	Go to Step (3)	Go to Step (4)
3	Measure oil Voltage	Is Oil Voltage>4.8V?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Troubleshoot and correct the source of oil overheating Re-test			
6	Faulty Sensor			

DTC 1512 - AUX Analog PU1 Low



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault condition: Oil voltage < 0.2 Volts
- MIL: ON

Fault Description

This fault sets if the measured oil temperature is outside the upper limit as defined in the calibration. Required entry conditions for evaluation of this fault are the absence of any of the four faults below:


- **Oil Level and Temperature Sensor Loss**
- **Oil Level and Temperature Sensor Voltage Out of Range**
- **Oil Level Out of Range**
- **Oil Temperature Out of Range**

NOTE: The **Oil voltage Too High** fault is not reported in the EDIS **Oil T/L** diagnostics state field and does not illuminate the LED

DTC 1512 - AUX Analog PU1 Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Off System Mode="Stopped"	Does DST display fault code?	Go to Step (3)	Go to Step (4)
3	Measure oil Voltage	Is Oil Voltage<0.2V?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Troubleshoot and correct the source of oil overheating Re-test			
6	Faulty Sensor			

DTC 1514 - AUX Analog PU2 Low



Conditions for Setting the DTC

- Check Condition: Key On, Engine On
- Fault condition: Oil voltage < 0.2 Volts
- MIL: ON
- AUX analog PU2 < 0.2 volts
- Configuration #1: Auxiliary Sensor (proportional voltage type),
- Configuration #2: Auxiliary Sensor (switch-type)

Fault Description

The auxiliary analog input circuit is customer specific and can be used to perform an action based on a sensor that switches to ground or a sensor that outputs a proportional voltage. Typical uses of the auxiliary circuit includes switches that activate particular software strategies, switches that act as vehicle safeties to trigger derate or shutdown conditions, or auxiliary senders used to drive gauges.


The circuit internal to the ECM is connected in parallel with the regulated 5 VDC power supply so that when no load is connected to the circuit the feedback voltage is equal to 5 VDC.

This fault is active when the voltage feedback from the sensor is below the limit defined in calibration.

DTC 1514 - AUX Analog PU2 Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Off System Mode="Running" Operate engine at condition that set AUX PU <u>X</u> DTC set Verify that AUX PU <u>X</u> DTC is active"	Does DST display AUX PU <u>X</u> voltage less than the limit set in calibration?	Go to Step (3)	Go to Step (4)
3	Key On, Engine Off Run Mode="Running" Disconnect sensor from harness	Does DST display AUX PU <u>X</u> voltage >4.90V?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Jumper AUX PU <u>X</u> to ground at the sensor connector	Does DST display AUX PU <u>X</u> voltage < 0.100 VDC?	Go to Step (7)	Go to Step (8)
6	Faulty wire harness Faulty ECM connection Faulty ECM			
7	Faulty operation/operating Faulty Sensor			
8	Faulty wire harness Faulty ECM connection Faulty ECM			

DTC 1515 - AUX Analog PD1 High



Conditions for setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault condition: AUX analog PD>4.8 volts
- MIL: ON

Fault Description

The auxiliary analog input circuit is customer specific and can be used to perform an action based on a sensor that switches to ground or a sensor that outputs a proportional voltage. Typical uses of the auxiliary circuit include switches that activate particular software strategies, switches that act as vehicle safeties to trigger derate or shutdown conditions, or auxiliary senders used to drive gauges.


The circuit internal to the ECM is connected in parallel ground so that when no load is connected to the circuit the feedback voltage is equal to 0 VDC.

This fault is active when the voltage feedback from the sensor is ABOVE the limit defined in calibration.

DTC 1515 - AUX Analog PD1 High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine On System Mode="Running" Operate engine at condition that set AUX PUX DTC set	Is AUX PD {X} inactive?	Go to Step (3)	Go to Step (4)
3	Key On, Engine Off Disconnect sensor from harness	Does DST display AUX PD {X} voltage >4.90V?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Faulty wire harness Faulty ECM connector Faulty harness		Go to Step (7)	Go to Step (8)
6	Measure the resistance of 5v rtn	Is resistance <5Ω?	Go to Step (9)	Go to Step (10)
7	Faulty operation/operating Faulty Sensor			
8	Faulty wire harness Faulty ECM connection Faulty ECM			
9	Faulty sensor			
10	Faulty wire harness Faulty ECM connection Faulty ECM			

DTC 1516 - AUX Analog PD1 Low



Conditions for setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault condition: AUX analog PD<0.2 volts
- MIL: ON

Fault Description

The auxiliary analog input circuit is customer specific and can be used to perform an action based on a sensor that switches to ground or a sensor that outputs a proportional voltage. Typical uses of the auxiliary circuit include switches that activate particular software strategies, switches that act as vehicle safeties to trigger derate or shutdown conditions, or auxiliary senders used to drive gauges.


The circuit internal to the ECM is connected in parallel ground so that when no load is connected to the circuit the feedback voltage is equal to 0 VDC.

This fault is active when the voltage feedback from the sensor is ABOVE the limit defined in calibration.

DTC 1516 - AUX Analog PD1 Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine On System Mode="Running" Operate engine at condition that set AUX PUX DTC set	Is AUX PD {X} active?	Go to Step (3)	Go to Step (4)
3	Key On, Engine Off Disconnect sensor from harness	Does DST display AUX PD {X} voltage >4.90V?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	Faulty wire harness Faulty ECM connector Faulty harness		Go to Step (7)	Go to Step (8)
6	Measure the resistance of 5v rtn	Is resistance <5Ω?	Go to Step (9)	Go to Step (10)
7	Faulty operation/operating Faulty Sensor			
8	Faulty wire harness Faulty ECM connection Faulty ECM			
9	Faulty sensor			
10	Faulty wire harness Faulty ECM connection Faulty ECM			

DTC 1517 - AUX analog PU3 high / Oil Temp Sensor High Voltage



Conditions for setting the DTC

- Check Condition: Key On
- Fault condition: AUX analog PU3 > 2.5 volts
- MIL: ON
- Engine Shutdown

Fault Description

The auxiliary analog input circuit is customer specific and can be used to perform an action based on a sensor that switches to ground or a sensor that outputs a proportional voltage. Typical uses of the auxiliary circuit includes switches or sensors that activate particular software strategies, switches that act as safeties to trigger derate or shutdown conditions, or auxiliary senders used to drive gauges.

This fault is active when the voltage feedback from the sensor is above the limit defined in calibration.


The fault code is generally setup to monitor oil temperature using the oil pressure/temp sensor. In cases where the oil temperature is higher than expected, the voltage at the ECM will increase, when the voltage at the ECM AUX_Ana_PU exceeds 2.5volts, the fault code will activate.

The sensor is a negative temp coefficient (NTC) sensor which means as temperature increases, resistance decreases. This in turn results in a higher voltage signal being sent to the ECM.

DTC 1517 - AUX analog PU3 high / Oil Temp Sensor High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running"	-	Go to Step (3)	
3	1. Operate engine at condition that set AUX PU3 DTC 1517. 2. Open RawVolts page in 4G Display, monitor AUX PU 3 voltage (AUX_PU3_raw) Is AUX_PU3_raw above 2.5 volts?		Go to Step (4)	Go to Step (5)
4	Key On, Engine off Run Mode - "Stopped"	Engine OFF	Go to Step (6)	
5	Intermittent problem, collect information on setting conditions and attempt to replicate issue.			
6	Disconnect oil pressure/temp sensor from engine wire harness. Check AUX_PU3_raw in 4G Display	Voltage \geq 4.90 VDC?	Go to Step (7)	Go to Step (8)
7	Jumper AUX PU3 to ground at the sensor connector Check AUX_PU3_raw in 4G Display	Voltage \leq 0.100 VDC?	Go to Step (9)	Go to Step (8)
8	Disconnect harness from oil pressure/temp sensor and from ECM. Using a DVOM measure resistance in wire harness from terminal 2 at connector to terminal 71 at ECM header connector.	Less than 1 ohm (Ω)	Replace Oil Pressure/Temp Sensor	Repair circuit issue (high resistance) or replace harness
9	Measure oil temp with temp gun or thermal-couple to do determine if oil temp exceeds allowable max temp. Is oil temp higher than max temp?	Refer to engine spec sheet for max oil temp. WP (Max) 235F 20L (Max) 250F	Diagnose cause of high oil temperature.	Replace Oil Pressure/Temp Sensor

DTC 1552 (111:0) – Aux Dig 1 Low Voltage / Coolant Level Low



Conditions for Setting the DTC

- **Fault Condition:** Low coolant level switch circuit (Aux_DIG1) voltage is less than 1.25V while the engine is running and coolant temperature is above 70°F
- **MIL:** ON during active fault
- Engine Shutdown


Fault Description

The coolant level switch is an optional switch installed by the OEM in the cooling circuit to detect a loss of engine coolant and shut the engine down. The switch is normally open and shorts the AUX_DIG1 wire to ground when closed, triggering the fault. The MIL will light and the engine will shut down.

Diagnostic Aids

1. Begin by checking the engine coolant level. If it's low, refill it to the appropriate level.
2. If the coolant level is full, proceed to check the function of the coolant level switch:
 - a. Disconnect the coolant level switch.
 - b. Clear any fault codes or alerts.
 - c. Attempt to start the engine again.
3. If the fault does not reoccur after disconnecting the switch, focus on examining the coolant level switch itself.
4. However, if the fault persists even with the switch disconnected, the next step is to inspect the wiring associated with the switch to ensure it's not shorted to ground:
 - a. Locate the wiring, which originates at the Vehicle Interface Connector (VIC) on the engine at terminal K.
 - b. Disconnect the VIC.
 - c. Use an ohmmeter to check for a short to ground:
 - i. Measure from pin K on the engine side of the VIC.
 - ii. Measure from pin K on the OEM side of the VIC.
 - d. Based on your measurements, determine whether the short is on the engine side or in the OEM wiring.
5. Once you've identified the location of the short (engine side or OEM wiring), you can begin the process of locating and repairing the short circuit.

DTC 1572 - AUX DIG4 high - Coolant Level Stage 1 High Voltage



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: This fault is active when the voltage feedback from the sensor is ABOVE the limit defined in calibration.
- MIL: ON during active fault
- Engine Shutdown

Fault Description


The auxiliary digital input circuit is customer specific and can be used to perform an action based on a sensor that is switchable between two voltages as well as a center voltage. Typical uses of the auxiliary circuit include switches that activate particular software strategies, switches that act as vehicle safeties to trigger derate or shutdown conditions, or auxiliary senders used to drive gauges.

The circuit internal to the ECM is connected in parallel both with the regulated 5 VDC power supply as well as ground, so that when no load is connected to the circuit the feedback voltage is equal to either 32 VDC or 0 VDC, based on the switch state.

DTC 1572 - AUX DIG4 high - Coolant Level Stage 1 High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at condition that set AUX_DIG(N) DTC	Is AUX_DIG(N) DTC active?	Go to Step (3)	Go to Step (4)
3	Key On, Engine Off Disconnect sensor/switch from harness Measure the input voltage of AUX_DIG(N)	Does DST or multi-meter display an AUX_DIG(N) voltage ~2.5 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5		Does DST or multi-meter display an AUX_DIG(N) voltage >=5.5 VDC?	Go to Step (7)	Go to Step (8)
6	Faulty sensor			
7	Faulty ECM or Faulty Harness			
8	Replace with known good sensor and re-test			

DTC 1574 - AUX DIG5 high - Coolant Level Stage 2 High Voltage



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: This fault is active when the voltage feedback from the sensor is ABOVE the limit defined in calibration.
- MIL: ON during active fault
- Engine Shutdown

Fault Description


The auxiliary digital input circuit is customer specific and can be used to perform an action based on a sensor that is switchable between two voltages as well as a center voltage. Typical uses of the auxiliary circuit include switches that activate particular software strategies, switches that act as vehicle safeties to trigger derate or shutdown conditions, or auxiliary senders used to drive gauges.

The circuit internal to the ECM is connected in parallel both with the regulated 5 VDC power supply as well as ground, so that when no load is connected to the circuit the feedback voltage is equal to either 32 VDC or 0 VDC, based on the switch state.

DTC 1574 - AUX DIG5 high - Coolant Level Stage 2 High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine On System Mode = "Running" Operate engine at condition that set AUX_DIG(N) DTC	Is AUX_DIG(N) DTC active?	Go to Step (3)	Go to Step (4)
3	Key On, Engine Off Disconnect sensor/switch from harness Measure the input voltage of AUX_DIG(N)	Does DST or multi-meter display an AUX DIG(N) voltage ~2.5 VDC?	Go to Step (5)	Go to Step (6)
4	Intermittent Problem			
5	-	Does DST or multi-meter display an AUX DIG(N) voltage >=5.5 VDC?	Go to Step (7)	Go to Step (8)
6	Faulty sensor			
7	Faulty ECM or Faulty Harness			
8	Replace with known good sensor and re-test			

DTC 1602 - Relay Off High Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running / Stopped Checked
- Fault Condition: Relay control off with VRelay voltage >80.0% Vbat
- MIL: ON during active fault

Fault Description


Certain models of the 4G ECM source power for part of the internal circuitry from the VRelay circuit, which also supplies power to the engine harness. The VRelay is controlled by the ECM using one of the low side (LS) driver

This fault sets if the output for the power relay is off, with VRelay voltage greater than a calibratable percentage of battery voltage.

DTC 1602 - Relay Off High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine Off Locate VRelay voltage on EDIS RawVolts page	Is VRelay >%VBat specified in the calibration?	Go to Step (3)	Go to Step (4)
3	Locate power relay in the harness and remove it.	Did EDIS VRelay voltage go to 0.0V?	Go to Step (5)	Go to Step (5)
4	Fault condition not present			
5	Replace the Power relay with a new unit and recheck.			
6	Locate and repair short to power in the wiring harness.			

DTC 1603 - Relay On Low Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running / Stopped Checked
- Fault Condition: Relay control on with feedback <20.0% Vbat
- Injectors relay powered: Yes
- Ignition coils relay powered: Yes
- MIL: ON during active fault

Fault Description

Certain models of the 4G ECM source power for part of the internal circuitry from the VRelay circuit, which also supplies power to the engine harness. The VRelay is controlled by the ECM using one of the low side (LS) drivers.

This fault sets if the output for the power relay is on, with VRelay voltage less than a calibratable percentage of battery voltage.


Please note:

- 1) If the injectors are relay powered (selection dropdown set to YES), all injector faults will be ignored while this fault is active.
- 2) If the ignition coils are relay powered (selection dropdown set to YES), all injector faults will be ignored while this fault is active.

DTC 1603 - Relay Off High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine On Locate VRelay voltage on EDIS RawVolts page	Is VRelay <%VBat specified in the calibration?	Go to Step (3)	Go to Step (4)
3	-	Are DTCs 685 or 6987 set?	Go to Step (5)	Go to Step (5)
4	Fault condition not present			
5	Refer to diagnostics for the set fault. Repair and retest.			
6	Check power relay fuse. Repair as needed. Check for battery voltage to and from the power relay. Repair as needed.			

DTC 1612 - RTI 1 Loss



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Adaptive: Disabled for the remainder of the key-ON cycle
- Engine shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this code occurs.

DTC 1612 - RTI 1 Loss

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running DST (Diagnostic Scan Tool) connected in System Data Mode Clear system fault code Does DTC 1612 reset with the engine idling?		Go to Step (3)	Intermittent problem Go to Intermittent section
3	Check ECM power and ground circuits Did the power and ground circuits check OK?		Go to Step (4)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
4	Replace ECM Is the replacement complete?		Go to Step (5)	-
5	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-1612 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1613 - RTI 2 Loss



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Adaptive: Disabled for the remainder of the key-ON cycle
- Engine shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this code occurs.

DTC 1613 - RTI 2 Loss

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Running System Data Mode Clear System Fault	Does DTC 1613 reset with engine idling?	Go to Step (3)	Go to Step (4)
3	Check all power and ground circuits to ECM	Are all circuits, ok?	Go to Step (5)	Go to Step (6)
4	Fault is intermittent			
5	Replace ECM with known good part and retest			
6	Repair wiring to ECM and retest			

DTC 1614 - RTI 3 Loss



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Adaptive disabled for the remainder of the key-ON cycle
- Engine shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this code occurs.

DTC 1614 - RTI 3 Loss

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Running System Data Mode Clear System Fault	Does DTC 1614 reset with engine idling?	Go to Step (3)	Go to Step (4)
3	Check all power and ground circuits to ECM	Are all circuits, ok?	Go to Step (5)	Go to Step (6)
4	Fault is intermittent			
5	Replace ECM with known good part and retest			
6	Repair wiring to ECM and retest			

DTC 1615 - A/D Loss



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Adaptive disabled for the remainder of the key-ON cycle
- Engine shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this code occurs.

DTC 1615 - A/D Loss

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Running System Data Mode Clear System Fault	Does DTC reset with engine idling?	Go to Step (3)	Go to Step (4)
3	Check all power and ground circuits to ECM	Are all circuits, ok?	Go to Step (5)	Go to Step (6)
4	Fault is intermittent			
5	Replace ECM with known good part and retest			
6	Repair wiring to ECM and retest			

DTC 1616 - Invalid Interrupt



Conditions for Setting the DTC

- Check Condition: Key on
- Fault Condition: Internal microprocessor error
- MIL: ON
- Adaptive disabled for the remainder of the key-ON cycle
- Engine Shutdown will occur


Circuit Description

The ECM has several internal checks that must be satisfied each time an instruction is executed. Several different things can happen within the microprocessor that will cause this fault. The ECM will attempt to reset itself in the event this fault is set. The MIL command is on and will remain on until the code is cleared using the DST. The engine will shut down if this code occurs.

DTC 1616 - Invalid Interrupt

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key On, Engine Running System Data Mode Clear System Fault	Does DTC reset with engine idling?	Go to Step (3)	Go to Step (4)
3	Check all power and ground circuits to ECM	Are all circuits, ok?	Go to Step (5)	Go to Step (6)
4	Fault is intermittent			
5	Replace ECM with known good part and retest			
6	Repair wiring to ECM and retest			

DTC 1625 - J1939 Shutdown Request



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: Master ECM receives a shutdown request over the CAN network
- MIL: ON during active fault
- Engine Shutdown

Fault Description


This fault is triggered when a device connected to the CAN network triggers an engine shutdown. The MIL will light and the engine will shut down.

Diagnostic Aids


This fault is triggered in the master ECM whenever there is a fault in the slave ECM that requires the engine to shut down. The slave ECM doesn't have the authority to shut down the engine on its own, so it sends a shutdown request over the CAN network to the master ECM to get the engine to shut down. Connect to the slave ECU and check all stored fault codes to find the fault that triggered the shutdown on the master side.

To access the secondary side ECM, Change your Comm Port (Configure ECOM) to Target CAN Address 1. This will give you access to the secondary side ECM.

If there are no stored faults on the slave ECM, check any other devices connected to the CAN network that are capable of triggering an engine shutdown, such as genset controllers or pump controllers.



DTC 1626 - CAN1 Tx Failure



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: CAN Tx error 120 packets lost within 1 second
- MIL: ON


Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. This fault will set if the ECM broadcasts 120 packets to the network that are not received within a one second time period. The MIL command is ON.

Diagnostic Aides

- Verify that all CAN devices are powered and properly grounded
- Verify that the CAN1 network is properly terminated
- Check CAN1 wire routing with respect to noise sources (ignition coils, spark plug coil wires, etc.) and shield if necessary
- Check CAN1 (+) and (-) wires for short circuits

DTC 1627 - CAN1 Rx Failure



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: CAN1 Rx error 120 packets lost within 1 second
- MIL: ON

Circuit description


The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. This fault will set if the ECM detects 120 packets lost within a one second time period. The MIL command is ON.

DTC 1627 - CAN1 Rx Failure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running DST (Diagnostic Scan Tool) connected in System Data Mode Clear system fault code Does DTC1627 reset with the engine idling?		Go to Step (3)	Intermittent problem Go to Intermittent section
3	Check that the ECM power connection C019 is clean, tight and in the proper location. Check that the ECM ground connection C010 is clean, tight and in the proper location. Are the power and ground circuits OK?		Go to Step (4)	Repair the circuit as necessary. Refer to Wiring Re-pairs in Engine Electrical.
4	Using a DVOM check for continuity between ECM pins 14 and 15 Do you have continuity between them?		Repair the shorted circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (5)
5	Using a DVOM check for continuity to engine ground on pin 15. Do have continuity to engine ground?		Repair the shorted to ground circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (6)
6	Using a DVOM check for continuity to battery positive on pin 15. Do have continuity between them?		Repair the shorted to ground circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (7)
7	Replace the ECM Is the replacement complete?		Go to Step (8)	-

Step	Action	Value(s)	Yes	No
8	<p>Remove all test equipment except the DST. Connect any disconnected components, fuses, etc.</p> <p>Using the DST clear DTC information from the ECM.</p> <p>Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature</p> <p>Observe the MIL</p> <p>Observe engine performance and drivability After operating the engine within the test parameters of DTC-1627 check for any stored codes. Does the engine operate normally with no stored codes?</p>		System OK	Go to OBD System Check

DTC 1628 - CAN Address Conflict



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: 5 or more address conflict errors
- MIL: ON


Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. Individual devices are assigned network addresses. This fault will set if the ECM detects an address conflict, such as two devices with the same address. This is usually not due to an in-field failure and may be the results of "add on" CAN devices.

DTC 1628 - CAN Address Conflict

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running DST (Diagnostic Scan Tool) connected in System Data Mode Clear system fault code Does DTC1628 reset with the engine idling?		Go to Step (3)	Intermittent problem Go to Intermittent section
3	Key OFF Disconnect one CAN device Clear DTC 1628 Key ON (start engine if possible if not continue cranking for at least 3 seconds) Wait 5 seconds Does DTC 1628 re-set?		Repeat step 3 until all CAN devices have been disconnected one at a time	Contact the CAN device manufacturer for additional CAN address information Go to Step (4)
4	Has the CAN device been replaced, or address conflict resolved?		Go to Step (5)	-
5	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-1628 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 1646 - CAN2 Tx Failure



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: CAN Tx error 120 packets lost within 1 second
- MIL: ON

Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. This fault will set if the ECM broadcasts 120 packets to the network that are not received within a one second time period. The MIL command is ON.

Diagnostic Aides

- Verify that all CAN devices are powered and properly grounded
- Verify that the CAN2 network is properly terminated
- Check CAN2 wire routing with respect to noise sources (ignition coils, spark plug coil wires, etc.) and shield if necessary
- Check CAN2 (+) and (-) wires for short circuits

DTC 1647 - CAN3 Tx Failure

Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: CAN Tx error 120 packets lost within 1 second
- MIL: ON


Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. This fault will set if the ECM broadcasts 120 packets to the network that are not received within a one second time period. The MIL command is ON.

Diagnostic Aides

- Verify that all CAN devices are powered and properly grounded
- Verify that the CAN3 network is properly terminated
- Check CAN3 wire routing with respect to noise sources (ignition coils, spark plug coil wires, etc.) and shield if necessary
- Check CAN3 (+) and (-) wires for short circuits

DTC 1648 - CAN2 Rx Failure




Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: CAN2 Rx error 120 packets lost within 1 second
- MIL: ON

Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. This fault will set if the ECM detects 120 packets lost within a one second time period. The MIL command is ON.

DTC 1649 - CAN3 Rx Failure




Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: CAN3 Rx error 120 packets lost within 1 second
- MIL: ON

Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. This fault will set if the ECM detects 120 packets lost within a one second time period. The MIL command is ON.

DTC 1650 – CAN2 Address Conflict Failure




Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: 5 or more address conflict errors
- MIL: ON

Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. Individual devices are assigned network addresses. This fault will set if the ECM detects an address conflict, such as two devices with the same address. This is usually not due to an in-field failure and may be the results of "add on" CAN devices.

DTC 1653 – CAN3 Address Conflict Failure




Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: 5 or more address conflict errors
- MIL: ON

Circuit description

The CAN bus (controller area network) is used by the ECM to communicate with other digital devices used throughout the fuel system. Information is sent over the CAN bus in digital information "packets" that contain information for various control functions. Individual devices are assigned network addresses. This fault will set if the ECM detects an address conflict, such as two devices with the same address. This is usually not due to an in-field failure and may be the results of "add on" CAN devices.

DTC 1673 - Calibration Configuration Error



Conditions for Setting the DTC

- Check Condition: Engine running
- Fault Condition: Specific calibration variable checks do not return expected results
- MIL: ON
- Adaptive disabled, engine derated


Circuit description

The ECM checks certain safety-related calibration variables for acceptable values or ranges. This fault becomes active when these variable checks do not return the expected results.

Diagnostic Aids

Clear the fault and run the engine again. If the fault returns, contact PSI.

DTC 1674 - Hardware ID Failure



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: MOT file is too old for the given hardware revision level
- MIL: ON
- Adaptive disabled, engine derated

Circuit description

The ECM checks the MOT file against hardware ID tags that indicate the current ECM hardware revision level. This fault will set when programming the ECM with a MOT file that is too old for the given hardware and revision level.


Diagnostic Aids

Clear the fault and run the engine again. If the fault returns, contact PSI.

DTC 1674 - Hardware ID Failure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key ON, Engine On System Mode="Running" Operate engine at idle Clear system fault	Did DTC 1674 occur after flashing new MOT file?	Go to Step (3)	Go to Step (4)
3	Recompile with latest software and re-flash the ECM	Does DTC 1674 clear after reflashing with new software?		Go to Step (8)
4	-	Does DTC 1674 reset with engine idling?	Go to Step (5)	Go to Step (6)
5	Check all power and ground circuits to ECM	Are all circuits ok?	Go to Step (7)	Go to Step (8)
6	Fault is intermittent			
7	Repair wiring to ECM and retest			
8	Replace ECM with known good part and retest			

DTC 2111 - Unable To Reach Lower TPS



Conditions for Setting the DTC

- Check Condition: Cranking or Running
- Fault Condition: Actual throttle position is 20% greater than the throttle command
- MIL: ON during active fault
- Engine shutdown

Circuit Description

Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. When the throttle is closed TPS1 will read low voltage and TPS2 will read high voltage. The TPS 1 and TPS 2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. This fault will set if the actual throttle position is 20% greater than the throttle command. During this active fault the MIL command is ON and the engine will shut down.

Diagnostic Aid


This fault is most often caused by a mechanical problem with the throttle. Testing the engine with a known good throttle or swapping the throttles side to side on a G-drive engine and seeing if the problem moves are good ways to diagnose a stuck throttle.

DTC 2111 - Unable To Reach Lower TPS

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine OFF DST (Diagnostic Scan Tool) connected in DBW (Drive By Wire) test mode Depress foot pedal until the throttle command is between 63%-68% Is the TPS 1 voltage greater than 2.0 volts?		Go to Step (3)	Intermittent problem Go to Intermittent section
3	Key OFF Disconnect electronic throttle connector C017 Probe TPS 1 signal pin 1 with a test light connected to battery voltage Key ON Does DST display TPS 1 voltage less than 0.2 volts?		Go to Step (6)	Go to Step (4)
4	Key OFF Disconnect ECM wire harness connector C001 Key ON Using a DVOM check for voltage between throttle connector TPS 1 signal pin 1 and engine ground Do you have voltage?		Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (5)
5	Replace ECM Is the replacement complete?		Go to Step (13)	-
6	Probe sensor ground circuit at ECM connector C001 with a test light connected to battery voltage Does the test light come on?		Go to Step (9)	Go to Step (7)
7	Key OFF Disconnect ECM wire harness connector C001 Using a DVOM check for continuity between throttle connector signal ground pin 3 and ECM signal ground circuit pin 20 Do you have continuity between them?		Go to Step (8)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
8	Replace ECM Is the replacement complete?		Go to Step (13)	-
9	Check throttle for foreign object in bore Did you find a foreign object in the bore?		Go to Step (10)	Go to Step (11)
10	Remove foreign object Is the removal complete?		Go to Step (13)	-
11	Inspect the throttle wire harness connector terminals for damage, corrosion or contamination Did you find the problem?		Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (10)

Step	Action	Value(s)	Yes	No
12	Replace throttle Is the replacement complete?		Go to Step (13)	-
13	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-2111 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

DTC 2112 - Unable To Reach Higher TPS



Conditions for Setting the DTC

- Check Condition: Cranking or Running
- Fault Condition: Actual throttle position is 20% less than the throttle command
- MIL: ON during active fault
- Engine shutdown

Circuit Description

Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS 1 will read low voltage when closed and TPS 2 will read high voltage when closed. The TPS 1 and TPS 2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. This fault will set if the actual throttle position is 20% less than the throttle command. The MIL command is ON and the engine will shut down.

Diagnostic Aid


This fault is most often caused by a mechanical problem with the throttle. Testing the engine with a known good throttle or swapping the throttles side to side on a G-Drive engine and seeing if the problem moves are good ways to diagnose a stuck throttle.

DTC 2112 - Unable To Reach Higher TPS

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
	Key ON, Engine OFF DST (Diagnostic Scan Tool) connected in DBW (Drive By Wire) test mode Depress ² foot pedal until the throttle command is 63%-68% Is the TPS voltage less than 2.0 volts?		Go to Step (3)	Intermittent problem Go to Intermittent section
3	Key OFF Disconnect electronic throttle connector C017 Probe TPS 1 signal circuit pin 1 with test light connected to battery voltage Key ON		Go to Step (4)	Go to Step (8)
4	Check throttle bore for foreign object Did you find a problem?		Go to Step (5)	Go to Step (6)
5	Remove the foreign object Has the object been removed?		Go to Step (11)	-
6	Check the electronic throttle connector terminals for damage corrosion or contamination Did you find a problem?		Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (7)
7	Replace throttle Is the replacement complete?		Go to Step (11)	-
8	Key OFF Disconnect ECM wire harness connector C001 Using a DVOM check for continuity between throttle connector TPS 1 signal pin 1 and ECM TPS 1 signal pin 39 Do you have continuity between them?		Go to Step (9)	Repair the circuit as necessary. Refer to Wiring Repairs in Engine Electrical.
9	Using a DVOM check for continuity between throttle connector TPS 1 signal pin 1 and engine ground Do you have continuity between them?		Repair the shorted to ground circuit as necessary. Refer to Wiring Repairs in Engine Electrical.	Go to Step (10)

Step	Action	Value(s)	Yes	No
10	Replace ECM Is the replacement complete?		Go to Step (11)	-
11	<p>Remove all test equipment except the DST. Connect any disconnected components, fuses, etc.</p> <p>Using the DST clear DTC information from the ECM.</p> <p>Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature</p> <p>Observe the MIL</p> <p>Observe engine performance and drivability After operating the engine within the test parameters of DTC-2112 check for any stored codes. Does the engine operate normally with no stored codes?</p>		System OK	Go to OBD System Check

DTC 2122 - FPP1 High Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running / Stopped Checked
- Fault Condition: FPP voltage > 4.8 volts
- MIL: ON during active fault

Circuit Description

The FPP sensor is an electronic device that is coupled to a mechanically driven input as commanded by the vehicle/engine operator. A FPP sensor may be, but is not limited to a foot pedal assembly, a cable-lever-sensor assembly, or a rotary potentiometer. General sensor configurations consist of single potentiometer/hall-effect with IVS, two potentiometers/hall-effects, or two potentiometers/hall-effects with IVS. The FPP sensor outputs are proportional to the commanded input. The ECM uses the FPP sensor input(s) to control the throttle and adjust the engine's load in order to achieve the requested power. Since the FPP sensor inputs directly affect the engine's power output, redundant sensors are generally used to ensure safe, reliable operation. In systems that utilize a mechanical throttle the foot pedal input is used to monitor the position of the mechanical throttle valve in order to activate minimum or maximum governors. In electronic throttle control systems, the foot pedal position/throttle control position sensor is used by the engine/equipment operator or system to command either throttle position or a governor speed target proportional to the input to achieve desired system behavior.


Fault Description

This fault will set if FPP1 voltage is higher than the limit defined in the engine calibration at any operating condition. Fully redundant systems (when three sensors are compared) limited operation may result in setting codes without requiring derates, however, single, or non-redundant systems (FPP1 w/IVS) must command forced idle or engine shutdowns depending on the type of system.

DTC 2122 - FPP1 High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off	Does DST display FPP voltage greater than the fault trigger value defined in the calibration?	Go to Step (3)	Go to Step (4)
3	Disconnect the foot pedal from the wiring harness	Does DST display 0V FPP voltage?	Go to Step (5)	Go to Step (6)
4	Slowly depress FP while monitoring FPP voltage	Does DST display FPP voltage greater than the fault trigger value defined in the calibration?	Go to Step (7)	Go to Step (8)
5	Faulty foot pedal			
6	Faulty wiring harness			
7	Faulty FPP, or Faulty Connection, or Poor 5-volt power supply circuit			
8	Intermittent Problem			

DTC 2123 - FPP1 Low Voltage



Conditions for Setting the DTC

- Check Condition: Engine Running / Stopped Checked
- Fault Condition: FPP voltage < 0.2 volts
- MIL: ON during active fault

Circuit Description

The FPP sensor is an electronic device that is coupled to a mechanically driven input as commanded by the vehicle/engine operator. A FPP sensor may be, but is not limited to a foot pedal assembly, a cable-lever-sensor assembly, or a rotary potentiometer. General sensor configurations consist of single potentiometer/hall-effect with IVS, two potentiometers/hall-effects, or two potentiometers/hall-effects with IVS. The FPP sensor outputs are proportional to the commanded input. The ECM uses the FPP sensor input(s) to control the throttle and adjust the engine's load in order to achieve the requested power. Since the FPP sensor inputs directly affect the engine's power output, redundant sensors are generally used to ensure safe, reliable operation. In systems that utilize a mechanical throttle the foot pedal input is used to monitor the position of the mechanical throttle valve in order to activate minimum or maximum governors. In electronic throttle control systems, the foot pedal position/throttle control position sensor is used by the engine/equipment operator or system to command either throttle position or a governor speed target proportional to the input to achieve desired system behavior.


Fault Description

This fault will set if FPP1/FPP2 voltage is lower than the limit defined in the engine calibration at any operating condition. Fully redundant systems (when three sensors are compared) limited operation may result in setting codes without requiring derates, however, single or non-redundant systems (FPP w/IVS) must command forced idle or engine shutdowns depending on the type of system.

DTC 2123 - FPP1 Low Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Off	Does DST display FPP voltage less than the fault trigger value defined in the calibration?	Go to Step (3)	Go to Step (4)
3	Disconnect the foot pedal from the wiring harness Jumper the 5V supply in the wiring harness to the FPP wire in the harness	Does DST display FPP voltage >4.8V?	Go to Step (5)	Go to Step (6)
4	Slowly depress FP while monitoring FPP voltage	Does DST display FPP voltage less than the fault trigger value defined in the calibration?	Go to Step (7)	Go to Step (8)
5	Faulty foot pedal			
6	Faulty wiring harness			
7	Faulty FPP, or Faulty Connection, or Poor 5-volt power supply circuit			
8	Intermittent Problem			

DTC 2135 - TPS1/2 Simultaneous Voltages Out of Range



Conditions for Setting the DTC

- Check Condition: Key On, Engine running
- Fault Condition: TPS1 voltage is greater than 4.8V or less than 0.2V AND TPS2 voltage is greater than 4.8V or less than 0.2V
- MIL: ON during active fault
- Engine Shutdown


Fault Description

Dual throttle position sensors are used within the throttle that use variable resistors to determine signal voltage based on throttle plate position. TPS1 will read lower voltage when closed and TPS2 will read higher voltage when closed. The TPS1 and TPS2 percentages are calculated from these voltages. Although the voltages are different, the calculated values for the throttle position percentages should be very close to the same. The TPS values are used by the ECM to determine if the throttle is opening as commanded. The TPS is not serviceable and in the event of a failure the electronic throttle assembly must be replaced. This fault will set if there are simultaneous voltage out-of-range faults for both TPS 1 and TPS2.

Diagnostic Aids

- Troubleshoot according to TPS1 voltage out-of-range following DTC 122 and 123 procedures.
- Troubleshoot according to TPS2 voltage out-of-range following DTC 222 and 223 procedures.

DTC 2229 - BP High Pressure



Conditions for Setting the DTC

- Check Condition: Key ON
- Fault Condition: BP greater than 16 psia
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

The BP (Barometric Pressure) is estimated from the TMAP sensor. The barometric pressure value is used for fuel and airflow calculations. This fault sets in the event the BP value is out of the normal range.

DTC 2229 - BP High Pressure

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON DST (Diagnostic Scan Tool) connected in System Data Mode Does DST display MAP pressure of 16 psia or greater?		Go to Step (3)	Intermittent problem Go to Intermittent section
3	Replace TMAP sensor. Is the repair complete?		Go to Step 4	-
4	Remove all test equipment except the DST. Connect any disconnected components, fuses, etc. Using the DST clear DTC information from the ECM. Turn the ignition OFF and wait 30 seconds. Start the engine and operate the vehicle to full operating temperature Observe the MIL Observe engine performance and drivability After operating the engine within the test parameters of DTC-2229 check for any stored codes. Does the engine operate normally with no stored codes?		System OK	Go to OBD System Check

Description and Diagnostic Aids for Primary Coil Faults

Hardware/Circuit Description

The primary coil system consists of a coil driver responsible for firing the ignition coil for each cylinder. The fault codes relate to issues detecting a short-to-ground, open circuit, or low-side short in the harness or within the primary coil itself. The firing order determines the association of the coil driver to specific cylinders. The table below provides the description and diagnostic aids for the fault codes listed:

The fault codes are dependent on whether the diagnostic software is connected to the MASTER ECM or the SLAVE ECM.

- **If connected to the Master ECM**, DTCs correspond to **Master-side cylinder numbers**.
- **If connected to the Slave ECM**, the same DTCs correspond to **Slave-side cylinder numbers**.

Master and Slave Cylinder Numbering


- The Master ECM considers Cylinder 1–6 as Cylinders 1-6 in Block Order.
- The Slave ECM mirrors this but numbers Cylinders 12-7 as Cylinders 1-6 when diagnosing faults.
- This means a DTC 2301 on the Master ECM refers to Cylinder 1, while a DTC 2301 on the Slave ECM refers to Cylinder 12.

The chart below shows the correlation between **DTCs**, **coil drivers**, and **cylinder numbers** on the master and slave sides of a 22L Engine. The firing order and cylinder mapping provided have been incorporated


				Cylinder Block Number	
Description	DTC	SPN	FMI	Master Side	Slave Side
1 Primary Coil Shorted	2301	1268	6	1	12
1 Primary Loop Open or Low-Side Short to Ground	2300	1268	5	1	12
2 Primary Coil Shorted	2304	1269	6	2	11
2 Primary Loop Open or Low-Side Short to Ground	2303	1269	5	2	11
3 Primary Coil Shorted	2307	1270	6	3	10
3 Primary Loop Open or Low-Side Short to Ground	2306	1270	5	3	10
4 Primary Coil Shorted	2310	1271	6	4	9
4 Primary Loop Open or Low-Side Short to Ground	2309	1271	5	4	9
5 Primary Coil Shorted	2313	1272	6	5	8
5 Primary Loop Open or Low-Side Short to Ground	2312	1272	5	5	8
6 Primary Coil Shorted	2316	1273	6	6	7
6 Primary Loop Open or Low-Side Short to Ground	2315	1273	5	6	7

22L Cylinder Block Number Arrangement vs Firing Order


Firing Order: 1-12-5-8-3-10-6-7-2-11-4-9



Master / Primary Engine Bank



Slave / Secondary Engine Bank



Overview:

The 22L engine uses single spark plug shaft smart ignition coils, which are mounted directly on the spark plug. These ignition coils integrate their own electronics and do not require high-voltage ignition cables. They receive B+ power from a common relay on Terminal 1 and are controlled by the ECM, which switches ground on Terminal 2 to fire the spark plug.

Each ignition coil corresponds to a dedicated ECM spark coil circuit, which monitors its operation. A fault code is triggered if the ECM detects a short-to-ground, open circuit, or low-side short in the ignition coil circuit.

Harness Pin & Wiring Verification

The ignition harness diagram identifies each ECM coil pin and its corresponding harness connector pin. If the ignition coil is not functioning properly:

1. **Verify that the correct ECM pin is providing the trigger signal** to the ignition coil.
2. **Check harness continuity** for the specific **coil circuit wire** leading from the ECM to the ignition coil.
3. **Inspect power and ground pin locations in the harness** to ensure the correct pin supplies voltage.

Technician Notes:

- ✓ If **power, ground, and ECM trigger are confirmed good**, but the coil does not function, **replace the coil**.
- ✓ If there is **no ECM trigger signal**, check the **ECM, crankshaft position sensor, and ignition timing settings**.
- ✓ If **harness continuity is poor**, repair or replace the **damaged wiring** before proceeding.

Primary Coil Shorted – Additional Observations

- Step 4 (Primary Resistance Test) → Resistance is too low ($< 0.53\Omega$)
- Step 6 (ECM Trigger Signal Verification) → ECM may shut down coil due to overcurrent
- Step 7 (Primary Current Test) → Excessive current ($> 8.5A$) may indicate a shorted winding

Primary Loop Open – Additional Observations

- Step 4 (Primary Resistance Test) → Infinite resistance (OL) confirms open coil
- Step 5 (Harness Continuity Check) → Open circuit detected between ECM and coil
- Step 6 (ECM Trigger Signal Verification) → ECM still attempts to trigger coil, but no response

Low-Side Short to Ground – Additional Observations


- Step 3 (Ground Circuit Check) → Unexpected low resistance between harness trigger pin and ground
- Step 5 (Harness Continuity Check) → Wire is shorted to ground
- Step 6 (ECM Trigger Signal Verification) → ECM may be unable to command the coil if the driver is shorted

Step	Procedure	Expected Result	Tools Required
1. Visual Inspection	- Inspect the ignition coil for cracks, burns, or carbon tracking.	No visible damage, corrosion, or loose connections.	None
	- Check connector pins for bent, corroded, or loose terminals.		
	- Inspect harness for damaged or frayed wires .		
	- Ensure the coil boot and terminal are clean.		
2. Power Supply Check (Harness Pin Verification)	- Set multimeter to DC Volts (V) .	Voltage should be 24V ± system variance .	Multimeter
	- Turn ignition ON (engine not running).	The correct harness pin should supply power.	
	- Probe the B+ (power) pin on the harness connector and a known engine ground.		
	- Verify that the correct pin is receiving power per the ignition harness diagram .		
3. Ground Circuit Check (Harness Pin Verification)	- Set multimeter to Ohms (Ω) .	Resistance should be ≤ 0.2Ω .	Multimeter
	- Disconnect the coil harness connector .	If high resistance, inspect harness ground points .	
	- Measure resistance between the harness ground pin and engine ground.		
	- Verify ground path continuity based on the ignition harness diagram .		
4. Primary Resistance Test	- Set multimeter to Ohms (Ω) .	Resistance should be 0.59Ω ± 10% (range: 0.53Ω – 0.65Ω).	Multimeter
	- Disconnect the ignition coil connector .		
	- Measure resistance between the two coil pins .		
5. ECM to Coil Harness Pin Continuity Check	- Disconnect the harness from the ECM and ignition coil .	Continuity should be < 1Ω .	Multimeter
	- Set multimeter to continuity mode (Ω) .	If open circuit or high resistance, inspect for damaged wiring or loose connectors .	
	- Check continuity between the ECM spark coil pin and the corresponding harness connector pin .		
	- Refer to the ignition harness diagram for correct wiring.		
6. ECM Trigger Signal Verification	- Connect an oscilloscope probe to the trigger/ground pin of the coil connector.	A square wave pulse (switching between 0V	Oscilloscope (If Available)

	- Crank the engine and observe the waveform.	and 5-24V) should be visible.	
7. Primary Current Test	- Use a current clamp meter on the coil's power wire .	Coil should draw 8A ± 0.5A before cutoff.	Clamp Meter
	- Crank the engine and measure current draw.		
8. Secondary Voltage Output Check	- Use an oscilloscope or ignition tester probe to measure the coil's high-voltage output .	Secondary output voltage should be 28kV ± 10% .	Oscilloscope / HV Probe
	- Capture waveform during engine cranking.		
9. Spark Output Test	- Connect an adjustable spark tester to the coil's output.	A strong, blue spark should be present at a 6mm gap .	Spark Tester
	- Crank the engine and observe spark.		
10. Swap Test (If Needed)	- Exchange the suspected coil with another known-good coil.	The expected readings should match a known-good coil.	None
	- Repeat steps 5-9 on both coils.		
	- Verify if readings change.		
11. Final Verification	- Reconnect all components.	No issues found, consistent performance.	EDIS 4G Software
	- Clear fault codes using EDIS 4G software .		
	- Start the engine and verify stable operation.		

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step 2	Go to OBD System Check Section
2	Key ON, Engine Off. System Mode = "Stopped". Enable "DBW Test" mode.	TPS1 voltage low (< 1.00 VDC) at 0% TPS by design	Go to Step 3	Go to Step 4
3	Key ON, Engine Off. System Mode = "Stopped". With the throttle closed, check if DST displays a TPS1 fault condition.	TPS1 voltage < 0.200 VDC	Go to Step 5	Go to Step 7
4	Slowly sweep throttle position while observing TPS1 voltage. System Mode = "Stopped".	TPS1 voltage < 0.200 VDC	Go to Step 5	Go to Step 6
5	Key Off. Disconnect throttle from harness. Jumper 5Vref1 to TPS1 signal circuit at throttle connector. Key ON, Engine Off. System Mode = "Stopped".	TPS1 voltage > 4.0 VDC	Go to Step 9	Go to Step 10
6	Slowly sweep throttle position while observing TPS1 voltage. System Mode = "Stopped".	TPS1 voltage ever falls below 0.200 VDC	Go to Step 7	Intermittent problem.

DTC 2300 - 1 Primary Loop Open or Low-Side Short to Ground



Conditions for Setting the DTC

- Check Condition: Key ON, Engine On
- Fault Condition: If dwell current control = 'Adaptive Dwell' dwell adjustment ≥ 1 ms, or total dwell ≥ 4 ms; If dwell current control = 'Monitor Only': final current < 0.5 amps, and crank dwell (external module only) < 90 ms.
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

Coil driver #1 fires either the 1st cylinder in the firing order or the 1st cylinder in the block order depending on the configuration of the 'Injector/Spark Diagnostic Numbering' scheme as set in calibration. The purpose of this fault is to detect a short-to-ground or open circuit in the harness or internal to the primary coil.


Fault Description

This fault will set if the ECM detects **x** number of coil firings in which the adaptive dwell adjustment is greater than **y** ms. or the total dwell is greater than **w** ms. and battery voltage is greater than **z** volts as defined in the diagnostic calibration.

DTC 2300 - 1 Primary Loop Open or Low-Side Short to Ground

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Data Mode Clear System Fault	Does DST 2300 reset with engine idling?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect harness from the ECM Disconnect the ignition coil from the harness Using a high impedance DVOM measure the resistance between pin 27 of the ECM connector and pin C of the coil connector	Does the DVOM display a resistance of 5.0 Ohms or less?	Go to Step (5)	Go to Step (6)
4	Intermittent fault			
5	Using a DVOM measure the resistance between pins C and D on the ignition coil	Does the DVOM display a resistance of 5.0 Ohms or less?	Go to Step (7)	Go to Step (8)
6	Find and repair the open in the harness			
7	Faulty connection at ECM or coil or Faulty ECM			
8	Replace faulty coil			

DTC 2301 - 1 Primary Coil Shorted



Conditions for Setting the DTC

- Check Condition: Key ON, Engine On
- Fault Condition: If dwell current control = 'Adaptive Dwell' dwell adjustment = -1 ms, or total dwell ≤ 1 ms; If dwell current control = 'Monitor Only': dwell adjustment < 5.5 amps, or total dwell < 90 μ s.
- MIL: ON for active fault
- Power derate 1
- Adaptive: Disabled

Circuit Description

Coil driver #1 fires either the 1st cylinder in the firing order or the 1st cylinder in the block order depending on the configuration of the 'Injector/Spark Diagnostic Numbering' scheme as set in calibration. The purpose of this fault is to detect a short-to-ground or open circuit in the harness or internal to the primary coil.


Fault Description

This fault will set if the ECM detects x number of coil firings in which the adaptive dwell adjustment is greater than y ms. or the total dwell is greater than w ms. and battery voltage is greater than z volts as defined in the diagnostic calibration.

DTC 2301 - 1 Primary Coil Shorted

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Running System Data Mode Clear System Fault	Does DST 2301 reset with engine idling?	Go to Step (3)	Go to Step (4)
3	Key Off Disconnect the ignition coil from the harness Using a high impedance DVOM measure the resistance between pins C and D on the ignition coil	Does the DVOM display a resistance of 1.5 Ohms or more?	Go to Step (5)	Go to Step (6)
4	Intermittent fault			
5	Disconnect harness connector from the ECM Check between pin 27 of the ECM connector and pin C of the coil connector for a short to ground NOTE: Perform this test using a DVOM and check one pin at a time to battery ground	Is circuit shorted?	Go to Step (7)	Go to Step (8)
6	Replace the coil			
7	Repair short to ground in harness			
8	Faulty coil or faulty ECM			

DTC 3011 - UEGO1 Internal Processor Fault



Conditions for Setting the DTC

- Check Condition: Key ON, Engine Running
- Fault Condition: Break in communication has occurred between the UEGO controller and the main micro- controller (both devices inside the ECM). The UEGO controller is no longer responsive.
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. Internal to the ECM there is an application specific integrated circuit/controller that controls the sensor. The UEGO controller communicates internally within the ECM to the main microcontroller. The UEGO controller must always be functioning and communicating with the main microcontroller for proper emissions control.


Fault Description

This fault may set if the power supplied to the ECM (alternator or battery power) is excessively noisy and exhibits low voltage dips or dropouts. It may also indicate an internal failure within the ECM. This fault should be configured to disable adaptive learn for the remainder of the key-cycle to avoid improperly learning the adaptive learn table and may be configured to disable closed loop.

Diagnostic Aids

- Verify that the alternator is working properly and there is not excessive noise on the alternator output or battery power from other loads. This fault may occur if power repeatedly dips but does not completely drop to zero.
- Verify the ECM ground is sufficient (clean and tight to the engine block)
- Swap ECM with a known good part, run engine for 10 minutes, and then retest.

DTC 3012 - UEGO1 Heater Supply High Voltage



Conditions for Setting the DTC

- Check Condition: Key ON, Engine Running
- Fault Condition: UEGO heater supply voltage > 32 volts.
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. The sensor is heated with an internal resistor element that is supplied by the battery voltage and switched on/off by the ECM. The ECM will pull the heater control signal to ground when turning on the heater. The ECM monitors the heater control signal for a short to Vbattery. If the control signal does not reach zero volts when the heater is turned on then the circuit is not functioning properly. The UEGO heater circuit must always be functioning for proper emissions control.


Fault Description

This fault will set when the UEGO heater control signal does not achieve zero volts when the heater is switched on. This may be caused by an internal fault within the ECM. This fault should be configured to disable adaptive learn for the remainder of the key-cycle to avoid improperly learning the adaptive learn table and may be configured to disable closed loop.

DTC 3012 - UEGO1 Heater Supply High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key ON, Engine Stopped Disconnect the harness from the UEGO Sensor With a DMM, measure the heater resistance and look for short. (For both Bosch sensor, measure the resistance between the white and grey lines connected to pins 3 and 4.) Normal resistance is approximately 2.5 ohms.	Is the resistance < 0.5 ohms?	Go to Step (3)	Go to Step (4)
3	Disconnect the harness from the UEGO sensor and ECM Check the heater control signal (Test between Pin 3 of the UEGO sensor and Pin 75 of the ECM) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to the positive battery terminal	Is circuit shorted?	Go to Step (5)	Go to Step (6)
4	UEGO heater element has short. Replace UEGO sensor			
5	Repair short to Vbattery in harness			
6	Replace ECM			

DTC 3014 - UEGO1 Cal Resistor Voltage High



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault Condition: Voltage feedback from the UEGO calibration resistor is high.
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

Typically UEGO sensors will have a calibration resistor built into the connector. This provides calibration information to the ECM, allowing the ECM to interpret the signals from the sensor correctly

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2


Fault Description

This fault will set when the UEGO calibration resistor signal does not achieve zero volts when the UEGO is switched on. This may be caused by an internal fault within the ECM.

DTC 3014 - Cal Resistor Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key Off, Engine Stopped Disconnect the harness from the UEGO Sensor and ECM Check the sense control signal (test between Pin 6 of the UEGO sensor and the ECM pin assigned to UEGOS) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to battery plus.	Is circuit shorted?	Go to Step (3)	Go to Step (4)
3	Repair short to Vbattery in harness			
4	Faulty UEGO Sensor or Faulty ECM			

DTC 3020 - UEGO1 Sense Cell Voltage High



Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: Voltage feedback from the UEGO sensor sense control signal is equal to battery or supply voltage (short to Vbattery.)
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. The sensor has a sense control signal between the sense cell and the ECM. The ECM monitors the sense control signal for a short to Vbattery. The UEGO sense circuit must always be functioning for proper emissions control.


Fault Description

This fault will set when the UEGO sense control signal is continuously equal to battery voltage (short to Vbattery.) This may be caused by a faulty UEGO sensor or a short in the harness to Vbattery. This fault should be configured to disable adaptive learn for the remainder of the key-cycle to avoid improperly learning the adaptive learn table and may be configured to disable closed loop.

DTC 3020 - Sense Cell Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key Off, Engine Stopped Disconnect the harness from the UEGO Sensor and ECM Check the sense control signal (test between Pin 6 of the UEGO sensor and Pin 18 of the ECM) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to battery plus.	Is circuit shorted?	Go to Step (3)	Go to Step (4)
3	Repair short to Vbattery in harness			
4	Faulty UEGO Sensor or Faulty ECM			

DTC 3024 - UEGO1 Sense Cell Slow To Warm Up



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault Condition: Internal fault message communicated to ECM over CAN
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

UEGO sensors comprise of both a pump cell and a sense cell.

If the pump cell is at its drive limit it means it is no longer in control. This

fault is only applicable to non-smart NGK UEGO sensors.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

Fault Description


- Poor harness connections
- Faulty sensor

NOTE: The UEGO sense cell slow to warm up faults are currently only "set" when running the Closed-Loop test from the Tests page in EDIS. As such these will not complete during normal operation of the engine.

Diagnostic Aids

- Check harness (post-control box harness, sensor side) for poor connections
- Replace sensor with known good unit and re-test

DTC 3026 - UEGO1 Sense Cell Impedance High



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault Condition: Pump cell did not warm up within the time limit, or warmup period and additional 180.0 seconds elapsed without achieving normal operation
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

UEGO sensors comprise of both a pump cell and a sense cell.

If the pump cell is at its drive limit it means it is no longer in control. This

fault is only applicable to non-smart NGK UEGO sensors.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

Fault Description

For non-smart sensor this fault is set if the sensor does not warm up and achieve normal operation within the specified time limit. This may be a result of

- Poor harness connections
- Faulty sensor


For smart CAN based UEGO sensors this fault is internally triggered and communicated to the ECM via the CAN bus.

NOTE: The **UEGO sense cell slow to warm up** faults are currently only "set" when running the Closed-Loop test from the **Tests** page in EDIS. As such these will not complete during normal operation of the engine.

Diagnostic Aids

- Check harness for poor connections
- Replace sensor with known good unit and re-test

DTC 3029 - Drift Is Out-Of-Tolerance



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault Condition: • UEGO drift compensation accumulator $< -12.0\% I_p$ or $> 12.0\% I_p$
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

UEGO sensors comprise both a pump cell and a sense cell.

If the pump cell is at its drive limit it means it is no longer in control. This

fault is only applicable to non-smart NGK UEGO sensors.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.


Fault Description

This fault will set when the UEGO drift adjustment (accumulator) exceeds the maximum positive or negative thresholds (pump current I_p) set in the diagnostic calibration. This fault is caused by a faulty UEGO sensor.

Diagnostic Aids

Due to the nature of this fault and given the internal diagnostic checks that occur prior to setting this fault, the best diagnostic course of action is to replace the sensor and clear the code.

DTC 3030 - Drift Is Out-Of-Tolerance – Level 2



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked
- Fault Condition: • UEGO drift compensation accumulator <-15.0% lp or > 15.0%lp
- MIL: ON for active fault
- Adaptive: Disabled

Circuit Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

The UEGO sensor should read a fixed value in fresh air. The UEGO drift can be determined by comparing the fresh air reading with the expected fresh air reading.

The fresh air reading is taken during Fuel Shut off. A new measurement is attempted during every FSO event and the successful measurements are fed into an accumulator, to provide a smooth accurate reading

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.


Fault Description

This fault will set when the UEGO drift adjustment (accumulator) exceeds the maximum positive or negative thresholds (pump current lp) set in the diagnostic calibration. This fault is caused by a faulty UEGO sensor.

Diagnostic Aids

Due to the nature of this fault and given the internal diagnostic checks that occur prior to setting this fault, the best diagnostic course of action is to replace the sensor and clear the code.

DTC 3031 - UEGO1 Heater Open/Ground Short



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: UEGO heater low-side feedback < 5% of Vbattery for 2 seconds and PWM duty cycle < 5%
- MIL: ON during active fault
- Closed Loop Disabled

Fault Description


A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. The sensor is heated with an internal resistive element that is supplied by the battery voltage and switched on/off by the ECM. The ECM will pull the heater control signal to ground when turning on the heater. The ECM monitors the heater control signal for a short to ground. If the control signal is not equal to Vbattery with the heater is turned off, then the circuit is not functioning properly. The UEGO heater circuit must always be functioning for proper emissions control.

This fault will set when the UEGO heater control signal does not achieve Vbattery when the heater is switched off. This may be caused by a bad heater element on the UEGO sensor, a break in the wire harness on the heater supply or control circuits, or fault within the ECM.

DTC 3031 - UEGO1 Heater Open/Ground Short

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key Off, Engine Stopped Disconnect the harness from the UEGO Sensor and ECM With a DMM, measure the heater resistance (For Bosch sensor, measure the resistance between the white and grey lines connected to pins 3 and 4.) Normal resistance is approximately 2.5 ohms.	Is the resistance > 50 ohms?	Go to Step (3)	Go to Step (4)
3	UEGO heater element is bad Replace UEGO sensor			
4	Disconnect the harness from the ECM With DMM, check for continuity in the harness on the heater control signal (Test between Pin 3 on the UEGO sensor connector and Pin 75 on the ECM connector)	Does continuity exist (Is resistance < 5 ohms)?	Go to Step (5)	Go to Step (6)
5	Replace ECM			
6	Repair/Replace circuit in harness			

DTC 3032 - UEGO1 Heater Short to Power



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: UEGO heater low-side feedback < 90% of Vbattery for 2 seconds and PWM duty cycle < 90%
- MIL: ON during active fault
- Closed Loop Disabled

Fault Description


A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. The sensor is heated with an internal resistive element that is supplied by the battery voltage and switched on/off by the ECM. The ECM will pull the heater control signal to ground when turning on the heater. The ECM monitors the heater control signal for a short to ground. If the control signal is not equal to Vbattery with the heater is turned off, then the circuit is not functioning properly. The UEGO heater circuit must always be functioning for proper emissions control.

This fault will set when the UEGO heater control signal does not achieve zero volts when the heater is switched on. This may be caused by an internal fault within the ECU.

DTC 3032 - UEGO1 Heater Short to Power

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key Off, Engine Stopped Disconnect the harness from the UEGO Sensor and ECM With a DMM, measure the heater resistance (For Bosch sensor, measure the resistance between the white and grey lines connected to pins 3 and 4.) Normal resistance is approximately 2.5 ohms.	Is the resistance < 0.5 ohms?	Go to Step (3)	Go to Step (4)
3	UEGO heater element is bad Replace UEGO sensor			
4	Disconnect the harness from the ECM Check the heater control signal (Test between Pin 3 and the UEGO sensor and Pin 75 of the ECM) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to the positive battery terminal	Is circuit shorted?	Go to Step (5)	Go to Step (6)
5	Replace ECM			
6	Repair/ short to Vbattery in harness			

DTC 8901 - UEGO1 Internal Processor Fault



Conditions for Setting the DTC

- Check Condition: Key On
- MIL: ON during active fault
- Closed Loop and Adaptive Learn Disabled

Fault Description


A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. Internal to the ECM there is an application specific integrated circuit/controller that controls the sensor. The UEGO controller communicates internally within the ECM to the main microcontroller. The UEGO controller must always be functioning and communicating with the main microcontroller for proper emissions control.

This fault may be set if the power supplied to the ECM (alternator or battery power) is excessively noisy and exhibits low voltage dips or dropouts. It may also indicate an internal failure within the ECM. The fault will disable closed loop and adaptive learn for the remainder of the key cycle.

Diagnostic Aids

- Verify that the alternator is working properly and there is not excessive noise on the alternator output or battery power from other loads. This fault may occur if power repeatedly dips but does not completely drop out to zero.
- Verify the ECM ground is sufficient (clean and tight to the engine block).
- Swap ECM with a known good part, run engine for 10 minutes, and then retest.

DTC 8902 - UEGO1 Heater Supply High Voltage



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: UEGO heater supply voltage > 32V
- MIL: ON during active fault
- Adaptive Disabled

Fault Description


A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. The sensor is heated with an internal resistive element that is supplied by the battery voltage and switched on/off by the ECM. The ECM will pull the heater control signal to ground when turning on the heater. The ECM monitors the heater control signal for a short to ground. If the control signal is not equal to Vbattery with the heater is turned off, then the circuit is not functioning properly. The UEGO heater circuit must always be functioning for proper emissions control.

This fault will set when the UEGO heater control signal is greater than 32V when the heater is switched on. This may be caused by an internal fault within the ECM. This fault will disable adaptive learn and light the MIL.

DTC 8902 - UEGO1 Heater Supply High Voltage

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Go to OBD System Check Section
2	Key Off, Engine Stopped Disconnect the harness from the UEGO Sensor and ECM With a DMM, measure the heater resistance (For Bosch sensor, measure the resistance between the white and grey lines connected to pins 3 and 4.) Normal resistance is approximately 2.5 ohms.	Is the resistance < 0.5 ohms?	Go to Step (3)	Go to Step (4)
3	UEGO heater element has short Replace UEGO sensor			
4	Disconnect the harness from the ECM Check the heater control signal (Test between Pin 3 and the UEGO sensor and Pin 75 of the ECM) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to the positive battery terminal	Is circuit shorted?	Go to Step (5)	Go to Step (6)
5	Replace ECM			
6	Repair/ short to Vbattery in harness			

DTC 8904 - UEGO1 Internal Supply Voltage Low



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: UEGO internal supply voltage is low
- MIL: ON during active fault
- Closed Loop Disabled

Fault Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

This fault sets whenever the UEGO processing circuitry supply voltage is too low for normal operation, and the Vbat or Vrelay low-pass filtered voltage supplying power to the UEGO circuitry is > 9.0V. Typically, this fault only sets when the power is noisy due to a failed alternator or another supply voltage problem and the ECM is unable to monitor the noise via the low-passed supply feedback.

Diagnostic Aids

- Inspect alternator and repair/replace as needed.
- Troubleshoot supply voltage source; repair/replace as needed
- Replace UEGO sensor and re-test
- Replace ECM and re-test

The diagram illustrates the electrical connections between a UEGO sensor, an ECM, a UEGO controller, and a microcontroller. The UEGO sensor (left) includes a sense cell, pump cell, trim resistor, and heater. The ECM (right) provides control signals (SENSE CONTROL, PUMP/SENSE RETURN, PUMP CONTROL, HEATER CONTROL) and feedback (HEATER FEEDBACK) to the UEGO sensor. The UEGO controller and microcontroller are connected to the ECM pins for monitoring and control. The heater is connected to the ECM and the system power relay (Vrelay).

- Check Condition: Engine Running/Stopped Checked (user-defined in calibration)
- Fault Condition: Voltage feedback from the UEGO sensor sense cell signal is high.
- MIL: ON during active fault
- Closed Loop Disabled

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

If the pump cell is at it drive limit it means it is no longer in control.


The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

It may be a result of a faulty sensor, poor harness, or ECM failure.

DTC 8910 - UEGO1 Sense Cell Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key OFF Engine Stopped Disconnect the harness from the UEGO sensor and ECM. Check the sense control signal (test between Pin 6 of the UEGO sensor and the ECM pin assigned to UEGOS) for a short to Vbattery. NOTE: Perform this test using a DMM and check one pin at a time to battery plus	Is the circuit shorted?	Go to Step (3)	Go to Step (4)
3	Repair short to Vbattery in harness			-
4	Faulty UEGO Sensor or Faulty ECM			

DTC 8914 - UEGO1 Sense Cell Slow to Warm Up



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked (user-defined in calibration)
- Fault Condition: Internal fault message communicated to ECM over CAN
- MIL: ON during active fault
- Closed Loop Disabled

Fault Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

UEGO sensors comprise of both a pump cell and a sense cell.

If the pump cell is at it drive limit it means it is no longer in control.

This fault is only applicable to non-smart NGK UEGO sensors.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

- Poor harness connections
- Faulty sensor

NOTE: The UEGO sense cell slow to warm up faults are currently only "set" when running the Closed-Loop test from the Tests page in EDIS. As such these will not complete during normal operation of the engine.

Diagnostic Aids:

- Check harness (post-control box harness, sensor side) for poor connections
- Replace sensor with known good unit and re-test

DTC 8915 - UEGO1 pump cell slow to warm up

Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked (user-defined in calibration)
- Fault Condition: Pump cell did not warm-up within time limit
- MIL: ON during active fault
- Closed Loop Disabled


Fault Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. Internal to the ECM there is an application specific integrated circuit/controller that controls the sensor. The UEGO controller communicates internally within the ECM to the main microcontroller. The UEGO controller must always be functioning and communicating with the main microcontroller for proper emissions control.

Diagnostic Aids:

PSI Released revised calibrations to address nuisance DTC 8915 codes. Check the calibration number and revision to determine if you have the latest calibration installed. Contact PSI technical support for guidance. See PSI Product Bulletin PSI240016.

DTC 8916 - UEGO1 Sense Cell Impedance High



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked (user-defined in calibration)
- Fault Condition: UEGO sense cell impedance is high
- MIL: ON during active fault
- Closed Loop Disabled

Fault Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio. Internal to the ECM there is an application specific integrated circuit/controller that controls the sensor. The UEGO controller communicates internally within the ECM to the main microcontroller. The UEGO controller must always be functioning and communicating with the main microcontroller for proper emissions control.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

For non-smart CAN based UEGO sensors this fault is triggered when the impedance of sense cell is too high, which indicates that the sensor has not warmed up correctly.


It may be a result of cracked sensor, poor harness or ECM failure.

For smart CAN based sensors, the sensor self-diagnoses a heater failure and transmits the diagnostic to the ECM

Diagnostic Aids:

- Check harness (post-control box, sensor side) for poor connections.
- Replace sensor with known good unit and re-test.

DTC 8920 - UEGO1 Internal Supply Voltage Low



Conditions for Setting the DTC

- Check Condition: Engine Running/Stopped Checked (user-defined in calibration)
- Fault Condition: UEGO internal supply voltage is low
- MIL: ON during active fault
- Closed Loop Disabled

Fault Description

A UEGO sensor measures the exhaust content across a wide-range of air-fuel ratios with a linear output proportional to lambda/equivalence ratio/air-fuel ratio.

The ECM examines the sensors in order (1-4). The first pre-catalyst sensor found will be associated with Bank 1. The second pre-catalyst sensor will be associated with Bank 2 or will be used for averaging. The first post-catalyst sensor will be associated with Bank 1. The second post-catalyst sensor will be associated with Bank 2.

This fault sets whenever the UEGO processing circuitry supply voltage is too low for normal operation, and the Vbat or Vrelay low-pass filtered voltage supplying power to the UEGO circuitry is > 9.0V. Typically, this fault only sets when the power is noisy due to a failed alternator or another supply voltage problem and the ECM is unable to monitor the noise via the low-passed supply feedback

Diagnostic Aids:

- Inspect alternator and repair/replace as needed.
- Troubleshoot supply voltage source; repair/replace as needed
- Replace UEGO sensor and re-test
- Replace ECM and re-test

Definitions

Air Valve Vacuum (AVV): The vacuum signal taken from below the air valve assembly and above the throttle butterfly valve.

ADP: Adaptive Digital Processor.

Air/Fuel Ratio: The amount or balance of air and fuel in the air fuel mixture that enters the engine.

Analog Voltmeter: A meter that uses a mechanical needle to point to a value on a scale of numbers. It is usually of the low impedance type and used to measure voltage and resistance.

Aromatics: Pertaining to or containing the six-carbon ring characteristic of the benzene series. Found in many petroleum distillates.

Backfire: Combustion of the air/fuel mixture in the intake or exhaust manifolds. A backfire can occur if the intake or exhaust valves are open when there is a mis-timed ignition spark.

Benzene: An aromatic (C_6H_6). Sometimes blended with gasoline to improve anti-knock value. Benzene is toxic and suspected of causing cancer.

Bi-Fueled: A vehicle equipped to run on two fuels.

Blow-By: Gases formed by the combustion of fuel and air, which ordinarily should exert pressure only against the piston crown and first compression ring. When rings do not seal, these gases escape or "blow by" the side of the piston into the crankcase.

BTU: British Thermal Unit. A measurement of the amount of heat required to raise the temperature of 1lb. of water 1 degree F.

Butane: An odorless, colorless gas, C_4H_{10} found in natural gas and petroleum. One of the five LP gases.

CAFE: Corporate Average Fuel Economy.

CARB: California Air Resources Board.

Carbon Monoxide (CO): A chemical compound of a highly toxic gas that is both odorless and colorless.

Carburetor: An apparatus for supplying an internal-combustion engine a mixture of vaporized fuel and air.

Cathode Ray Tube: A vacuum tube in which cathode rays usually in the form of a slender beam are projected on a fluorescent screen and produce a luminous spot.

Circuit: A path of conductors through which electricity flows.

Closed Loop Operation: Applies to systems utilizing an oxygen sensor. In this mode of operation, the system uses oxygen sensor information to determine air/fuel ratio. Adjustments are made accordingly and checked by comparing the new oxygen sensor to previous signals. No stored information is used.

CNG: Compressed Natural Gas.

CKP: Crankshaft Position Sensor

CMP: Camshaft Position Sensor

Conductor: A material, normally metallic, that permits easy passage of electricity.

Contaminants: Impurities or foreign material present in fuel.

Control Module: One of several informal names for a solid state microcomputer which monitors engine conditions and controls certain engine functions; i.e. air/fuel ratio, injection and ignition time, etc. The formal name and the one used throughout this manual is ECM, or Engine Control Module.

Converter: A LPG fuel system component containing varying stages of fuel pressure regulation combined with a vaporizer.

Cryogen: A refrigerant used to obtain very low temperatures.

Current: The volume or flow of electrons through a conductor. Measured in amperes or amps. **DBW:** Drive By Wire

Dedicated Fuel System: A motor fuel system designed to operate on only one fuel type.

Diaphragm: A thin, flexible membrane that separates two chambers. When the pressure in one chamber is lower than in the other chamber, the diaphragm will move toward the side with the low pressure.

Diaphragm Port: The external port located at the fuel inlet assembly and connected to the vacuum chamber above the air valve diaphragm.

DLC: Data Link Connector.

DTC: Diagnostic Trouble Code

DST: Diagnostic Scan Tool.

DVOM: Digital Volt/ohm Meter. A meter that uses a numerical display in place of a gauge and is usually of the high impedance type.

ECT: Engine Coolant Temperature.

ECM: Electronic Control Module

ECOM: A DLC cable supporting CAN and serial communication with a NGE/ECControls ECM.

EFI: Electronic Fuel Injection. A fuel injection system, which uses a microcomputer (ECM) to determine and control the amount of fuel, required by, and injected into, a particular engine.

EGO: Exhaust Gas Oxygen, used to describe a sensor. Also known as "HEGO" (Heat Exhaust Gas Oxygen) sensor, " O_2 " or "Oxygen sensor."

EGR: Exhaust Gas Recirculation.

EPA: Environmental Protection Agency: A regulating agency of the Federal government which, among other duties, establishes and enforces automotive emissions standards.

Ethanol: Grain alcohol (C_2H_5OH), generally produced by fermenting starch or sugar.

Evaporative Emissions Controls: An automotive emission control system designed to reduce hydrocarbon emissions by trapping evaporated fuel vapors from the fuel system.

Excess Flow Valve: A check valve that is caused to close by the fuel when the flow exceeds a pre-determined rate.

FTV: Fuel Trim Valve.

FFV: Flexible Fuel Vehicle.

Firing Line: The portion of an oscilloscope pattern that represents the total amount of voltage being expended through the secondary circuit. **FMVSS:** Federal Motor Vehicle Safety Standards. **FPP:** Foot Pedal Position Sensor

Fuel Injector: a spring loaded, electromagnetic valve which delivers fuel into the intake manifold, in response to an electrical input from the control module.

Fuel Lock: A solenoid-controlled valve located in the fuel line to stop the flow when the engine stops or the ignition switch is off.

Gasohol: 10 percent ethanol, 90 percent gasoline. Often referred to as E-10.

Gasoline: A motor vehicle fuel that is a complex blend of hydrocarbons and additives. Typical octane level is 89.

GCP: Spectrum III (90-pin) ECM.

Greenhouse Effect: A scientific theory suggesting that carbon dioxide from the burning of fossil fuels is causing the atmosphere to trap heat and cause global warming.

HC: Hydrocarbon. An organic chemical compound.

HD 10: A fuel of not less than 80% liquid volume propane and not more than 10% liquid volume propylene.

HD 5: A fuel of not less than 90% liquid volume propane and not more than 5% liquid volume propylene.

HDV: Heavy Duty Vehicle.

Heavy Ends: A term used to describe the buildup of wax-like impurities that fall out of LPG when vaporized.

HEGO: Heated Exhaust Gas Oxygen, used to describe a sensor. Also known as "EGO" (Exhaust Gas Oxygen sensor), "O₂" or "Oxygen sensor."

Hg: Chemical symbol for the element mercury. Used in reference to a measure of vacuum (inches of Hg).

Histogram: The graphical version of a table which shows what proportion of values fall into specific

categories over a specific period of time.

Hydrocarbon: A chemical compound made up of hydrogen and carbon (HC). Gasoline and almost all other fuels are hydrocarbons.

Hydrostatic Relief Valve: A pressure relief device installed in the liquid LPG hose on a LPG fuel system.

IAT: Intake Air Temperature

Ideal Mixture: The air/fuel ratio at which the best compromise of engine performance to exhaust emissions is obtained. Typically, 14.7:1.

Ignition Reserve: The difference between available voltage and the required voltage.

ILEV: Inherently Low Emission Vehicle.

Impedance: A form of opposition of AC electrical current flow (resistance) measured in ohms.

Insulation: A nonconductive material used to cover wires in electrical circuits to prevent the leakage of electricity and to protect the wire from corrosion.

Intercept: An electrical term for a type of splice where the original circuit is interrupted and redirected through another circuit.

Knock: Sound produced when an engine's air/fuel mixture is ignited by something other than the spark plug, such as a hot spot in the combustion chamber. Also caused by a fuel with an octane rating that is too low and/or incorrect ignition timing. Also called detonation or ping.

Lambda Sensor: A feedback device, usually located in the exhaust manifold, which detects the amount of oxygen present in exhaust gases in relation to the surrounding atmosphere. (See HEGO).

LDV: Light Duty Vehicle.

Lean Mixture: An air to fuel ratio above the stoichiometric ratio; too much air.

LEV: Low Emission Vehicle.

Limp-in or Limp Home: A mode where the ECM or a component has failed, but the vehicle remains operational although the engine may operate minimally. This term may also describe the drivability characteristics of a failed computer system.

Liquid Petroleum Gas (LPG): A fuel commonly known as propane consisting mostly of propane (C_3H_8), derived from the liquid components of natural gas stripped out before the gas enters the pipeline, and the lightest hydrocarbons produced during petroleum refining. Octane level of LPG is 107.

LPG: Liquefied Petroleum Gas.

M85: A blend of gasoline and methanol consisting of 85% methanol and 15% gasoline.

Measurements of Pressure: 1 PSI=2.06" Hg (mercury) = 27.72" H₂O (water column). At sea level atmospheric pressure is 29.92" Hg.

Methanol: Known as wood alcohol (CH₃OH), a light, volatile, flammable alcohol commonly made from natural gas.

MIL: Malfunction Indicator Lamp.

Misfire: Failure of the air/fuel mixture to ignite during the power stroke.

Mixer: Fuel introduction device that does not include a throttle plate.

MFI: Multiport Fuel Injection. A fuel injection system that uses one injector per cylinder mounted on the engine to spray fuel near the intake valve area of combustion chamber.

MSV: Manual Shut-Off Valve. Refers to the manually operated valve on the LPG tank.

MTBE: Methyl Tertiary Butyl Ether. Oxygenate add to gasoline to reduce harmful emissions and to improve the octane rating.

Multi-fuel System: A motor fuel system designed to operate on two different fuels, such as LPG and gasoline.

Natural Gas: A gas formed naturally from buried organic material, composed of a mixture of hydrocarbons, with methane (CH₄) being the dominant component.

NGV: Natural Gas Vehicle.

NOX: See Oxides of Nitrogen.

OBD: On Board Diagnostic

Octane Rating: The measurement of the antiknock value of a motor fuel.

OEM: Original Equipment Manufacturer, the vehicle manufacturer.

Open-Loop: An operational mode during which control module memory information is used to determine air/fuel ratio, injection timing, etc., as opposed to actual oxygen sensor input.

Orifice: A port or passage with a calibrated opening designed to control or limit the amount of flow through it.

Oscilloscope: An instrument that converts voltage and frequency readings into traces on a cathode ray tube (also see Cathode Ray Tube).

Oxides of Nitrogen: Chemical compounds of nitrogen bonded to various amounts of oxygen (NOX). A chief smog forming-agent.

Oxygen Sensor: An automotive fuel system that produces a signal in accordance with the oxygen content of the exhaust gas. (See Lambda Sensor).

Oxygenate: Oxygenates (such as MTBE, ethanol

and methanol) added to gasoline to increase the oxygen content and therefore reduce exhaust emissions.

Ozone: A radical oxygen molecule (O₃) that is found in the upper atmosphere and filters out ultraviolet radiation from the sun. Ground level ozone is formed by NOX, during the formation of photo-chemical smog.

Particulates: Microscopic pieces of solid or liquid substances such as lead and carbon that are discharged into the atmosphere by internal combustion engines.

Positive Crankcase Ventilation (PCV): An automotive emission control system designed to reduce hydrocarbon emissions by routing crankcase fumes into the intake manifold rather than to the atmosphere.

Power Derate: A mode of reduced engine power output for the purposes of protecting engine components during a failure or malfunction.

Pressure Differential: The differential between atmospheric pressure and intake manifold (referred to as vacuum) pressure.

Pressure Regulator: A device to control the pressure of fuel delivered to the fuel injector(s).

Primary Circuit: The low-voltage or input side of the ignition coil.

Propane: An odorless and colorless gas, C₃H₈, found in natural gas and petroleum.

PSIa: pounds per square inch absolute

PTV: Pressure Trim Valve

Reactivity: Refers to the tendency of an HC in the presence of NOX and sunlight to cause a smog-forming reaction. The lighter the HC, the lower reactivity tends to be.

Regulator: An assembly used to reduce and control the pressure of a liquid or vapor.

Resistance: The opposition to the flow of current in an electrical circuit. Measured in ohms.

Rest Pressure: Fuel pressure maintained within the system after engine shutdown.

Rich Mixture: An air to fuel ratio below the stoichiometric ratio; too much fuel.

SAE: Society of Automotive Engineers.

Secondary Circuit: The high-voltage output side of the ignition coil.

SEFI or SFI: Sequential Electronic Fuel Injection or Sequential Fuel Injection.

Sensors: Devices that provide the control module with engine information as needed to properly control engine function.

Spark Line: The portion of an oscilloscope pattern that represents the time during which the air/fuel mixture is being burned in the combustion chamber.

Splice: An electrical term for the joining of two or more conductors at a single point.

Stoichiometric Ratio: An ideal fuel/air ratio for combustion in which all of the fuel and most of the oxygen will be burned.

Sulfur Oxides: Chemical compounds where sulfur is bonded to oxygen produced by the combustion of gasoline or any other fuel that contains sulfur. As sulfur oxides combine with water in the atmosphere to form sulfuric acid.

System Pressure: The fuel pressure maintained in the system during normal engine operation.

Tap: An electrical term for a type of splice where the original circuit is not interrupted.

TBI: Throttle Body Injection. Any of several injection systems that have the fuel injector(s) mounted in a centrally located throttle body.

Throttle Body: Controls engine RPM by adjusting the engine manifold vacuum to the mixer. Consists of a housing shaft, throttle liner and butterfly valve.

TLEV: Transitional Low Emission Vehicle.

TMAP: Combined Air Inlet and Manifold Pressure Sensor.

Toluene: A liquid aromatic hydrocarbon C_7H_8 .

TPS: Throttle Position Sensor.

TSB: Technical Service Bulletin.

ULEV: Ultra Low Emission Vehicle.

USB: Universal Serial Bus. A plug or interface supplied on most personal computers.

Vaporization: A process in which liquid changes states into gas.

Variable Frequency Driver (VFD): Allow electrical loads from motors to be applied gradually.

Venturi Air Valve Vacuum (VAVV): An amplified air valve vacuum signal coming from the venturi area of the mixer, directly exposed to airflow before the addition of vaporized LPG.

Volt/ohmmeter (VOM): A combination meter used to measure voltage and resistance in an electrical circuit. Available in both analog and digital types. May also referred to as AVOM and DVOM.

Voltage: The electrical pressure that causes current to flow in a circuit. Measured in volts.

Voltage Drop: A lowering of the voltage in a circuit when resistance or electrical load is added.


Voltmeter: A meter that uses a needle to point to a value on a scale of numbers usually of the low impedance type; used to measure voltage and resistance.

VSS: Vehicle Speed Sensor

Xylene: $C_6H_4(CH_3)_2$. Any of three toxic, flammable, and oily isomeric aromatic hydrocarbons that are dimethyl homologues of benzene and usually obtained from petroleum or natural gas distillates.

ZEV: Zero Emission Vehicle.

Connecting to Each ECM



NOTE:

- ECOM cable and PC with the latest revision of 4G software is needed before performing the instructions below.
- Steps 1-8 should be repeated if the secondary 4G display is closed while the engine is off. At no time should 4G display be left communicating with the primary ECM on its own.
- You can leave the display open while disconnecting the ECOM from the engine and reconnecting.

1. Connect ONE ECOM cable to the diagnostic port on the engine harness.

NOTE:

These engines only require the use of one ECOM unlike the previous GCP versions that required one per bank.

2. Start the engine.
3. Open the 4G display and verify it has connected in the to left corner.
4. Select "COMM PORT", then "Configure ECOM".
5. An ECOM configuration window will appear (Image above). For "Target CAN Address", change the "0" to a "1", then select "OK".
6. Disconnect the ECOM USB connection from your computer and reconnect. Verify secondary bank connectivity by going to the Marine page and verify secondary communications.
7. Launch a second version of 4G display to connect to the primary, verify both screens are connected.
8. Monitor the "CUST SOFTWARE NAME/NUMBER". The secondary bank will be one digit higher than the primary



Mass Fuel Gas (MFG) Diagnostic Trouble Codes

Note:

The images below each MFG DTC show the adapter harness that's used to adapt the EPR1 connector to the MFG valve.

Description	DTC	SPN	FMI
MFG RLV Test Failed	103C	2807	31
MFG Main Comm Lost	101A	520270	31
MFG Unable to Reach Higher TPS	1020	520276	31
MFG Unable to Reach Lower TPS	1021	520277	31
MFG Supply Voltage High	1022	520278	3
MFG Supply Voltage Low	1023	520278	4
MFG Fluid Temperature Voltage High	1024	520279	3
MFG Fluid Temperature Voltage Low	1025	520279	4
MFG Upstream Pressure Voltage High	1026	520280	3
MFG Upstream Pressure Voltage Low	1027	520280	4
MFG Downstream Pressure Voltage High	1028	520281	3
MFG Downstream Pressure Voltage Low	1029	520281	4
MFG Delta Pressure zVolt Voltage High	102A	520282	3
MFG Delta Pressure zVolt Voltage Low	102B	520282	4
MFG Delta Pressure Voltage High	102C	520283	3
MFG Delta Pressure Voltage Low	102D	520283	4
MFG General Fault	102E	520284	31
MFG Internal Circuitry Fault Detection	101B	520271	12

DTC 101A - MFG Main Comm Lost



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E


Conditions for Setting the DTC

- Check Condition: Engine Running
- Fault Condition: ECU received no communication from the MFG for .5 seconds
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault sets if the ECM loses CAN communication with the MFG. The fault indicates that the ECM is no longer receiving CAN packets from the MFG which also results in the MFG not receiving communication from the ECM. This is often the result of a power loss at the MFG or improper CAN termination or wiring.

DTC 101B - MFG Internal Circuitry Fault Detection



Conditions for Setting the DTC

- Check Condition: Key On, Engine Running
- Fault Condition: MFG detects an internal circuitry fault
- MIL: ON during active fault
- Engine shutdown


Fault Description

This fault will set if the MFG detects a COP (Watchdog) fault or fails to execute any of the real-time loops in a timely manner. The fault is transmitted from the MFA/AT to the ECM via CAN..

Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 102A - MFG Delta Pressure zVoltage High



Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid delta pressure sensor thermal compensation circuit output voltage is higher than the internally defined high voltage limit.



Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 102A - MFG Delta Pressure zVoltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key OFF Engine Running System Mode ="Running" Clear fault with DST and see if the fault resets	Fault resets?	Go to Step (3)	Go to Step (4)
3	Replace MFG and re-test			-
4	Intermittent problem – unable to diagnose at this time			

DTC 102B - MFG Delta Pressure zVoltage High



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid delta pressure sensor thermal compensation circuit output voltage is lower than the internally-defined high voltage limit.



Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 102B - MFG Delta Pressure zVoltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key OFF Engine Running System Mode ="Running" Clear fault with DST and see if the fault resets	Fault resets?	Go to Step (3)	Go to Step (4)
3	Replace MFG and re-test			-
4	Intermittent problem – unable to diagnose at this time			

DTC 102C - MFG Delta Pressure Voltage High



FROM TO CONNECTOR CHART		
WIRE COLOR	C1	C2
RED W/ WHITE STRIPE	5	A
RED W/ TAN STRIPE	6	B
BLACK	4	C
WHITE	1	D
RED W/ BLACK STRIPE	2	E

Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid delta pressure sensor output voltage is lower than the internally-defined high voltage limit.


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 102C - MFG Delta Pressure Voltage High

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key OFF Engine Running System Mode ="Running" Clear fault with DST and see if the fault resets	Fault resets?	Go to Step (3)	Go to Step (4)
3	Replace MFG and re-test			-
4	Intermittent problem – unable to diagnose at this time			

DTC 102D - MFG Delta Pressure Voltage Low



Conditions for Setting the DTC

- Check Condition: Engine Running or cranking
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set if the MFG fluid delta pressure sensor output voltage is lower than the internally-defined high voltage limit.


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 102D - MFG Delta Pressure Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key OFF Engine Running System Mode ="Running" Clear fault with DST and see if the fault resets	Fault resets?	Go to Step (3)	Go to Step (4)
3	Replace MFG and re-test			-
4	Intermittent problem – unable to diagnose at this time			

DTC 102E - MFG Delta Pressure Voltage Low



Conditions for Setting the DTC

- Check Condition: Key On
- Fault Condition: Fault is diagnosed internally within the MFG then relayed to the ECM via CAN communication
- MIL: ON during active fault
- Engine shutdown

Fault Description

This fault will set after a latch period if the MFG experiences a general error which includes a EEPROM failures, internal timing overload failures, or a general calibration issues.


Diagnostic Aid

- Replace MFG with known good unit and retest.

DTC 102E - MFG Delta Pressure Voltage Low

Step	Action	Value(s)	Yes	No
1	Did you perform the On-Board (OBD) System Check?	-	Go to Step (2)	Goto OBD System Check Section
2	Key OFF Engine Running System Mode ="Running" Clear fault with DST and see if the fault resets	Fault resets?	Go to Step (3)	Go to Step (4)
3	Replace MFG and re-test			-
4	Intermittent problem – unable to diagnose at this time			

DTC 103C - MFG RLV Test Failed



Conditions for Setting The DTC

- Check Conditions: Engine Running
- Fault Conditions: Fuel run-out engine run time >
- " Number of engine warm cycles between runs
- " Engine hours elapsed before forced test run
- MIL: ON during active fault
- Engine shutdown

Fault Description

If MFG redundant lockoff verification is enabled, MFG applications will verify the operation of the secondary lockoff device when the number of warm engine cycles or elapsed engine hours specified for the MFG RLV test failed diagnostic have occurred since the previous execution of the test.

The test starts when the key is turned off or a remote engine stop command is received. Fuel run-out is engaged and only the secondary lockoff device is closed. The test is successful if the engine stops before the fuel run-out engine run time threshold calibrated for the MFG RLV test failed diagnostic is exceeded. The test fails if that diagnostic becomes active-latched.

Pro-Lube Electrical Diagrams




Figure 1. Pre-Lube Module Electrical Diagram

NOTE:

- The pre-lube module must be installed with the isolators and nylon nuts in order to prevent engine vibration damaging the electrical components within the module.
- The WHITE (WH) wire connects to a positive output of the start circuit. The positive coil of the start relay or the "S" terminal on the starter may be used.
- The PINK (PK) wire must connect to a Battery + signal that indicates when the engine is running.
- To enable the emergency stop capability to the pre-lube, an emergency shutoff switch or similar switch supplying +24 VDC to the ORANGE (OR) wire of the main harness will safely shut system off when needed. If no connection is made to orange wire, the pre-lube will continue to run cycles unless the batteries are disconnected.

Pre-Lube Electrical Diagrams – Continued




Figure 2. Pre-Lobe Pump Electrical Diagram



**POWER SOLUTIONS
INTERNATIONAL**

**Power Solutions International,
Inc (PSI) 201 Mittel Drive
Wood Dale,
IL 60191 USA
630-350-9400**